

## GROUP 42A

## BODY

## CONTENTS

<b>HOOD</b> .....	<b>42A-4</b>	<b>STRUT TOWER BAR</b> .....	<b>42A-14</b>
<b>HOOD DIAGNOSIS</b> .....	42A-4	<b>REMOVAL AND INSTALLATION</b> .	42A-14
INTRODUCTION .....	42A-4	<b>WINDOW GLASS</b> .....	<b>42A-15</b>
TROUBLESHOOTING STRATEGY ...	42A-4	<b>SPECIFICATIONS</b> .....	42A-15
<b>TROUBLE SYMPTOM CHART</b> ...	42A-4	<b>ADHESIVES</b> .....	42A-15
<b>SYMPTOM PROCEDURES</b> .....	42A-4	<b>GENERAL</b> .....	42A-15
<b>ON-VEHICLE SERVICE</b> .....	42A-5	<b>WINDOW GLASS DIAGNOSIS</b> ...	42A-17
ADJUSTMENT OF CLEARANCE		INTRODUCTION TO WINDOW GLASS	
AROUND HOOD .....	42A-5	DIAGNOSIS .....	42A-17
ALIGNMENT OF HOOD LATCH AND		WINDOW GLASS DIAGNOSTIC	
STRIKER .....	42A-5	TROUBLESHOOTING STRATEGY.....	42A-17
ADJUSTMENT OF HOOD HEIGHT ...	42A-6	<b>WINDOW GLASS DIAGNOSTIC</b>	
<b>HOOD</b> .....	42A-7	<b>TROUBLE SYMPTOM CHART</b> ...	42A-17
HOOD REMOVAL AND INSTALLATION	42A-7	<b>SYMPTOM PROCEDURES</b> .....	42A-17
INSPECTION.....	42A-8	<b>SPECIAL TOOL</b> .....	42A-17
DISASSEMBLY AND ASSEMBLY.....	42A-8	<b>WINDSHIELD</b> .....	42A-18
<b>FENDER</b> .....	<b>42A-10</b>	REMOVAL AND INSTALLATION.....	42A-18
<b>REMOVAL AND INSTALLATION</b> .	42A-10	<b>REAR WINDOW GLASS</b> .....	42A-23
<b>SPLASH SHIELD</b> .....	<b>42A-12</b>	REMOVAL AND INSTALLATION.....	42A-23
<b>REMOVAL AND INSTALLATION</b> .	42A-12		
<b>FUEL FILLER LID</b> .....	<b>42A-13</b>		
<b>REMOVAL AND INSTALLATION</b> .	42A-13		

Continued on next page

<b>DOOR</b> .....	<b>42A-27</b>	ADJUSTMENT .....	42A-120
<b>SPECIFICATIONS</b> .....	42A-15	POWER WINDOW CHECK .....	42A-121
SERVICE SPECIFICATIONS .....	42A-27	GLASS SLIDING MECHANISM CHECK AND ADJUSTMENT .....	42A-121
SEALANT .....	42A-27	POWER WINDOW SAFETY MECHANISM CHECK <DRIVER'S SIDE ONLY> .....	42A-122
LUBRICANT .....	42A-27	POWER WINDOW TIMER FUNCTION CHECK .....	42A-122
COMPONENT IDENTIFICATIONS .....	42A-27	POWER WINDOW OPERATING CURRENT CHECK .....	42A-122
<b>GENERAL INFORMATION</b> .....	42A-27	LEARNING PROCEDURES OF THE POWER WINDOW FULLY CLOSED POSITION <DRIVER'S SIDE ONLY> ..	42A-123
<b>CENTRAL DOOR LOCKING SYSTEM</b>		CENTRAL DOOR LOCKING SYSTEM CHECK .....	42A-124
<b>DIAGNOSIS</b> .....	42A-30	CHECK OF KEY LOCK PREVENTION FUNCTION .....	42A-124
TROUBLESHOOTING STRATEGY ...	42A-30	SHIFT "P" INTERLINK DOOR UNLOCK FUNCTION CHECK <TC-SST> .....	42A-124
TROUBLE SYMPTOM CHART .....	42A-30	IGNITION "LOCK (OFF)" POSITION-LINKED DOOR UNLOCKING FUNCTION CHECK <M/T, TC-SST> .....	42A-124
<b>SYMPTOM PROCEDURES &lt;CENTRAL DOOR LOCKING SYSTEM&gt;</b> .....	42A-31	DOOR OUTSIDE HANDLE PLAY CHECK .....	42A-125
<b>POWER WINDOW DIAGNOSIS</b> ..	42A-64	DOOR INSIDE HANDLE CHECK .....	42A-125
TROUBLESHOOTING STRATEGY ...	42A-64	CUSTOMIZATION FUNCTION .....	42A-127
DIAGNOSTIC TROUBLE CODE CHART	42A-64		
TROUBLE SYMPTOM CHART .....	42A-64		
<b>DIAGNOSTIC TROUBLE CODE PROCEDURES &lt;POWER WINDOW&gt;</b> .....	42A-65	<b>DOOR ASSEMBLY</b> .....	42A-128
<b>SYMPTOM PROCEDURES &lt;POWER WINDOW&gt;</b> .....	42A-74	REMOVAL AND INSTALLATION .....	42A-128
<b>CHECK AT ECU TERMINAL</b> .....	42A-110	INSPECTION .....	42A-130
<b>DOOR DIAGNOSIS</b> .....	42A-111	<b>DOOR GLASS AND REGULATOR</b> .....	42A-131
INTRODUCTION TO GLASS AND DOOR DIAGNOSIS .....	42A-111	REMOVAL AND INSTALLATION .....	42A-131
GLASS AND DOOR DIAGNOSTIC TROUBLESHOOTING STRATEGY ...	42A-111	INSPECTION .....	42A-134
SYMPTOM CHART .....	42A-111	<b>DOOR HANDLE AND LATCH</b> .....	42A-136
<b>SYMPTOM PROCEDURES</b> .....	42A-111	REMOVAL AND INSTALLATION .....	42A-136
<b>HOW TO LOCATE WIND NOISE</b> .	42A-114	INSPECTION .....	42A-140
<b>SPECIAL TOOLS</b> .....	42A-116	<b>WINDOW GLASS RUNCHANNEL AND DOOR OPENING WEATHERSTRIP</b> .....	42A-142
<b>ON-VEHICLE SERVICE</b> .....	42A-118	REMOVAL AND INSTALLATION .....	42A-142
DOOR FIT ADJUSTMENT .....	42A-118	<b>PROTECTOR FILM &lt;Vehicles without side air dam&gt;</b> .....	42A-148
DOOR WINDOW GLASS		REMOVAL AND INSTALLATION .....	42A-148

Continued on next page

<b>TRUNK LID</b> .....	<b>42A-150</b>	DIAGNOSTIC TROUBLE CODE CHART .....	42A-158
		TROUBLE SYMPTOM CHART .....	42A-158
<b>SPECIFICATIONS</b> .....	42A-15	<b>DIAGNOSTIC TROUBLE CODE PROCEDURES</b> .....	42A-159
SEALANT .....	42A-150	<b>SYMPTOM PROCEDURES</b> .....	42A-165
<b>TRUNK LID DIAGNOSIS</b> .....	42A-150	<b>CHECK AT ECU TERMINAL</b> .....	42A-185
INTRODUCTION TO TRUNK LID		<b>SPECIAL TOOLS</b> .....	42A-186
DIAGNOSIS .....	42A-150	<b>ON-VEHICLE SERVICE</b> .....	42A-187
TRUNK LID DIAGNOSTIC		WATER TEST .....	42A-187
TROUBLESHOOTING STRATEGY ...	42A-150	SUNROOF FIT ADJUSTMENT .....	42A-188
<b>TROUBLE SYMPTOM CHART</b> ...	42A-150	SUNROOF SAFETY FUNCTION CHECK .....	42A-188
<b>SYMPTOM PROCEDURES</b> .....	42A-150	SUNROOF CHECK .....	42A-188
<b>SPECIAL TOOLS</b> .....	42A-151	SUNROOF TIMER FUNCTION CHECK	42A-188
<b>ON-VEHICLE SERVICE</b> .....	42A-152	SUNROOF LID GLASS OPERATION CURRENT CHECK .....	42A-189
ADJUSTMENT OF CLEARANCE AROUND		LEARNING PROCEDURES OF THE SUNROOF FULLY CLOSED	
TRUNK LID .....	42A-152	POSITION .....	42A-189
TRUNK LID STRIKER ADJUSTMENT .	42A-152	SUNROOF OPERATION CHECK .....	42A-190
TRUNK LID HEIGHT ADJUSTMENT ...	42A-152	<b>SUNROOF</b> .....	42A-193
<b>TRUNK LID</b> .....	42A-153	SUNROOF ASSEMBLY REMOVAL AND INSTALLATION .....	42A-193
REMOVAL AND INSTALLATION .....	42A-153	INSPECTION .....	42A-195
INSPECTION .....	42A-156	DISASSEMBLY AND ASSEMBLY .....	42A-196
<b>SUNROOF</b> .....	<b>42A-157</b>	<b>LOOSE PANEL</b> .....	<b>42A-198</b>
<b>SPECIFICATIONS</b> .....	42A-15	<b>REMOVAL AND INSTALLATION</b> .....	42A-198
SERVICE SPECIFICATION .....	42A-157		
SEALANT .....	42A-157		
<b>GENERAL INFORMATION</b> .....	42A-157		
<b>SUNROOF DIAGNOSIS</b> .....	42A-158		
TROUBLESHOOTING STRATEGY ...	42A-158		

# HOOD

## HOOD DIAGNOSIS

### INTRODUCTION

Wind noise at the hood may be caused by improper hood adjustment.

M1421005800448

### TROUBLESHOOTING STRATEGY

Use these steps to plan your diagnostic strategy. If you follow them carefully, you will be sure that you have exhausted most of the possible ways to find a hood fault.

1. Gather information from the customer.

2. Verify that the condition described by the customer exists.
3. Find the malfunction by following the Symptom Chart.
4. Verify malfunction is eliminated.

M1421005900393

### TROUBLE SYMPTOM CHART

M1421006000467

Symptom	Inspection procedure	Reference page
Difficult locking and unlocking	1	<a href="#">P.42A-4</a>
Uneven body clearance	2	<a href="#">P.42A-5</a>
Uneven height	3	<a href="#">P.42A-5</a>

## SYMPTOM PROCEDURES

### INSPECTION PROCEDURE 1: Difficult Locking and Unlocking

#### DIAGNOSIS

**STEP 1. Check that the release cable is routed correctly.**

**Q: Is the release cable routed correctly?**

**YES :** Go to Step 2.

**NO :** Re-route the release cable. Then go to Step 4.

**STEP 2. Check the engagement of the hood latch and hood striker.**

**Q: Are the hood latch and hood striker engaged correctly?**

**YES :** Go to Step 3.

**NO :** Adjust the hood latch (Refer to [P.42A-5](#)). Then go to Step 4.

**STEP 3. Check for proper lubrication of release cable.**

**Q: Is the release cable properly lubricated?**

**YES :** Go to Step 4.

**NO :** Lubricate, then go to Step 4.

**STEP 4. Retest the system.**

**Q: Does the hood lock operate easily?**

**YES :** The procedure is complete.

**NO :** Return to Step 1.

**INSPECTION PROCEDURE 2: Uneven Body Clearance**

**DIAGNOSIS**

**STEP 1. Check the clearance around the hood.**

**Q: Is the clearance around the hood even?**

**YES :** Go to Step 2.

**NO :** Adjust the hood (Refer to [P.42A-5](#)). Then go to Step 2.

**STEP 2. Retest the system.**

**Q: Are the clearances between body panels even?**

**YES :** The procedure is complete.

**NO :** Return to Step 1.

**INSPECTION PROCEDURE 3: Uneven Height**

**DIAGNOSIS**

**STEP 1. Check the hood damper height.**

**Q: Is the hood damper height proper?**

**YES :** Go to Step 2.

**NO :** Adjust the hood damper (Refer to [P.42A-6](#)). Then go to Step 2.

**STEP 2. Retest the system.**

**Q: Are the hood and body height even?**

**YES :** The procedure is complete.


**NO :** Return to Step 1.

**ON-VEHICLE SERVICE**

**ADJUSTMENT OF CLEARANCE AROUND HOOD**

M1421007200464


1. Loosen the hood hinge mounting bolts but do not remove them. Move the hood hinge back/forth and left/right to align the hood level.
2. After the adjustment, tighten the hood hinge mounting bolts to  $12 \pm 2$  N·m ( $102 \pm 22$  in-lb).




**ALIGNMENT OF HOOD LATCH AND STRIKER**

M1421008500048

1. Remove the headlight support panel cover (Refer to GROUP 51, Front Bumper Assembly and Radiator Grille [P.51-3](#)).



2. Loosen the hood latch mounting bolts but do not remove them. Move the hood latch up/down and left/right to align the hood level and adjust the hood striker engagement.
3. After the adjustment, tighten the hood latch mounting bolts to  $9.0 \pm 1.0$  N·m ( $80 \pm 9$  in-lb).
4. Install the headlight support panel cover. (Refer to GROUP 51, Front Bumper Assembly and Radiator Grille P.51-3.)



### ADJUSTMENT OF HOOD HEIGHT

M1421007400479

Turn the damper to the dimension shown in the figure to adjust the hood height. If the hood height is still not even, turn the damper again until the height is even. The damper height is altered by roughly 4 mm (0.16 inch) when the damper is rotated one full turn.

*NOTE: If a rattling noise is heard due to the vibration of the hood when the vehicle is being driven, adjust the damper height until the damper is seated on the hood.*




HOOD

HOOD REMOVAL AND INSTALLATION

M1421001601445

Post-installation operation

- Adjustment of clearance around hood (Refer to P.42A-5).
- Adjustment of the hood level and hood striker engagement (Refer to P.42A-5).
- Adjustment of hood height (Refer to P.42A-6).



AC708681AB

**Hood removal steps**

1. Windshield washer hose connection
2. Hood assembly
3. Shim
4. Hood hinge
5. Hood support rod
6. Hood damper

**Hood latch and hood lock release cable removal steps**

- Headlight support panel cover (Refer to GROUP 51, Front Bumper Assembly and Radiator Grille P.51-3.)
- 7. Hood latch

**Hood latch and hood lock release cable removal steps (Continued)**

- Cowl side trim (driver's side) (Refer to GROUP 52A, Interior Trim P.52A-12.)
- Instrument panel cover lower <MR> (Refer to GROUP 52A, Instrument Lower Panel Assembly P.52A-9.)
- 8. Hood lock release handle
- Front splash shield (Refer to P.42A-12.)

- 9. Hood lock release cable


**Damper removal**

- 10. Damper

INSPECTION

M1421001700579


HOOD LATCH SWITCH CONTINUITY CHECK




Claw position	Terminal number	Normal value
Unlock (ON)	1 -2	Continuity exists (2 Ω or less)
Lock (OFF)	1 -2	Open circuit


DISASSEMBLY AND ASSEMBLY

M1421010200163





←: Clip A positions      ↩: Clip B positions



AC808367AB

**Disassembly steps**

1. Hood insulator A
2. Hood insulator B
3. Hood weatherstrip side A
4. Hood weatherstrip
5. Hood weatherstrip B <LH>

<<A>>

<<B>>


**Disassembly steps (Continued)**

6. Windshield washer nozzle assembly
7. Hood air outlet garnish
8. Hood air inlet garnish
9. Damper
10. Hood

**REMOVAL SERVICE POINTS**


**<<A>> HOOD AIR OUTLET GARNISH REMOVAL**

Using 6 mm (0.2 in) socket wrench, push out the hood air outlet garnish assembling clips.



**<<B>> HOOD AIR INLET GARNISH REMOVAL**

Using 6 mm (0.2 in) socket wrench, push out the hood air inlet garnish assembling clips.




# FENDER

## REMOVAL AND INSTALLATION


M1421001901491

**Pre-removal and post-installation operation**


- Front splash shield removal and installation (Refer to P.42A-12.)
- Side air dam removal and installation (Refer to GROUP 51, Side Air Dam P.51-13.)
- Front bumper bracket removal and installation (Refer to GROUP 51, Front Bumper Assembly and Radiator Grille P.51-3.)
- Front delta garnish removal and installation (Refer to GROUP 51, Garnish and Molding P.51-7.)
- Front deck garnish removal and installation (Refer to GROUP 51, Windshield Wiper P.51-74.)
- Headlight assembly removal and installation (Refer to GROUP 54A, Headlight P.54A-202.)
- Side turn signal light removal and installation (Refer to GROUP 54A, Side Turn Signal Light P.54A-258.)




Section B - B



Section C - C



Section D - D



AC900040AC

**Removal steps**

- <<A>> >>A<< 1. Fender  
2. Fender protector rear


**Removal steps (Continued)**

3. Front fender bracket  
4. Front fender garnish

**REMOVAL SERVICE POINT**

**<<A>> FENDER REMOVAL**


1. Remove the fender protector rear assembling clip.
2. Slide the fender protector rear, then remove the fender mounting bolt shown in the illustration.



**INSTALLATION SERVICE POINT**

**>>A<< FENDER INSTALLATION**


1. Temporarily install the fender protector rear to the fender.
2. Install the fender to the body. (Do not install the fender mounting bolt shown in the illustration at this time.)
3. Slide the temporarily-installed fender protector rear, and then install the fender mounting bolt.



# SPLASH SHIELD

## REMOVAL AND INSTALLATION

M1421009700227




Note  
 : Clip positions

### Front splash shield removal

1. Front splash shield

View A



AC710602AB


### Rear splash shield removal steps

2. Rear wheel splash shield front <MR>
3. Rear wheel splash shield rear

# FUEL FILLER LID

## REMOVAL AND INSTALLATION

M1421002500921



AC708682AB

### Fuel filler lid removal steps


1. Fuel filler lid
  2. Fuel filler lid damper spring
- ### Fuel filler lid lock release cable removal steps
- Front scuff plate <Driver's side> (Refer to GROUP 52A, Interior Trim [P.52A-12.](#))
  - 3. Fuel filler lid lock release handle
    - Trunk side trim <LH> (Refer to GROUP 52A, Interior Trim [P.52A-12.](#))
  - 4. Fuel filler lid hook

### Fuel filler lid lock release cable removal steps (Continued)

- Center pillar trim lower (Refer to GROUP 52A, Interior Trim [P.52A-12.](#))
- Front seat assembly (Refer to GROUP 52A, Front Seat Assembly [P.52A-21.](#))
- Rear seat cushion assembly, Rear seatback assembly (Refer to GROUP 52A, Rear Seat Assembly [P.52A-27.](#))
- 5. Fuel filler lid lock release cable

**STRUT TOWER BAR****REMOVAL AND INSTALLATION**

M1421005600314



AC705425AE

**Removal**

1. Strut tower bar

## WINDOW GLASS

### SPECIFICATION(S)

#### ADHESIVES

M1421000500356

Item	Specified adhesive
Windshield	3 M™ AAD part No. 8609 super fast urethane and 3 M™ AAD part No. 8608 super fast urethane primer or equivalent
Rear window glass	

Item	Specified adhesive
Windshield	Adhesive tape: Double-sided tape [6.5 mm (0.25 in) width, 100 mm (3.93 in) length and 0.4 mm (0.015 in) thickness]

#### GENERAL

M1422000101008

The windshield, rear window glass are attached by an urethane-base adhesive to the window frame. This adhesive provides improved glass holding and sealing, and also gives body openings a greater structural strength.


#### ITEMS

Item	Application	Quantity
Wire (diameter × length)	For cutting adhesive	Five pieces of wire 0.6 mm × 1 m (0.02 in × 3.3 ft)
Glass adhesive knife	For cutting adhesive	One
Sealant gun	For adhesive application	One
Wiping shop towels	–	As required
Sealer	For prevention of water and wind leaks after adhesive application	As required
3M™ AAD Part No. 8906 or equivalent	For cleaning or degreasing body parts and glasses	As required
Glass holder MB990480	For securing of window glass	Two

WINDOW GLASS INSTALLATION

**⚠ CAUTION**

Do not apply primer on the adhesion surface, as adhesion may be reduced.



## WINDOW GLASS DIAGNOSIS

### INTRODUCTION TO WINDOW GLASS DIAGNOSIS

M1421005800437

If water emerges from the following points, there is a problem in the seal or body flange.

- Windshield
- Rear window glass

### WINDOW GLASS DIAGNOSTIC TROUBLESHOOTING STRATEGY

M1422006800295

Use these steps to plan your diagnostic strategy. If you follow them carefully, you will be sure that you have exhausted most of the possible ways to find a window glass fault.

1. Gather information from the customer.

2. Verify that the condition described by the customer exists.
3. Find the malfunction by following the Symptom Chart.
4. Verify malfunction is eliminated.

### WINDOW GLASS DIAGNOSTIC TROUBLE SYMPTOM CHART

M1422006900377

Symptom	Inspection procedure	Reference page
Water leak through windshield	1	<a href="#">P.42A-17</a>
Water leak through rear window glass		

## SYMPTOM PROCEDURES

### INSPECTION PROCEDURE 1: Water Leak Through Windshield/Rear Window Glass

#### DIAGNOSIS

**STEP 1. Check if the seal is faulty.**

**Q: Is the seal faulty?**

- YES :** Repair the seal, then go to Step 3.  
**NO :** Go to Step 2.

**STEP 2. Check if the body flange is deformed.**

**Q: Is the body flange deformed?**

- YES :** Replay the body flange, then go to Step 3.  
**NO :** Go to Step 3.


**STEP 3. Retest the system.**

**Q: Is any water leaking?**

- YES :** Return to Step 1.  
**NO :** This diagnosis complete.

#### SPECIAL TOOL

M142200600583

Tool	Tool number and name	Supersession	Application
 MB990480	MB990480 Glass holder	General service tool	Removal and installation of window glass



WINDSHIELD

REMOVAL AND INSTALLATION


M1422001001071

**Pre-removal and Post-installation Operation**

- Front Deck Garnish Removal and Installation (Refer to GROUP 51, Windshield Wiper P.51-74).
- Front Pillar Trim Removal and Installation (Refer to GROUP 52A, Interior Trims P.52A-12).
- Inside Rear View Mirror Removal and Installation (Refer to GROUP 52A, Inside Rear View Mirror P.52A-20).
- Lighting control sensor Removal and Installation <Vehicles with automatic light> (Refer to GROUP 54A, Headlight P.54A-206).



AC609364AB



AC609366AB

**REMOVAL STEPS**

- <<A>> >>B<< 1. Windshield  
>>A<< 2. Windshield molding  
>>A<< 3. Glass stopper  
>>A<< 4. Front deck garnish retainer

**REMOVAL STEPS (Continued)**

- >>A<< 5. Windshield spacer A  
>>A<< 6. Windshield spacer B

**Required Special Tool:**

- MB990480: Glass Holder

**REMOVAL SERVICE POINT**


**<<A>> WINDSHIELD REMOVAL**





1. To protect the body (paint surface), apply cloth tape to all body areas around the installed windshield.
2. Make mating marks on the windshield and body.
3. Using piano wire.
  - (1) Using a sharp-point drill, make a hole in the windshield adhesive.
  - (2) Pass the piano wire from the inside of the vehicle through the hole.

**⚠ CAUTION**

**Do not let the piano wire touch the edge of the windshield.**

- (3) Pull the piano wire alternately from the inside and outside along the windshield to cut the adhesive.





**⚠ CAUTION**

Inserting the glass adhesive knife too deeply into windshield adhesive may damage windshield.

4. Using glass adhesive knife

Keep glass adhesive knife at right angles with the windshield edge, and put the blade at windshield edge and surface. Then cut away adhesive along the windshield edge.

5. Use special tool MB990480 to remove the windshield.

**⚠ CAUTION**

- Be careful not to remove more adhesive than is necessary.
- Be careful also not to damage the paint on the body surface with the knife. If the paint is damaged, repair the damaged area with touch-up paint.

6. Use a knife to cut away the remaining adhesive so that the thickness is within 2 mm (0.08 inch) around the entire circumference of the body flange.

7. Finish the flange surfaces so that they are smooth.

**⚠ CAUTION**

Allow the cleaned area to dry for at least three minutes. Do not touch any surface that has been cleaned.

8. When reusing the windshield, remove the adhesive still adhering to the windshield, and clean with 3M™ AAD Part number 8906 or equivalent.

9. Clean the body side in the same way.

INSTALLATION SERVICE POINTS

>>A<< WINDSHIELD SPACER/GLASS STOP-  
PER/WINDSHIELD UPPER MOLDING/WIND-  
SHIELD SIDE MOLDING INSTALLATION


**⚠ CAUTION**

Leave the degreased parts for 3 or more minutes to dry well, before starting on the next step. Do not touch the degreased parts.

1. Use 3M™ AAD Part number 8906 or equivalent to degrease the inside and outside of the windshield and the body flanges.

Windshield spacer and glass stopper installation position

Unit: mm (in)




AC609365AC

2. Install the windshield spacer and glass stoppers to the specified positions so that there are no adrift or warped surfaces inside the windshield.

Adhesive tape installation position

Unit: mm (in)



AC608860AB


3. Install the adhesive tape to the windshield.
4. Install the windshield molding and front deck garnish retainer to the windshield.


>>B<<WINDSHIELD INSTALLATION

1. When replacing the windshield, temporarily set the windshield against the body, and place a mating mark on the windshield and body.

**CAUTION**

- The primer strengthens the adhesive, so be sure to apply it evenly around the entire circumference. However, a too thick application will weaken the adhesive.
  - Do not touch the coated surface.
  - Do not apply the primer on the remaining adhesive because of weakening the adhesive.
2. Soak a sponge in the primer, and apply evenly to the windshield and the body in the specified places.
  3. Allow the windshield to dry for at least three minutes after applying primer.





4. Fill a sealant gun with adhesive. Then apply the adhesive evenly around the windshield within 30 minutes after applying the primer.  
*NOTE: Cut the tip of the sealant gun nozzle into a V shape to simplify adhesive application.*
5. Align the mating marks on the windshield and the body, and lightly press the windshield evenly so that it adheres completely.
6. Use a spatula or similar tool to remove any excessive adhesive. Clean the surface with 3M™ AAD Part number 8906 or equivalent. Avoid moving the vehicle until the adhesive sets.

**⚠ CAUTION**


- Do not move the vehicle unless absolutely necessary.
  - When testing for water leakage, do not apply strong water pressure.
7. Wait 30 minutes or more, and then test for water leakage.

**REAR WINDOW GLASS  
REMOVAL AND INSTALLATION**


M1422001600412

**Pre-removal and Post-installation Operation**

- Rear Pillar Trim and Rear Shelf Trim Removal and Installation (Refer to GROUP 52A, Trims [P.52A-12](#)).



AC705066AC



AC613173AB

**REMOVAL STEPS**

- Harness connector
- <<A>> >>B<< 1. Rear window glass
- >>A<< 2. Rear window side dam

**REMOVAL STEPS (Continued)**

- >>A<< 3. Rear window upper dam
- >>A<< 4. Glass stopper
- >>A<< 5. Rear window spacer
- >>A<< 6. Fastener

**REMOVAL SERVICE POINT**

**<<A>> REAR WINDOW GLASS REMOVAL**

Remove the rear window glass using the same procedure as for the windshield (Refer to P.42A-18).

*NOTE: Use a piano wire to remove the rear window glass.*


INSTALLATION SERVICE POINTS

>>A<< FASTENER/REAR WINDOW  
SPACER/GLASS STOPPER/REAR WINDOW  
UPPER DAM/REAR WINDOW SIDE DAM INSTAL-  
LATION


**⚠ CAUTION**

Leave the degreased parts for 3 or more minutes to dry well, before starting on the next step. Do not touch the degreased parts.


1. Use 3M™ AAD Part number 8906 or equivalent. to degrease the inside and outside edges of the rear window glass and the surface of the body flange.



2. Install the fastener, rear window spacers, and glass stoppers to the specified positions so that there are no adrift or warped surfaces inside the rear window glass.



3. Install the fasteners to the specified positions on the body flange.



AC609640AB

4. Install the rear window upper dam and side dam to the rear window glass.

**>>B<< REAR WINDOW GLASS INSTALLATION**

1. Apply the primer and adhesive.
2. Install the rear window glass in the same way as for the windshield glass installation (Refer to [P.42A-18](#)).

# DOOR

## SPECIFICATION(S)

### SERVICE SPECIFICATIONS

M1421000300761

Item	Standard value
Door inside handle lock knob stroke mm (in) [Target value: mm (in)]	13.7 –15.0 (0.54 –0.59) [14.7 (0.58)]
Door inside handle play mm (in) [Target value: mm (in)]	Driver's side
	Except for driver's side
Door outside handle play mm (in) [Target value: mm (in)]	10.0 –23.7 (0.39 –0.93) [17.0 (0.67)]
Door outside handle play mm (in) [Target value: mm (in)]	5.0 –18.7 (0.2 –0.74) [12.0 (0.47)]
Door outside handle play mm (in) [Target value: mm (in)]	0.3 –5.0 (0.01 –0.2) [2.4 (0.09)]
Power window operation current A	7 ± 1 [Power supply voltage 14.5 ± 0.5V at 25° C (77° F)]

### SEALANT

M1421000500367

Item	Specified sealant	Remark
Waterproof film	3 M™AAD Part No. 8633 or equivalent	Ribbon sealer

### LUBRICANT

M1421000400036

Item	Specified lubricant	Quantity
Degrease agent	Grease and dirt removal from parts surface	3M™ AAD Part No. 8906 or equivalent
		As required

## COMPONENT IDENTIFICATIONS

M1421005400321

### <DOOR CHECK>

Applicable location	Identification mark
Front door	Left door
	Right door
Rear door	Left door
	Right door

### <DOOR OPENING OUTER WEATHERSTRIP>

Applicable side	Identification clip color
Left door	Yellow
Right door	Purple

## GENERAL INFORMATION

M1423000100473

### OPERATION

#### CENTRAL DOOR LOCKING SYSTEM


The central door locking system operates the door lock actuator to lock or unlock the doors using the operation of the door lock switch built into the front power window (main or sub) switch. The system has the following operations and features.

- All doors can be locked using the door lock switch built into the front power window (main or sub <RH>) switch.

#### CENTRAL DOOR LOCKING

- All the doors can be locked/unlocked, using the driver's side door lock switch or the passenger's side door lock switch.

- The function that allows the driver's door to be opened by pulling the driver's door inside handle even when the driver's door inside lock knob is in the lock position is called "override function".




When the door is locked by the driver's or passenger's door lock switch, the ETACS-ECU operates its door lock relay and passes a current through the door lock actuators of all the doors for 0.25 second to lock all the doors.

When the door is unlocked by the driver's or passenger's door lock switch, the ETACS-ECU operates its door unlock relay and passes a current through the door lock actuators of all the doors for 0.25 second to unlock all the doors.

When the door is locked and unlocked by driver's or passenger's door lock switch consecutively, the ETACS-ECU operates its door lock relay and passes a current through the door lock actuators of all the doors for 0.25 second to lock all the doors. Then, the ETACS-ECU operates its door unlock relay and passes a current through the door lock actuators of all the doors for 0.25 second to unlock all the doors. Due to this, there may be a time lag between the driver's or passenger's door lock switch actuation and the time when all the doors are unlocked.

**SELECTOR "P" POSITION-LINKED DOOR UNLOCKING FUNCTION <TC-SST>**


- When the selector lever is shifted to the "P" (parking) position with the ignition switch turned ON, all the doors will be unlocked automatically, improving passengers' convenience for getting out. Using a customization feature, the selector "P" position-linked door unlocking function can be switched (Refer to P.42A-127).



When the selector lever is shifted to the P position with the ignition switch turned ON, the lever position sensor "P" turns ON, ETACS-ECU turns the unlock relay output ON for 0.25 second to unlock all the doors.

**IGNITION SWITCH "LOCK (OFF)" POSITION-LINKED DOOR UNLOCKING FUNCTION <M/T, TC-SST>**

- When the ignition switch is turned to the " LOCK (OFF)" position, all the doors will be unlocked automatically, improving passengers' convenience for getting out. Using a customization function, the ignition switch " LOCK (OFF)" position-linked door unlocking function can be changed (Refer to P.42A-127).



When the ignition switch is turned to the " LOCK (OFF)" position, ETACS-ECU turns the unlock relay output ON for 0.25 second to unlock all the doors.

## POWER WINDOWS

When the power window (main or sub) switch is operated, the door windows will open or close. This system has the following operations and features.


- There is a power window lock switch featured on the power window main switch to prevent the door window glass from opening/closing with the front passenger's and rear power window sub switch.
- The power window of the door window glass can be opened/closed for 30 seconds with the timer function after the ignition switch is turned OFF (The timer expires if the front door <LH or RH> is opened when the timer is in operation).
- The power window main switch contains a one-touch down/up switch that will automatically open/close driver's side door window only.

## SAFETY MECHANISM (DRIVER'S DOOR ONLY)

- The power window with the safety mechanism has been adopted to enhance safety. If any obstacle such as a hand or a head is detected to be pinched during a door window glass closing operation, the door window glass is opened by approximately 150 mm (6.0 inches). The safety mechanism is activated when the power window switch is operated by one-touch closing operation (the status when the hand is released from the switch knob after one-touch closing operation).

- To prevent anyone from intruding into the vehicle, by performing the manual-closing operation of the power window switch, or by continuing the one-touch closing operation (keep pulling up the switch knob), the door window glass can be forcibly closed without safety mechanism activation even when the obstacle is detected to be pinched.
- When the power window switch manual-closing or one-touch closing operation is performed accidentally, and an obstacle is detected, the power window switch manual-closing and one-touch closing operations are prohibited for 3 seconds after the obstacle has been detected to be pinched, and activates the safety mechanism.

## POWER WINDOW TIMER FUNCTION



Even after the ignition is switched off, the ETACS-ECU keeps the power window relay activated for approximately 30 seconds, enabling raising or lowering of the power windows by using the power window switches. After approximately 30 seconds, the power window relay is deactivated. During this timed operation, if the driver's or passenger's doors are opened, the power window relay is deactivated from that moment.

**CENTRAL DOOR LOCKING SYSTEM  
DIAGNOSIS****TROUBLESHOOTING STRATEGY**

M1427002100073

Refer to GROUP 00 –How to Use Troubleshooting/Inspection Service Points, Contents of Troubleshooting [P.00-7](#).**TROUBLE SYMPTOM CHART**

M1427001800831

**⚠ CAUTION**

During diagnosis, a diagnostic trouble code associated with other system may be set when the ignition switch is turned on with connector(s) disconnected. On completion, check all systems for diagnostic trouble code(s). If diagnostic trouble code(s) are set, erase them all.

Trouble symptom	Inspection procedure number	Reference page
Central door locking system does not work at all.	1	<a href="#">P.42A-31</a>
Central door locking system does not operate even when door lock switch of power window main switch operated (door lock switch of front power window sub switch operate normally).	2	<a href="#">P.42A-38</a>
Central door locking system does not operate even when door lock switch of front power window sub switch operated (door lock switch of power window main switch operate normally).	3	<a href="#">P.42A-43</a>
A door cannot be locked or unlocked by the central door locking system.	4	<a href="#">P.42A-47</a>
Selector "P" Position-linked Door Unlock Function does not Operate Normally. <TC-SST>	5	<a href="#">P.42A-58</a>
Ignition "LOCK (OFF)" position-linked door unlock function does not operate. <M/T, TC-SST>	6	<a href="#">P.42A-58</a>


**SYMPTOM PROCEDURES <CENTRAL DOOR LOCKING SYSTEM>**

**INSPECTION PROCEDURE 1: Central Door Locking System does not work at All.**


**CAUTION**

Before replacing the ECU, ensure that the power supply circuit, the ground circuit and the communication circuit are normal.

Central Door Locking System Power Supply Circuit




Connectors: C-24, C-116




AC708951AF

Connector: E-08




AC608168AI

Connectors: C-101, C-103, C-129




AC708950AK

Connector: E-15



AC608167AM

Connectors: C-301, C-315  
ETACS-ECU

AC708972AK

## CIRCUIT OPERATION

- The ETACS-ECU controls the central door lock system, locking or unlocking all the doors by activating the central door lock relay (built into the ETACS-ECU). The ETACS-ECU uses inputs from the following components:
  - Door lock actuator
  - Door lock switch, which is incorporated in the power window main switch or power window sub switch

## TROUBLESHOOTING HINTS

- The wiring harness or connectors may have loose, corroded, or damaged terminals, or terminals pushed back in the connector
- The ETACS-ECU may be defective

## DIAGNOSTIC PROCEDURE

### Required Special Tools:

- MB992006: Extra fine probe
- MB991223: Harness set
- MB991958 Scan Tool (M.U.T.-III Sub Assembly)
  - MB991824: Vehicles Communication Interface (V.C.I.)
  - MB991827 M.U.T.-III USB Cable
  - MB991910 M.U.T.-III Main Harness A

**STEP 1. Checking keyless entry system operation**

Check that the keyless entry system works normally.

**Q: Is the check result normal?**

**YES** : Go to Step 2.

**NO <Vehicles with KOS>** : Refer to GROUP 42B, Inspection procedure 14 "Keyless entry system does not work at all [P.42B-204](#)."

**NO <Vehicles with WCM>** : Refer to GROUP 42C, Inspection procedure 5 "Keyless entry system does not work at all [P.42C-100](#)."

**STEP 2. Using scan tool MB991958, read the diagnostic trouble code.**

**⚠ CAUTION**


To prevent damage to scan tool MB991958, always turn the ignition switch to the "LOCK" (OFF) position before connecting or disconnecting scan tool MB991958.


- (1) Connect scan tool MB991958. Refer to "How to connect scan tool (M.U.T.-III) [P.42B-9](#)."
- (2) Turn the ignition switch to the "ON" position.
- (3) Check whether the ETACS-ECU related DTC is set.
- (4) Turn the ignition switch to the "LOCK" (OFF) position.

**Q: Is the DTC set?**

**YES** : Diagnose the ETACS-ECU. Refer to GROUP 54A, Diagnostic trouble code chart [P.54A-646](#).

**NO** : Go to Step 3.





**STEP 3. Using scan tool MB991958, check data list.**

Check the signals related to the central door locking system operation.

**⚠ CAUTION**

To prevent damage to scan tool MB991958, always turn the ignition switch to the "LOCK" (OFF) position before connecting or disconnecting scan tool MB991958.

- (1) Connect scan tool MB991958. Refer to "How to connect the Scan Tool (M.U.T.-III) P.42B-9."
- (2) Turn the ignition switch to the "ON" position.
- (3) Check the data list of the ETACS.
  - Turn the door lock switch (power window main switch or front power window sub switch) to the lock direction.

Item No.	Item name	Normal condition
271	Dr door unlock switch	Not unlock
277	Power lock switch	ON
278	Power unlock switch	OFF

- Turn the door lock switch (power window main switch or front power window sub switch) to the unlock direction.

Item No.	Item name	Normal condition
271	Dr door unlock switch	Unlock
277	Power lock switch	OFF
278	Power unlock switch	ON

- (4) Turn the ignition switch to the "LOCK" (OFF) position.

**OK: Normal conditions are displayed for all items.**

**Q: Are the check results normal?**

**Normal conditions are displayed for all the items. :** Go to Step 14.

**Normal condition is not displayed for item No. 271. :**  
Refer to GROUP 54A –Inspection procedure 4 "The front door lock actuator (driver's side) signal is not received P.54A-712."

**Normal condition is not displayed for item No. 277, 278. :**  
Go to Step 4.

**STEP 4. Check power window main switch connector E-15 for loose, corroded or damaged terminals, or terminals pushed back in the connector.**


**Q: Is power window main switch connector E-15 in good condition?**

**YES :** Go to Step 5.

**NO :** Repair or check the connector. Refer to GROUP 00E, Harness Connector Inspection [P.00E-2](#). Verify that all the doors can be locked and unlocked normally.

**STEP 5. Check the power window main switch (door lock switch).**

Remove the power window main switch. Refer to [P.42A-131](#).



Switch position	Tester connection	Specified condition
LOCK	14 -Ground	Continuity exists (2 Ω or less)
UNLOCK	13 -Ground	Continuity exists (2 Ω or less)

**Q: Does the power window main switch work normally?**

**YES :** Go to Step 6.

**NO :** Replace the power window main switch. Verify that all the doors can be locked and unlocked normally.

**STEP 6. Check ETACS-ECU connector C-301 and C-315 for loose, corroded or damaged terminals, or terminals pushed back in the connector.**

**Q: Are ETACS-ECU connector C-301 and C-315 in good condition?**

**YES :** Go to Step 7.

**NO :** Repair or replace the damaged component(s). Refer to GROUP 00E, Harness Connector Inspection [P.00E-2](#). Check that the sunroof works normally.

**STEP 7. Check the wiring harness between power window main switch connector E-15 (terminals Nos. 13, 14) and ETACS-ECU connector C-315 (terminal No. 15), ETACS-ECU connector C-301 (terminal No. 2).**

*NOTE: Also check joint connector (1) C-101, joint connector (3) C-103, intermediate connector C-129 for loose, corroded, or damaged terminals, or terminals pushed back in the connector. If joint connector (1) C-101, joint connector (3) C-103, intermediate connector C-129 is damaged, repair or replace the damaged component(s) as described in GROUP 00E, Harness Connector Inspection P.00E-2.*

**Q: Are the wiring harness between power window main switch connector E-15 (terminals Nos. 13, 14) and ETACS-ECU connector C-315 (terminal No. 15), ETACS-ECU connector C-301 (terminal No. 2) in good condition?**

**YES :** Go to Step 8.

**NO :** The wiring harness may be damaged or the connector may have loose, corroded or damaged terminals, or terminals pushed back in the connector. Repair the wiring harness as necessary. Verify that the central door locking system works normally.

**STEP 8. Check front power window sub switch connector E-08 for loose, corroded or damaged terminals, or terminals pushed back in the connector.**


**Q: Is front power window sub switch connector E-08 in good condition?**

**YES :** Go to Step 9.

**NO :** Repair or check the connector. Refer to GROUP 00E, Harness Connector Inspection P.00E-2. Verify that all the doors can be locked and unlocked normally.

**STEP 9. Check the front power window sub switch (door lock switch).**

Remove the front power window sub switch. Refer to P.42A-131.




Switch position	Tester connection	Specified condition
LOCK	3 -4	Continuity exists (2 Ω or less)
UNLOCK	2 -4	Continuity exists (2 Ω or less)

**Q: Does the front power window sub switch work normally?**

**YES :** Go to Step 10.

**NO :** Replace the front power window sub switch. Verify that all the doors can be locked and unlocked normally.



**STEP 10. Check the ground circuit to the front power window sub switch. Measure the resistance at front power window sub switch connector E-08.**

- (1) Disconnect front power window sub switch connector E-08 and measure the resistance available at the wiring harness side of the connector.
- (2) Measure the resistance value between terminal 4 and ground.
  - The resistance should be 2 ohms or less.

**Q: Is the measured resistance 2 ohms or less?**

**YES :** Go to Step 12.

**NO :** Go to Step 11.

**STEP 11. Check the wiring harness between front power window sub switch connector E-08 (terminal No. 4) and ground.**

*NOTE: Also check intermediate connector C-116 for loose, corroded, or damaged terminals, or terminals pushed back in the connector. If intermediate connector C-116 is damaged, repair or replace the damaged component(s) as described in GROUP 00E, Harness Connector Inspection P.00E-2.*

**Q: Is the wiring harness between front power window sub switch connector E-08 (terminal No. 4) and ground in good condition?**

**YES :** No action is necessary and testing is complete.

**NO :** The wiring harness may be damaged or the connector(s) may have loose, corroded or damaged terminals, or terminals pushed back in the connector. Repair the wiring harness as necessary. Check that the sunroof works normally.

**STEP 12. Check ETACS-ECU connector C-301 and C-315 for loose, corroded or damaged terminals, or terminals pushed back in the connector.**

**Q: Are ETACS-ECU connector C-301 and C-315 in good condition?**

**YES :** Go to Step 13.

**NO :** Repair or replace the damaged component(s). Refer to GROUP 00E, Harness Connector Inspection P.00E-2. Check that the sunroof works normally.

---

**STEP 13. Check the wiring harness between power window sub switch connector E-08 (terminals Nos. 2, 3) and ETACS-ECU connector C-315 (terminal No. 15), ETACS-ECU connector C-301 (terminal No. 2).**

*NOTE: Also check joint connector (1) C-101, joint connector (3) C-103, intermediate connector C-24 for loose, corroded, or damaged terminals, or terminals pushed back in the connector. If joint connector (1) C-101, joint connector (3) C-103, intermediate connector C-24 is damaged, repair or replace the damaged component(s) as described in GROUP 00E, Harness Connector Inspection P.00E-2.*

**Q: Are the wiring harness between power window sub switch connector E-08 (terminals Nos. 2, 3) and ETACS-ECU connector C-315 (terminal No. 15), ETACS-ECU connector C-301 (terminal No. 2) in good condition?**

**YES :** Go to Step 14.

**NO :** The wiring harness may be damaged or the connector may have loose, corroded or damaged terminals, or terminals pushed back in the connector. Repair the wiring harness as necessary. Verify that the central door locking system works normally.

---

**STEP 14. Retest the system.**

Check that the central door locking system works normally.

**Q: Is the check result normal?**

**YES :** No action is necessary and testing is complete.

**NO :** Replace the ETACS-ECU. Check that the central door locking system normally.

---


**INSPECTION PROCEDURE 2: Central Door Locking System does not Operate even when Door Lock Switch of Power Window Main Switch Operated (Door Lock Switch of Front Power Window Sub Switch Operate Normally).**

---



 **CAUTION**

Before replacing the ECU, ensure that the power supply circuit, the ground circuit and the communication circuit are normal.

Central Door Locking System Power Supply Circuit



AC709019AB



## CIRCUIT OPERATION

- The ETACS-ECU controls the central door lock system, locking or unlocking all the doors by activating the central door lock relay (built into the ETACS-ECU). The ETACS-ECU uses inputs from the following components:
  - Door lock actuator
  - Door lock switch, which is incorporated in the power window main switch or power window sub switch

## TROUBLESHOOTING HINTS

- The wiring harness or connectors may have loose, corroded, or damaged terminals, or terminals pushed back in the connector
- The power window main switch may be defective

## DIAGNOSTIC PROCEDURE

### STEP 1. Checking central door locking system operation

Check that the central door locking system works normally.

#### Q: Is the check result normal?

**YES** : Go to Step 2.


**NO** : Refer to Inspection procedure 1 "Central door locking system does not work at all [P.42A-31](#)."

### STEP 2. Check power window main switch connector E-15 for loose, corroded or damaged terminals, or terminals pushed back in the connector.

#### Q: Is power window main switch connector E-15 in good condition?

**YES** : Go to Step 3.

**NO** : Repair or check the connector. Refer to GROUP 00E, Harness Connector Inspection [P.00E-2](#). Verify that all the doors can be locked and unlocked normally.



**STEP 3. Check the power window main switch (door lock switch).**

Remove the power window main switch. Refer to [P.42A-131](#).

Switch position	Tester connection	Specified condition
LOCK	14 -Ground	Continuity exists (2 Ω or less)
UNLOCK	13 -Ground	Continuity exists (2 Ω or less)

**Q: Does the power window main switch work normally?**

**YES :** Go to Step 4.

**NO :** Replace the power window main switch. Verify that all the doors can be locked and unlocked normally.

**STEP 4. Check joint connector (1) connector C-101, joint connector (3) connector C-103 for loose, corroded or damaged terminals, or terminals pushed back in the connector.**

**Q: Are joint connector (1) connector C-101, joint connector (3) connector C-103 in good condition?**

**YES :** Go to Step 5.

**NO :** Repair or replace the damaged component(s). Refer to GROUP 00E, Harness Connector Inspection [P.00E-2](#). Check that the sunroof works normally.

**STEP 5. Check the wiring harness between power window main switch connector E-15 (terminals Nos. 13, 14) and joint connector (3) connector C-103 (terminal No. 20), joint connector (1) connector C-101 (terminal No. 4).**

*NOTE: Also check intermediate connector C-129 for loose, corroded, or damaged terminals, or terminals pushed back in the connector. If intermediate connector C-129 is damaged, repair or replace the damaged component(s) as described in GROUP 00E, Harness Connector Inspection P.00E-2.*

**Q: Are the wiring harness between power window main switch connector E-15 (terminals Nos. 13, 14) and joint connector (3) connector C-103 (terminal No. 20), joint connector (1) connector C-101 (terminal No. 4) in good condition?**

**YES :** Go to Step 6.

**NO :** The wiring harness may be damaged or the connector may have loose, corroded or damaged terminals, or terminals pushed back in the connector. Repair the wiring harness as necessary. Verify that the central door locking system works normally.

---

**STEP 6. Retest the system.**

Check that the central door locking system works normally.


**Q: Is the check result normal?**




**YES :** No action is necessary and testing is complete.

**NO :** Replace the power window main switch. Check that the central door locking system normally.

**INSPECTION PROCEDURE 3: Central Door Locking System does not Operate even when Door Lock Switch of Front Power Window Sub Switch Operated (Door Lock Switch of Power Window Main Switch Operate Normally).**

Central Door Locking System Power Supply Circuit





## CIRCUIT OPERATION

- The ETACS-ECU controls the central door lock system, locking or unlocking all the doors by activating the central door lock relay (built into the ETACS-ECU). The ETACS-ECU uses inputs from the following components:
  - Door lock actuator
  - Door lock switch, which is incorporated in the power window main switch or power window sub switch

## TROUBLESHOOTING HINTS

- The wiring harness or connectors may have loose, corroded, or damaged terminals, or terminals pushed back in the connector
- The front power window sub switch may be defective

## DIAGNOSTIC PROCEDURE

### STEP 1. Checking central door locking system operation

Check that the central door locking system works normally.

**Q: Is the check result normal?**

**YES :** Go to Step 2.


**NO :** Refer to Inspection procedure 1 "Central door locking system does not work at all [P.42A-31](#)."

**STEP 2. Check front power window sub switch connector E-08 for loose, corroded or damaged terminals, or terminals pushed back in the connector.**

**Q: Is front power window sub switch connector E-08 in good condition?**

**YES :** Go to Step 3.

**NO :** Repair or check the connector. Refer to GROUP 00E, Harness Connector Inspection [P.00E-2](#). Verify that all the doors can be locked and unlocked normally.



**STEP 3. Check the front power window sub switch (door lock switch).**


Remove the front power window sub switch. Refer to P.42A-131.

Switch position	Tester connection	Specified condition
LOCK	3 –4	Continuity exists (2 Ω or less)
UNLOCK	2 –4	Continuity exists (2 Ω or less)

**Q: Does the front power window sub switch work normally?**

**YES :** Go to Step 4.

**NO :** Replace the front power window sub switch. Verify that all the doors can be locked and unlocked normally.



**STEP 4. Check the ground circuit to the front power window sub switch. Measure the resistance at front power window sub switch connector E-08.**

- (1) Disconnect front power window sub switch connector E-08 and measure the resistance available at the wiring harness side of the connector.
- (2) Measure the resistance value between terminal 4 and ground.
  - The resistance should be 2 ohms or less.

**Q: Is the measured resistance 2 ohms or less?**

**YES :** Go to Step 6.

**NO :** Go to Step 5.

**STEP 5. Check the wiring harness between front power window sub switch connector E-08 (terminal No. 4) and ground.**

*NOTE: Also check intermediate connector C-116 for loose, corroded, or damaged terminals, or terminals pushed back in the connector. If intermediate connector C-116 is damaged, repair or replace the damaged component(s) as described in GROUP 00E, Harness Connector Inspection P.00E-2.*

**Q: Is the wiring harness between front power window sub switch connector E-08 (terminal No. 4) and ground in good condition?**

**YES :** No action is necessary and testing is complete.

**NO :** The wiring harness may be damaged or the connector(s) may have loose, corroded or damaged terminals, or terminals pushed back in the connector. Repair the wiring harness as necessary. Check that the sunroof works normally.

**STEP 6. Check joint connector (1) connector C-101, joint connector (3) connector C-103 for loose, corroded or damaged terminals, or terminals pushed back in the connector.**

**Q: Are joint connector (1) connector C-101, joint connector (3) connector C-103 in good condition?**

**YES :** Go to Step 7.

**NO :** Repair or replace the damaged component(s). Refer to GROUP 00E, Harness Connector Inspection [P.00E-2](#). Check that the sunroof works normally.

---

**STEP 7. Check the wiring harness between front power window sub switch connector E-08 (terminals Nos. 2, 3) and joint connector (3) connector C-103 (terminal No. 19), joint connector (1) connector C-101 (terminal No. 3).**

*NOTE: Also check intermediate connector C-24 for loose, corroded, or damaged terminals, or terminals pushed back in the connector. If intermediate connector C-24 is damaged, repair or replace the damaged component(s) as described in GROUP 00E, Harness Connector Inspection [P.00E-2](#).*

**Q: Are the wiring harness between front power window sub switch connector E-08 (terminals Nos. 2, 3) and joint connector (3) connector C-103 (terminal No. 19), joint connector (1) connector C-101 (terminal No. 3) in good condition?**

**YES :** Go to Step 8.

**NO :** The wiring harness may be damaged or the connector may have loose, corroded or damaged terminals, or terminals pushed back in the connector. Repair the wiring harness as necessary. Verify that the central door locking system works normally.

---

**STEP 8. Retest the system.**

Check that the central door locking system works normally.


**Q: Is the check result normal?**

**YES :** No action is necessary and testing is complete.

**NO :** Replace the front power window sub switch. Check that the central door locking system normally.


**INSPECTION PROCEDURE 4: A Door cannot be Locked or Unlocked by The Central Door Locking System.**

Central Door Locking System Circuit <Front Door>










AC609750AD

Central Door Locking System Circuit<Rear Door>




AC609751AF





### CIRCUIT OPERATION

- The ETACS-ECU operates the central door lock system according to the following signals:
  - Door lock actuator switch
  - Door lock switch, which is incorporated in the power window main switch or power window sub switch
- The ETACS-ECU locks or unlocks all the doors by operating the central door lock relay (incorporated in the ECU) in response to input signals.




### TECHNICAL DESCRIPTION (COMMENT)

The wiring harness between the ETACS-ECU and the door lock actuator may be defective.

### TROUBLESHOOTING HINTS

- The door lock actuator may be defective
- The wiring harness or connectors may have loose, corroded, or damaged terminals, or terminals pushed back in the connector
- The ETACS-ECU may be defective



**DIAGNOSTIC PROCEDURE**

**STEP 1. Confirmation of the defective door lock actuator.**

**Q: Which door is not locked normally?**

- Driver's door :** Go to Step 2.
- Front passenger's door :** Go to Step 6.
- Rear right door :** Go to Step 10.
- Rear left door :** Go to Step 14.


**STEP 2. Check front door lock actuator (LH) connector E-16 for loose, corroded or damaged terminals, or terminals pushed back in the connector.**

**Q: Is front door lock actuator (LH) connector E-16 in good condition?**

- YES :** Go to Step 3.
- NO :** Repair or check the connector. Refer to GROUP 00E, Harness Connector Inspection [P.00E-2](#). Verify that all the doors can be locked and unlocked normally.

**STEP 3. Check the front door lock actuator (LH).**

Remove the front door lock actuator (LH). The illustration shows when the door lock actuator is viewed from inside the door. Refer to [P.42A-136](#).



Lever position	Battery connection	Lever operation
At the "LOCK" position	<ul style="list-style-type: none"> <li>• Connect terminal No.4 and the negative battery terminal.</li> <li>• Connect terminal No.6 and the positive battery terminal.</li> </ul>	The lever moves from the "LOCK" position to the "UNLOCK" position.
At the "UNLOCK" position	<ul style="list-style-type: none"> <li>• Connect terminal No.6 and the negative battery terminal.</li> <li>• Connect terminal No.4 and the positive battery terminal.</li> </ul>	The lever moves from the "UNLOCK" position to the "LOCK" position.

**Q: Does the front door lock actuator (LH) work normally?**

- YES :** Go to Step 4.
- NO :** Replace the front door lock actuator (LH). Verify that all the doors can be locked and unlocked normally.

---

**STEP 4. Check ETACS-ECU connector C-315 for loose, corroded or damaged terminals, or terminals pushed back in the connector.**

**Q: Is ETACS-ECU connector C-315 in good condition?**

**YES :** Go to Step 5.

**NO :** Repair or check the connector. Refer to GROUP 00E, Harness Connector Inspection [P.00E-2](#). Verify that all the doors can be locked and unlocked normally.

---

**STEP 5. Check the wiring harness between ETACS-ECU connector C-315 (terminals Nos. 2, 6) and front door lock actuator (LH) connector E-16 (terminals Nos. 6, 4).**

*NOTE: Also check joint connector (3) C-103, intermediate connector C-129 for loose, corroded, or damaged terminals, or terminals pushed back in the connector. If joint connector (3) C-103, intermediate connector C-129 is damaged, repair or replace the damaged component(s) as described in GROUP 00E, Harness Connector Inspection [P.00E-2](#).*

**Q: Is the wiring harness between ETACS-ECU connector C-315 (terminals Nos. 2, 6) and front door lock actuator (LH) connector E-16 (terminals Nos. 6, 4) in good condition?**

**YES :** Go to Step 18.

**NO :** The wiring harness may be damaged or the connector(s) may have loose, corroded or damaged terminals, or terminals pushed back in the connector. Repair or replace the damaged component(s). Verify that all the doors can be locked and unlocked normally.


---

**STEP 6. Check front door lock actuator (RH) connector E-07 for loose, corroded or damaged terminals, or terminals pushed back in the connector.**

**Q: Is front door lock actuator (RH) connector E-07 in good condition?**

**YES :** Go to Step 7.

**NO :** Repair or replace the damaged component(s). Refer to GROUP 00E, Harness Connector Inspection [P.00E-2](#). Verify that all the doors can be locked and unlocked normally.



**STEP 7. Check the front door lock actuator (RH).**

Remove the front door lock actuator (RH). The illustration shows when the door lock actuator is viewed from inside the door. Refer to [P.42A-136](#).

Lever position	Battery connection	Lever operation
At the "LOCK" position	<ul style="list-style-type: none"> <li>Connect terminal No.4 and the negative battery terminal.</li> <li>Connect terminal No.6 and the positive battery terminal.</li> </ul>	The lever moves from the "LOCK" position to the "UNLOCK" position.
At the "UNLOCK" position	<ul style="list-style-type: none"> <li>Connect terminal No.6 and the negative battery terminal.</li> <li>Connect terminal No.4 and the positive battery terminal.</li> </ul>	The lever moves from the "UNLOCK" position to the "LOCK" position.

**Q: Is the front door lock actuator (RH) normal?**

**YES :** Go to Step 8.

**NO :** Replace the front door lock actuator (RH). Verify that all the doors can be locked and unlocked normally.

**STEP 8. Check ETACS-ECU connector C-315 for loose, corroded or damaged terminals, or terminals pushed back in the connector.**

**Q: Is ETACS-ECU connector C-315 in good condition?**

**YES :** Go to Step 9.

**NO :** Repair or replace the damaged component(s). Refer to GROUP 00E, Harness Connector Inspection [P.00E-2](#). Verify that all the doors can be locked and unlocked normally.

---

**STEP 9. Check the wiring harness between ETACS-ECU connector C-315 (terminals Nos. 5, 6) and front door lock actuator (RH) connector E-07 (terminals Nos. 6, 4).**

*NOTE: Also check joint connector (3) C-103, intermediate connector C-24 for loose, corroded, or damaged terminals, or terminals pushed back in the connector. If joint connector (3) C-103, intermediate connector C-24 is damaged, repair or replace the damaged component(s) as described in GROUP 00E, Harness Connector Inspection [P.00E-2](#).*

**Q: Is the wiring harness between ETACS-ECU connector C-315 (terminals Nos. 5, 6) and front door lock actuator (RH) connector E-07 (terminals Nos. 6, 4) in good condition?**

**YES :** Go to Step 18.

**NO :** The wiring harness may be damaged or the connector(s) may have loose, corroded or damaged terminals, or terminals pushed back in the connector. Repair the wiring harness as necessary. Verify that all the doors can be locked and unlocked normally.


---

**STEP 10. Check rear door lock actuator (RH) connector E-19 for loose, corroded or damaged terminals, or terminals pushed back in the connector.**

**Q: Is rear door lock actuator (RH) connector E-19 in good condition?**

**YES :** Go to Step 11.

**NO :** Repair or check the connector. Refer to GROUP 00E, Harness Connector Inspection [P.00E-2](#). Verify that all the doors can be locked and unlocked normally.



**STEP 11. Check the rear door lock actuator (RH).**

Remove the rear door lock actuator (RH). The illustration shows when the door lock actuator is viewed from inside the door. Refer to [P.42A-136](#).

Lever position	Battery connection	Lever operation
At the "LOCK" position	<ul style="list-style-type: none"> <li>Connect terminal No.4 and the negative battery terminal.</li> <li>Connect terminal No.6 and the positive battery terminal.</li> </ul>	The lever moves from the "LOCK" position to the "UNLOCK" position.
At the "UNLOCK" position	<ul style="list-style-type: none"> <li>Connect terminal No.6 and the negative battery terminal.</li> <li>Connect terminal No.4 and the positive battery terminal.</li> </ul>	The lever moves from the "UNLOCK" position to the "LOCK" position.

**Q: Is the rear door lock actuator (RH) normal?**

**YES :** Go to Step 12.

**NO :** Replace the rear door lock actuator (RH). Verify that all the doors can be locked and unlocked normally.

**STEP 12. Check ETACS-ECU connector C-311 for loose, corroded or damaged terminals, or terminals pushed back in the connector.**

**Q: Is ETACS-ECU connector C-311 in good condition?**

**YES :** Go to Step 13.

**NO :** Repair or replace the damaged component(s). Refer to GROUP 00E, Harness Connector Inspection [P.00E-2](#). Verify that all the doors can be locked and unlocked normally.

---

**STEP 13. Check the wiring harness between ETACS-ECU connector C-311 (terminals Nos. 6, 9) and rear door lock actuator (RH) connector E-19 (terminals Nos. 6, 4).**

*NOTE: Also check joint connector (4) C-43, intermediate connector D-01 for loose, corroded, or damaged terminals, or terminals pushed back in the connector. If joint connector (4) C-43, intermediate connector D-01 is damaged, repair or replace the damaged component(s) as described in GROUP 00E, Harness Connector Inspection [P.00E-2](#).*

**Q: Is the wiring harness between ETACS-ECU connector C-311 (terminals No. 6, 9) and rear door lock actuator (RH) connector E-19 (terminals No. 6, 4) in good condition?**

**YES :** Go to Step 18.

**NO :** The wiring harness may be damaged or the connector(s) may have loose, corroded or damaged terminals, or terminals pushed back in the connector. Repair the wiring harness as necessary. Verify that all the doors can be locked and unlocked normally.


---

**STEP 14. Check rear door lock actuator (LH) connector E-26 for loose, corroded or damaged terminals, or terminals pushed back in the connector.**

**Q: Is rear door lock actuator (LH) connector E-26 in good condition?**

**YES :** Go to Step 15.

**NO :** Repair or check the connector. Refer to GROUP 00E, Harness Connector Inspection [P.00E-2](#). Verify that all the doors can be locked and unlocked normally.



**STEP 15. Check the rear door lock actuator (LH).**

Remove the rear door lock actuator (LH). The illustration shows when the door lock actuator is viewed from inside the door. Refer to [P.42A-136](#).

Lever position	Battery connection	Lever operation
At the "LOCK" position	<ul style="list-style-type: none"> <li>Connect terminal No.4 and the negative battery terminal.</li> <li>Connect terminal No.6 and the positive battery terminal.</li> </ul>	The lever moves from the "LOCK" position to the "UNLOCK" position.
At the "UNLOCK" position	<ul style="list-style-type: none"> <li>Connect terminal No.6 and the negative battery terminal.</li> <li>Connect terminal No.4 and the positive battery terminal.</li> </ul>	The lever moves from the "UNLOCK" position to the "LOCK" position.

**Q: Is the rear door lock actuator (LH) normal?**

**YES :** Go to Step 16.

**NO :** Replace the rear door lock actuator (LH). Verify that all the doors can be locked and unlocked normally.

**STEP 16. Check ETACS-ECU connector C-311 for loose, corroded or damaged terminals, or terminals pushed back in the connector.**

**Q: Is ETACS-ECU connector C-311 in good condition?**

**YES :** Go to Step 17.

**NO :** Repair or replace the damaged component(s). Refer to GROUP 00E, Harness Connector Inspection [P.00E-2](#). Verify that all the doors can be locked and unlocked normally.

---

**STEP 17. Check the wiring harness between ETACS-ECU connector C-311 (terminals Nos. 6, 9) and rear door lock actuator (LH) connector E-26 (terminals Nos. 6, 4).**

*NOTE: Also check joint connector (4) C-43, intermediate connector D-24 for loose, corroded, or damaged terminals, or terminals pushed back in the connector. If joint connector (4) C-43, intermediate connector D-24 is damaged, repair or replace the damaged component(s) as described in GROUP 00E, Harness Connector Inspection P.00E-2.*

**Q: Is the wiring harness between ETACS-ECU connector C-311 (terminals Nos. 6, 9) and rear door lock actuator (LH) connector E-26 (terminals Nos. 6 and 4) in good condition?**

**YES :** Go to Step 18.

**NO :** The wiring harness may be damaged or the connector(s) may have loose, corroded or damaged terminals, or terminals pushed back in the connector. Repair the wiring harness as necessary. Verify that all the doors can be locked and unlocked normally.

---

**STEP 18. Retest the system.**

Check that the central door locking system works normally.

**Q: Is the check result normal?**

**YES :** No action is necessary and testing is complete.

**NO :** Replace the ETACS-ECU. Check that the central door locking system normally.

---


**INSPECTION PROCEDURE 5: Selector "P" Position-linked Door Unlock Function does not Operate Normally. <TC-SST>**


---

 <b>CAUTION</b>
--

Whenever the ECU is replaced, ensure that the input and output signal circuits are normal.

Selector "P" Position-linked Door Unlock Function <TC-SST>



AC503706AK

### OPERATION

ETACS-ECU determines whether the shift position is at "P" or not according to the shift position signal which is sent by shift lever .

### TECHNICAL DESCRIPTION (COMMENT)

If the doors are not unlocked when the selector lever is shifted to the P position, a malfunction of the shift position signal input circuit(s) or ETACS-ECU is suspected. Also, the selector "P" position-linked door unlock function may have been "disabled" with the customization function.

### TROUBLESHOOTING HINTS

- Malfunction of shift lever
- Malfunction of ETACS-ECU
- Damaged wiring harness and connectors

### DIAGNOSTIC PROCEDURE

#### Required Special Tools:

- MB992006: Extra fine probe
- MB991223: Harness set
- MB991958: Scan Tool (M.U.T.-III Sub Assembly)
  - MB991824: Vehicles Communication Interface (V.C.I.)
  - MB991827: M.U.T.-III USB Cable
  - MB991910: M.U.T.-III Main Harness A

---

#### STEP 1. Checking central door locking system operation

Check that the central door locking system works normally.

#### Q: Is the check result normal?

**YES** : Go to Step 2.

**NO** : Refer to Inspection procedure 1 "Central door locking system does not work at all [P.42A-31.](#)"

**STEP 2. Check the customize function.**

Check that either of the followings other than "Disable" is set for "Auto door unlock by P position" with the customization function.

- Always enabled

**Q: Is the check result normal?**

**YES :** Go to Step 3.

**NO :** Set either of the followings other than "Disable" for "Auto door unlock by P position" with the customization function (Refer to [P.42A-127](#)).

**STEP 3. Using scan tool MB991958, read CAN bus the diagnostic trouble code.**

**⚠ CAUTION**


To prevent damage to scan tool MB991958, always turn the ignition switch to the "LOCK" (OFF) position before connecting or disconnecting scan tool MB991958.


- (1) Connect scan tool MB991958. Refer to "How to connect scan tool (M.U.T.-III) [P.42B-9](#)."
- (2) Turn the ignition switch to the "ON" position.
- (3) Check whether the CAN bus lines related DTC is set.
- (4) Turn the ignition switch to the "LOCK" (OFF) position.

**Q: Is the DTC set?**

**YES :** Repair the CAN bus line (Refer to GROUP 54C, CAN bus diagnostics table [P.54C-15](#)).

**NO :** Go to Step 4.





**STEP 4. Using scan tool MB991958, read the diagnostic trouble code.**

**⚠ CAUTION**

To prevent damage to scan tool MB991958, always turn the ignition switch to the "LOCK" (OFF) position before connecting or disconnecting scan tool MB991958.

- (1) Connect scan tool MB991958. Refer to "How to connect scan tool (M.U.T.-III) P.42B-9."
- (2) Turn the ignition switch to the "ON" position.
- (3) Check whether the shift lever related DTC is set.
- (4) Turn the ignition switch to the "LOCK" (OFF) position.

**Q: Is the DTC set?**

**YES** : Diagnose the shift lever. Refer to GROUP 22C, Diagnostic trouble code chart P.22C-15.

**NO** : Go to Step 5.

**STEP 5. Retest the system.**

Check that shifting the selector lever to the P position unlocks the doors.

**Q: Is the check result normal?**

**YES** : No action is necessary and testing is complete.

**NO** : Replace the ETACS-ECU. Check that the selector lever to the P position unlocks the doors normally.

---

**INSPECTION PROCEDURE 6: Ignition "LOCK (OFF)" Position-linked Door Unlock Function does not Operate. <M/T, TC-SST>**

---

**⚠ CAUTION**

Before replacing the ECU, ensure that the power supply circuit, the ground circuit and the communication circuit are normal.

**TECHNICAL DESCRIPTION (COMMENT)**

If a door is not unlocked when the ignition switch is turned to the LOCK position, a malfunction of the CAN bus line, ignition switch or ETACS-ECU is suspected. Also, the ignition "LOCK" position-linked door unlock function may have been "Disabled" with the customization function.

**TROUBLESHOOTING HINTS**

- Malfunction of CAN bus line
- Malfunction of ETACS-ECU
- Malfunction of ignition switch
- Damaged wiring harness and connectors

**DIAGNOSTIC PROCEDURE****Required Special Tools:**

- MB991223: Harness Set
- MB992006: Extra Fine Probe
- MB991958: Scan Tool (M.U.T.-III Sub Assembly)
  - MB991824: Vehicles Communication Interface (V.C.I.)
  - MB991827: M.U.T.-III USB Cable
  - MB991910: M.U.T.-III Main Harness A

---

**STEP 1. Checking central door unlocking operation**

Check that the central door locking system works normally.

**Q: Is the check result normal?**

**YES** : Go to Step 2.

**NO** : Refer to trouble symptom chart [P.42A-30](#).

---

**STEP 2. Check the customization function.**

Check that the following other than "Disabled" is set for "Auto door unlock by ignition LOCK position" with the customization function.

- Always (LOCK pos)

**Q: Is the check result normal?**

**YES** : Go to Step 3.

**NO** : Set the function as mentioned above other than "Disabled" for "Auto door unlock by ignition LOCK position" with the customization function (Refer to [P.42A-127](#)).

**STEP 3.** Using scan tool MB991958, check CAN bus for diagnostic trouble code.

**⚠ CAUTION**


To prevent damage to scan tool MB991958, always turn the ignition switch to the "LOCK" (OFF) position before connecting or disconnecting scan tool MB991958.

- (1) Connect scan tool MB991958. Refer to GROUP 42B, "How to connect scan tool (M.U.T.-III) [P.42B-9](#)."
- (2) Turn the ignition switch to the "ON" position.
- (3) Check whether CAN bus lines related DTC is set.
- (4) Turn the ignition switch to the "LOCK" (OFF) position.

**Q: Is the DTC set?**

**YES :** Repair the CAN bus line (Refer to GROUP 54C, CAN bus diagnostics table [P.54C-9](#)).

**NO :** Go to Step 4.



**STEP 4. Using scan tool MB991958, read the diagnostic trouble code.**


**⚠ CAUTION**

To prevent damage to scan tool MB991958, always turn the ignition switch to the "LOCK" (OFF) position before connecting or disconnecting scan tool MB991958.

- (1) Connect scan tool MB991958. Refer to GROUP 42B, "How to connect scan tool (M.U.T.-III) P.42B-9."
- (2) Turn the ignition switch to the "ON" position.
- (3) Check whether the ETACS-ECU related DTC is set.
- (4) Turn the ignition switch to the "LOCK" (OFF) position.

**Q: Is the DTC set?**

- YES** : Diagnose the ETACS-ECU. Refer to P.42A-158.  
**NO** : Go to Step 5.



**STEP 5. Check the ignition switch.**

Check that the ignition switch works normally.

**Q: Is the check result normal?**

- YES** : Go to Step 6.  
**NO** : Repair the ignition switch (Refer to GROUP 54A – Ignition Switch Troubleshooting/Inspection Procedure 2 - Defective power supply system of the ignition switch P.54A-20).

**STEP 6. Retest the system.**

Check that turning the ignition switch to the "LOCK" position unlocks the doors.

**Q: Is the check result normal?**

- YES** : No action is necessary and testing is complete.  
**NO** : Replace the ETACS-ECU.

## POWER WINDOW DIAGNOSIS

## TROUBLESHOOTING STRATEGY

M1429002700220

Refer to GROUP 00 –How to Use Troubleshooting/Inspection Service Points, Contents of Troubleshooting P.00-7.

## DIAGNOSTIC TROUBLE CODE CHART

M1429006000096

**⚠ CAUTION**

On troubleshooting, if the ignition switch is turned ON while disconnecting connector(s), diagnostic trouble code(s) associated with other system may be set. On completion, check all systems for diagnostic trouble code(s). If diagnostic trouble code(s) are set, erase them all.

Diagnostic trouble code No.	Diagnostic item	Reference page
L0730	P/W (DR) SW pulse1 disconnection	<a href="#">P.42A-65</a>
L0732	P/W (DR) SW pulse2 disconnection	<a href="#">P.42A-67</a>
L0734	P/W (DR) Above window position	<a href="#">P.42A-69</a>
L0736	P/W (DR) Sensor fail (ground)	<a href="#">P.42A-70</a>
L0740	P/W (DR) 3 times jam - protection	<a href="#">P.42A-72</a>
L0746	P/W (DR) Parameter read fail	<a href="#">P.42A-73</a>
L0750	P/W (DR) Position read fail	

## TROUBLE SYMPTOM CHART

M1429002800904

**⚠ CAUTION**

During diagnosis, a diagnostic trouble code associated with other system may be set when the ignition switch is turned on with connector(s) disconnected. On completion, check all systems for diagnostic trouble code(s). If diagnostic trouble code(s) are set, erase them all.

Trouble symptom	Inspection procedure number	Reference page
Power windows do not work at all.	1	<a href="#">P.42A-74</a>
Driver's power window does not work by means of the power window main switch.	2	<a href="#">P.42A-82</a>
Relevant power window(s) does not work by means of the front and rear passenger's power window sub switches.	3	<a href="#">P.42A-85</a>
Front and/or rear passenger's power window(s) do not work by means of the power window main switch.	4	<a href="#">P.42A-101</a>
The power window timer function does not work normally.	5	<a href="#">P.42A-105</a>
Power window anti-trap function does not work normally <driver's side only>.	6	<a href="#">P.42A-107</a>
The window glass lowers automatically while it is rising.	7	<a href="#">P.42A-109</a>


DIAGNOSTIC TROUBLE CODE PROCEDURES <POWER WINDOW>

CODE NO. L0730: P/W (DR) SW pulse 1 disconnection

**CAUTION**


Before replacing the ECU, ensure that the input and output signal circuits are normal.

Driver's Side Power Window Circuit



AC901706AB

Connectors: E-14, E-15



**COMMENTS ON TROUBLE SYMPTOM**

If the pulse 1 signal from the front power window motor (LH) cannot be received, the power window main switch sets the diagnosis trouble code No. L0730.

**PROBABLE CAUSES**

- Malfunction of the front power window motor (LH)
- Malfunction of the power window main switch
- Damaged wiring harness and connectors

---

**DIAGNOSTIC PROCEDURE**

---

**STEP 1. Check power window main switch connector E-15, front power window motor (LH) connector E-14 for loose, corroded or damaged terminals, or terminals pushed back in the connector.**

**Q: Are power window main switch connector E-15, front power window motor (LH) connector E-14 in good condition?**

**YES :** Go to Step 2.

**NO :** Repair or replace the damaged component(s). Refer to GROUP 00E, Harness Connector Inspection [P.00E-2](#). Verify that the power window works normally.

---

**STEP 2. Check the wiring harness between power window main switch connector E-15 (terminals Nos. 8, 9, 12) and front power window motor (LH) connector E-14 (terminals Nos. 3, 5, 6).**

**Q: Is the wiring harness between power window main switch connector E-15 (terminals Nos. 8, 9, 12) and front power window motor (LH) connector E-14 (terminals Nos. 3, 5, 6) in good condition?**

**YES :** Go to Step 3.

**NO :** The wiring harness may be damaged or the connector(s) may have loose, corroded or damaged terminals, or terminals pushed back in the connector. Repair the wiring harness as necessary. Verify that the power window works normally.

---

**STEP 3. Diagnostic trouble code recheck**

Replace the front power window motor (LH). Recheck if the diagnostic trouble code is set.

(1) Erase the diagnostic trouble code.

(2) Operate the driver's door window switch on the power window main switch.

(3) Check if the diagnostic trouble code is set.

**Q: Is the diagnostic trouble code set?**

**YES :** Replace the power window main switch.


**NO :** The procedure is complete. Verify that the power window works normally.

CODE NO. L0732: P/W (DR) SW pulse 2 disconnection

**CAUTION**


Before replacing the ECU, ensure that the input and output signal circuits are normal.

Driver's Side Power Window Circuit



AC901706AB

Connectors: E-14, E-15



**COMMENTS ON TROUBLE SYMPTOM**

If the pulse 2 signal from the front power window motor (LH) cannot be received, the power window main switch sets the diagnosis trouble code No. L0732.

**PROBABLE CAUSES**

- Malfunction of the front power window motor (LH)
- Malfunction of the power window main switch
- Damaged wiring harness and connectors

---

**DIAGNOSTIC PROCEDURE**

---

**STEP 1. Check power window main switch connector E-15, front power window motor (LH) connector E-14 for loose, corroded or damaged terminals, or terminals pushed back in the connector.**

**Q: Are power window main switch connector E-15, front power window motor (LH) connector E-14 in good condition?**

**YES :** Go to Step 2.

**NO :** Repair or replace the damaged component(s). Refer to GROUP 00E, Harness Connector Inspection [P.00E-2](#). Verify that the power window works normally.

---

**STEP 2. Check the wiring harness between power window main switch connector E-15 (terminals Nos. 9, 11, 12) and front power window motor (LH) connector E-14 (terminals Nos. 5, 2, 6).**

**Q: Is the wiring harness between power window main switch connector E-15 (terminals Nos. 9, 11, 12) and front power window motor (LH) connector E-14 (terminals Nos. 5, 2, 6) in good condition?**

**YES :** Go to Step 3.

**NO :** The wiring harness may be damaged or the connector(s) may have loose, corroded or damaged terminals, or terminals pushed back in the connector. Repair the wiring harness as necessary. Verify that the power window works normally.

---

**STEP 3. Diagnostic trouble code recheck**

Replace the front power window motor (LH). Recheck if the diagnostic trouble code is set.

(1) Erase the diagnostic trouble code.

(2) Operate the driver's door window switch on the power window main switch.

(3) Check if the diagnostic trouble code is set.

**Q: Is the diagnostic trouble code set?**

**YES :** Replace the power window main switch.

**NO :** The procedure is complete. Verify that the power window works normally.

---

**CODE NO. L0734: P/W (DR) Above window position**

---

**⚠ CAUTION**

Before replacing the ECU, ensure that the input and output signal circuits are normal.

**COMMENTS ON TROUBLE SYMPTOM**

If the driver's door window glass exceeds the fully closed position, power window main switch sets the diagnostic trouble code No. L0734.

**PROBABLE CAUSES**

- Malfunction of the front power window motor (LH)
- Malfunction of the power window main switch

**DIAGNOSTIC PROCEDURE**

---

**STEP 1. Check the power window fully closed position**

- (1) Carry out the learning procedures of the power window fully closed position. Refer to [P.42A-123](#).
- (2) Recheck if the diagnostic trouble code is set.
  - a. Erase the diagnostic trouble code.
  - b. Press the driver's door window switch (on the power window main switch) down to open the window, and pull up the driver's door window switch to fully close the window.
  - c. Check if the diagnostic trouble code is set.

**Q: Is the check result normal?**

**YES** : The procedure is complete.

**NO** : Go to Step 2.

---

**STEP 2. Diagnostic trouble code recheck**

Replace the front power window motor (LH). Recheck if the diagnostic trouble code is set.

- (1) Erase the diagnostic trouble code.
- (2) Press the driver's door window switch (on the power window main switch) down to open the window, and pull up the driver's door window switch to fully close the window.
- (3) Check if the diagnostic trouble code is set.

**Q: Is the diagnostic trouble code set?**

**YES** : Replace the power window main switch.


**NO** : The procedure is complete. Verify that the power window works normally.

CODE NO. L0736: P/W (DR) Sensor fail (ground)

**CAUTION**


Before replacing the ECU, ensure that the input and output signal circuits are normal.

Driver's Side Power Window Circuit



AC901706AB

Connectors: E-14, E-15



**COMMENTS ON TROUBLE SYMPTOM**

If the ground fault of the front power window motor (LH) sensor power supply is detected, power window main switch sets the diagnosis trouble code No. L0736

**PROBABLE CAUSES**

- Malfunction of the front power window motor (LH)
- Malfunction of the power window main switch
- Damaged wiring harness and connectors

---

## DIAGNOSTIC PROCEDURE

---

**STEP 1. Check power window main switch connector E-15, front power window motor (LH) connector E-14 for loose, corroded or damaged terminals, or terminals pushed back in the connector.**

**Q: Are power window main switch connector E-15, front power window motor (LH) connector E-14 in good condition?**

**YES :** Go to Step 2.

**NO :** Repair or replace the damaged component(s). Refer to GROUP 00E, Harness Connector Inspection [P.00E-2](#). Verify that the power window works normally.

---

**STEP 2. Check the wiring harness between power window main switch connector E-15 (terminal No. 12) and front power window motor (LH) connector E-14 (terminal No. 6).**

**Q: Is the wiring harness between power window main switch connector E-15 (terminal No. 12) and front power window motor (LH) connector E-14 (terminal No. 6) in good condition?**

**YES :** Go to Step 3.

**NO :** The wiring harness may be damaged or the connector(s) may have loose, corroded or damaged terminals, or terminals pushed back in the connector. Repair the wiring harness as necessary. Verify that the power window works normally.

---

### **STEP 3. Diagnostic trouble code recheck**

Replace the front power window motor (LH). Recheck if the diagnostic trouble code is set.

(1) Erase the diagnostic trouble code.

(2) Turn the ignition switch from the LOCK (OFF) position to the ON position.

(3) Check if the diagnostic trouble code is set.

**Q: Is the diagnostic trouble code set?**

**YES :** Replace the power window main switch.

**NO :** The procedure is complete. Verify that the power window works normally.

---

**CODE NO. L0740: P/W (DR) 3 times jam - protection**

---

**⚠ CAUTION**

Before replacing the ECU, ensure that the input and output signal circuits are normal.

**COMMENTS ON TROUBLE SYMPTOM**

If the anti-trap function is activated consecutively three times or more, power window main switch sets the diagnostic trouble code No. L0740.

**PROBABLE CAUSES**

- Malfunction of the front power window motor (LH)
- Malfunction of the power window main switch

**DIAGNOSTIC PROCEDURE**

---

**STEP 1. Check the power window fully closed position**

- (1) Carry out the learning procedures of the power window fully closed position. Refer to [P.42A-123](#).
- (2) Recheck if the diagnostic trouble code is set.
  - a. Erase the diagnostic trouble code.
  - b. Turn the ignition switch from the LOCK (OFF) position to the ON position.
  - c. Check if the diagnostic trouble code is set.

**Q: Is the check result normal?**

**YES** : The procedure is complete.

**NO** : Go to Step 2.

---

**STEP 2. Diagnostic trouble code recheck**

Replace the front power window motor (LH). Recheck if the diagnostic trouble code is set.

- (1) Erase the diagnostic trouble code.
- (2) Turn the ignition switch from the LOCK (OFF) position to the ON position.
- (3) Check if the diagnostic trouble code is set.

**Q: Is the diagnostic trouble code set?**

**YES** : Replace the power window main switch.

**NO** : The procedure is complete. Verify that the power window works normally.

---

**CODE NO. L0746: P/W (DR) Parameter read fail**

**CODE NO. L0750: P/W (DR) Position read fail**

---

**⚠ CAUTION**

Before replacing the ECU, ensure that the input and output signal circuits are normal.

- If the driver's door window glass position cannot be read, power window main switch sets the diagnostic trouble code No. L0750.

**COMMENTS ON TROUBLE SYMPTOM**

- If the power window main switch information signals cannot be read, power window main switch sets the diagnostic trouble code No. L0746.

**PROBABLE CAUSES**

- Malfunction of the power window main switch

**DIAGNOSTIC PROCEDURE**

---

**Diagnostic trouble code recheck**

Recheck if the diagnostic trouble code is set.

- (1) Erase the diagnostic trouble code.
- (2) Turn the ignition switch from the LOCK (OFF) position to the ON position.
- (3) Check if the diagnostic trouble code is set.

**Q: Is the diagnostic trouble code set?**

**YES** : Replace the power window main switch.


**NO** : The procedure is complete. Verify that the power window works normally.




**SYMPTOM PROCEDURES <POWER WINDOW>**

**INSPECTION PROCEDURE 1: Power Windows do not work at All.**

**CAUTION**

Before replacing the ECU, ensure that the power supply circuit, the ground circuit and the communication circuit are normal.





## CIRCUIT OPERATION

The ETACS-ECU turns on the power window relay to activate the power windows when the ignition switch (IG1) is turned to the "ON" position.

## TROUBLESHOOTING HINTS

- The wiring harness or connectors may have loose, corroded, or damaged terminals, or terminals pushed back in the connector
- The power window main switch may be defective
- The ETACS-ECU may be defective

## DIAGNOSTIC PROCEDURE

### Required Special Tools:

- MB992006: Extra fine probe
- MB991223: Harness set
- MB991958: Scan Tool (M.U.T.-III Sub Assembly)
  - MB991824: Vehicles Communication Interface (V.C.I.)
  - MB991827: M.U.T.-III USB Cable
  - MB991910: M.U.T.-III Main Harness A

### STEP 1. Check the power supply system.

With the ignition switch in the LOCK (OFF) position, check if the following function operates normally:

- Hazard warning light

### Q: Is the check result normal?

**YES** : Go to Step 2.

**NO** : Refer to GROUP 54A –malfunction of ETACS-ECU power supply circuit [P.54A-700](#).

**STEP 2.** Using scan tool MB991958, read the diagnostic trouble code.

**⚠ CAUTION**


To prevent damage to scan tool MB991958, always turn the ignition switch to the "LOCK" (OFF) position before connecting or disconnecting scan tool MB991958.


- (1) Connect scan tool MB991958. Refer to "How to connect scan tool (M.U.T.-III) [P.42B-9](#)."
- (2) Turn the ignition switch to the "ON" position.
- (3) Check whether the ETACS-ECU related DTC is set.
- (4) Turn the ignition switch to the "LOCK" (OFF) position.

**Q: Is the DTC set?**

**YES :** Diagnose the ETACS-ECU. Refer to GROUP 54B, Diagnostic trouble code chart [P.54B-6](#).

**NO :** Go to Step 3.





**STEP 3. Using scan tool MB991958, check data list.**

Check the signals related to the power window operation.

**⚠ CAUTION**

To prevent damage to scan tool MB991958, always turn the ignition switch to the "LOCK" (OFF) position before connecting or disconnecting scan tool MB991958.

- (1) Connect scan tool MB991958. Refer to "How to connect the Scan Tool (M.U.T.-III) P.42B-9."
- (2) Turn the ignition switch to the "ON" position.
- (3) Check the data list of the ETACS.
  - Turn the ignition switch to the LOCK (OFF) position.

Item No.	Item name	Normal condition
254	IG voltage	Battery positive voltage

- (4) Turn the ignition switch to the "LOCK" (OFF) position.

**OK: Normal condition is displayed.**

**Q: Is the check result normal?**

**YES :** Go to Step 4.


**NO :** Refer to GROUP 54A, Inspection Procedure 2: ETACS-ECU does not receive any signal from the ignition switch (IG1) P.54A-706.

**STEP 4. Check ETACS-ECU connector C-309 for loose, corroded or damaged terminals, or terminals pushed back in the connector.**

**Q: Is ETACS-ECU connector C-309 in good condition?**

**YES :** Go to Step 5.

**NO :** Repair or replace the damaged component(s). Refer to GROUP 00E, Harness Connector Inspection P.00E-2. Verify that the power window works normally.



**STEP 5. Check the fusible link (34) line of power supply circuit to the ETACS-ECU. Measure the voltage at ETACS-ECU connector C-309.**

- (1) Disconnect ETACS-ECU connector C-309 and measure the voltage available at the wiring harness side of the connector.
- (2) Measure the voltage between terminal 1 and ground.
  - The voltage should measure approximately 12 volts (battery positive voltage).

**Q: Is the measured voltage approximately 12 volts (battery positive voltage)?**

**YES :** Go to Step 7.

**NO :** Go to Step 6.

**STEP 6. Check the wiring harness between ETACS-ECU connector C-309 (terminal 1) and fusible link (34).**

**Q: Is the wiring harness between ETACS-ECU connector C-309 (terminal 1) and fusible link (34) in good condition?**

**YES :** No action is necessary and testing is complete.


**NO :** The wiring harness may be damaged or the connector(s) may have loose, corroded or damaged terminals, or terminals pushed back in the connector. Repair the wiring harness as necessary. Check that the power window works normally.

**STEP 7. Check ETACS-ECU connector C-307 for loose, corroded or damaged terminals, or terminals pushed back in the connector.**

**Q: Is ETACS-ECU connector C-307 in good condition?**

**YES :** Go to Step 8.

**NO :** Repair or replace the damaged component(s). Refer to GROUP 00E, Harness Connector Inspection [P.00E-2](#). Verify that the power window works normally.



**STEP 8. Check the fusible link (36) line of power supply circuit to the ETACS-ECU. Measure the voltage at ETACS-ECU connector C-307.**

- (1) Disconnect ETACS-ECU connector C-307 and measure the voltage available at the wiring harness side of the connector.
- (2) Measure the voltage between terminal 2 and ground.
  - The voltage should measure approximately 12 volts (battery positive voltage).

**Q: Is the measured voltage approximately 12 volts (battery positive voltage)?**

**YES :** Go to Step 10.

**NO :** Go to Step 9.

**STEP 9. Check the wiring harness between ETACS-ECU connector C-307 (terminal 2) and fusible link (36).**

**Q: Is the wiring harness between ETACS-ECU connector C-307 (terminal 2) and fusible link (36) in good condition?**

**YES :** No action is necessary and testing is complete.


**NO :** The wiring harness may be damaged or the connector(s) may have loose, corroded or damaged terminals, or terminals pushed back in the connector. Repair the wiring harness as necessary. Check that the power window works normally.

**STEP 10. Check power window main switch connector E-15 for loose, corroded or damaged terminals, or terminals pushed back in the connector.**

**Q: Is power window main switch connector E-15 in good condition?**

**YES :** Go to Step 11.

**NO :** Repair or replace the damaged component(s). Refer to GROUP 00E, Harness Connector Inspection [P.00E-2](#). Verify that the power window works normally.



**STEP 11. Check the ETACS-ECU connector C-315 line circuit to the power window main switch. Measure the voltage at power window main switch connector E-15.**

- (1) Disconnect power window main switch connector E-15 and measure the voltage available at the wiring harness side of the connector.
- (2) Measure the voltage between terminal 5 and ground.
  - The voltage should measure approximately 12 volts (battery positive voltage).

**Q: Is the measured voltage approximately 12 volts (battery positive voltage)?**

**YES :** Go to Step 14.

**NO :** Go to Step 12.

**STEP 12. Check ETACS-ECU connector C-315 for loose, corroded or damaged terminals, or terminals pushed back in the connector.**

**Q: Is ETACS-ECU connector C-315 in good condition?**

**YES :** Go to Step 13.

**NO :** Repair or replace the damaged component(s). Refer to GROUP 00E, Harness Connector Inspection [P.00E-2](#). Verify that the power window works normally.


**STEP 13. Check the wiring harness between ETACS-ECU connector C-315 (terminal 10) and power window main switch connector E-15 (terminal 5).**

*NOTE: Also check intermediate connector C-128 for loose, corroded, or damaged terminals, or terminals pushed back in the connector. If intermediate connector C-128 is damaged, repair or replace the damaged component(s) as described in GROUP 00E, Harness Connector Inspection [P.00E-2](#).*

**Q: Is the wiring harness between ETACS-ECU connector C-315 (terminal 10) and power window main switch connector E-15 (terminal 5) in good condition?**

**YES :** No action is necessary and testing is complete.

**NO :** The wiring harness may be damaged or the connector(s) may have loose, corroded or damaged terminals, or terminals pushed back in the connector. Repair the wiring harness as necessary. Check that the power window works normally.



**STEP 14. Check the ground circuit to the power window main switch. Measure the resistance at power window main switch connector E-15.**

- (1) Disconnect power window main switch connector E-15 and measure the resistance available at the wiring harness side of the connector.
- (2) Measure the resistance value between terminal 10 and ground.
  - The resistance should be 2 ohms or less.

**Q: Is the measured resistance 2 ohms or less?**

**YES :** Go to Step 16.

**NO :** Go to Step 15.

**STEP 15. Check the wiring harness between power window main switch connector E-15 (terminal 10) and ground.**

*NOTE: Also check intermediate connector C-128 for loose, corroded, or damaged terminals, or terminals pushed back in the connector. If intermediate connector C-128 is damaged, repair or replace the damaged component(s) as described in GROUP 00E, Harness Connector Inspection P.00E-2.*

**Q: Is the wiring harness between power window main switch connector E-15 (terminal 10) and ground in good condition?**

**YES :** No action is necessary and testing is complete.

**NO :** The wiring harness may be damaged or the connector(s) may have loose, corroded or damaged terminals, or terminals pushed back in the connector. Repair the wiring harness as necessary. Check that the power window works normally.

**STEP 16. Retest the system.**

Check that the all power windows work normally.

**Q: Is the check result normal?**

**YES :** No action is necessary and testing is complete.


**NO :** Replace ETACS-ECU. Check that the power window works normally.

**INSPECTION PROCEDURE 2: Driver's Power Window does not work by means of the Power Window Main Switch.**

**CAUTION**


Before replacing the ECU, ensure that the power supply circuit, the ground circuit and the communication circuit are normal.

Driver's Side Power Window Circuit



AC901706AB

Connectors: E-14, E-15



**CIRCUIT OPERATION**

The front power window motor (LH) receives a signal ("UP", "DOWN", "AUTO UP" or "AUTO DOWN") from the front power window main switch and controls the driver's power window.

**TECHNICAL DESCRIPTION (COMMENT)**

The power window main switch or the front power window motor (LH) may be defective.

**TROUBLESHOOTING HINTS**

- The power window main switch may be defective
- The front power window motor (LH) may be defective
- The wiring harness or connectors may have loose, corroded, or damaged terminals, or terminals pushed back in the connector

**DIAGNOSTIC PROCEDURE**

**Required Special Tools:**

- MB992006: Extra fine probe
- MB991223: Harness set
- MB991958: Scan Tool (M.U.T.-III Sub Assembly)
  - MB991824: Vehicles Communication Interface (V.C.I.)
  - MB991827: M.U.T.-III USB Cable
  - MB991910: M.U.T.-III Main Harness A

**STEP 1. Using scan tool MB991958, read the diagnostic trouble code.**


**⚠ CAUTION**

To prevent damage to scan tool MB991958, always turn the ignition switch to the "LOCK" (OFF) position before connecting or disconnecting scan tool MB991958.

- (1) Connect scan tool MB991958. Refer to "How to connect scan tool (M.U.T.-III) P.42B-9."
- (2) Turn the ignition switch to the "ON" position.
- (3) Check whether the power window main switch related DTC is set.
- (4) Turn the ignition switch to the "LOCK" (OFF) position.

**Q: Is the DTC set?**

- YES :** Diagnose the power window main switch. Refer to Diagnostic trouble code chart P.42A-64.
- NO :** Go to Step 2.



**STEP 2. Check the power window main switch.**

Check that the passenger's or rear power window works by means of the power window main switch.

**Q: Is the check result normal?**

- YES :** Go to Step 3.
- NO :** Refer to inspection procedure 1 "Power windows do not work at all P.42A-64."

---

**STEP 3. Check power window main switch connector E-15, front power window motor (LH) connector E-14 for loose, corroded or damaged terminals, or terminals pushed back in the connector.**

**Q: Are power window main switch connector E-15, front power window motor (LH) connector E-14 in good condition?**

**YES :** Go to Step 4.

**NO :** Repair or replace the damaged component(s). Refer to GROUP 00E, Harness Connector Inspection [P.00E-2](#). Verify that the power window works normally.

---

**STEP 4. Check the wiring harness between power window main switch connector E-15 (terminals Nos. 2, 6) and front power window motor (LH) connector E-14 (terminals Nos. 4, 1).**

**Q: Is the wiring harness between power window main switch connector E-15 (terminals Nos. 2, 6) and front power window motor (LH) connector E-14 (terminals Nos. 4, 1) in good condition?**

**YES :** Go to Step 5.

**NO :** The wiring harness may be damaged or the connector(s) may have loose, corroded or damaged terminals, or terminals pushed back in the connector. Repair the wiring harness as necessary. Check that the power works normally.

---

**STEP 5. Retest the system.**

Check that the driver's power window works by means of the power window main switch.

**Q: Is the check result normal?**


**YES :** No action is necessary and testing is complete.

**NO :** Replace the front power window motor (LH). Check that the power works normally.


**INSPECTION PROCEDURE 3: Relevant Power Window(s) does not work by means of the Front and Rear Passenger's Power Window Sub Switches.**

**CAUTION**










Before replacing the ECU, ensure that the power supply circuit, the ground circuit and the communication circuit are normal.



Power window (Rear Door) Circuit



AC901720AB



**CIRCUIT OPERATION**

power window motors raise and lower the door windows when the front passenger's or rear passenger's sub switch is moved to "UP" or "DOWN" position.

**TECHNICAL DESCRIPTION (COMMENT)**

A power window sub switch or power window motor may be defective. Or, the power window lock switch (incorporated in the power window main switch in the driver's door) may remain pressed in the "LOCK" position.

**TROUBLESHOOTING HINTS**

- The power window main switch may be defective

- The front power window sub switch may be defective
- The rear power window sub switches may be defective
- The front power window motor (RH) may be defective
- The rear power window motors may be defective
- The wiring harness or connectors may have loose, corroded, or damaged terminals, or terminals pushed back in the connector

**DIAGNOSTIC PROCEDURE****STEP 1. Check the power window lock switch.**

**Q: Is the power window lock switch in the "UNLOCK" position?**

**YES :** Go to Step 2.

**NO :** Operate the power window lock switch to the "UNLOCK" position. When the power window sub switch is operated, the power windows should raise and lower normally.

**STEP 2. Check power window main switch connector E-15 for loose, corroded or damaged terminals, or terminals pushed back in the connector.**

**Q: Is power window main switch connector E-15 in good condition?**

**YES :** Go to Step 3.

**NO :** Repair or replace the damaged component(s). Refer to GROUP 00E, Harness Connector Inspection [P.00E-2](#). When the power window sub switch is operated, the power windows should raise and lower normally.

**STEP 3. Determine a trouble spot.**

**Q: Which power window does not work?**

**Front passenger's door :** Go to Step 4.

**Rear left door :** Go to Step 13.

**Rear right door :** Go to Step 22.

**STEP 4. Check front power window sub switch connector E-09 and front power window motor (RH) connector E-10 for loose, corroded or damaged terminals, or terminals pushed back in the connector.**


**Q: Are front power window sub switch connector E-09 and front power window motor (RH) connector E-10 in good condition?**

**YES :** Go to Step 5.

**NO :** Repair or replace the damaged component(s). Refer to GROUP 00E, Harness Connector Inspection [P.00E-2](#). When the front power window sub switch (RH) is operated, the front power window (RH) should raise and lower normally.

**STEP 5. Check the front power window sub switch for continuity.**

- (1) Remove the front power window sub switch. Refer to Door Glass and Regulator [P.42A-131](#).
- (2) Check continuity when the front power window sub switch is operated to "UP" or "DOWN" position.



Switch position	Tester connection	Specified condition
UP	4 -5, 6 -7	Continuity exists (2 Ω or less)
OFF	4 -5, 7 -8	Continuity exists (2 Ω or less)
DOWN	4 -6, 7 -8	Continuity exists (2 Ω or less)


**Q: Is the front power window sub switch normal?**

**YES :** Go to Step 6.

**NO :** Replace the front power window sub switch. When the front power window sub switch is operated, the front power window should raise and lower normally.

**STEP 6. Check the front power window motor (RH).**

- (1) Remove the front power window regulator (RH). Refer to Door Glass and Regulator P.42A-131.
- (2) Connect a battery to the motor terminal, and check that the motor runs freely.



Battery connection	Slider position
<ul style="list-style-type: none"> <li>• Connect terminal 1 to the negative battery terminal</li> <li>• Connect terminal 4 to the positive battery terminal</li> </ul>	UP
<ul style="list-style-type: none"> <li>• Connect terminal 4 to the negative battery terminal</li> <li>• Connect terminal 1 to the positive battery terminal</li> </ul>	DOWN


**Q: Is the front power window motor (RH) normal?**

**YES :** Go to Step 7.

**NO :** Replace the front power window regulator (RH).  
When the front power window sub switch (RH) is operated, the front power window (RH) should raise and lower normally.

**STEP 7. Check the battery power supply circuit to the front power window sub switch. Measure the voltage at front power window sub switch connector E-09.**

- (1) Disconnect front power window sub switch connector E-09 and measure the voltage available at the wiring harness side of the connector.
- (2) Measure the voltage between terminal 6 and ground.
  - The voltage should measure approximately 12 volts (battery positive voltage).



**Q: Is the measured voltage approximately 12 volts (battery positive voltage)?**

**YES :** Go to Step 10.

**NO :** Go to Step 8.

**STEP 8. Check ETACS-ECU connector C-315 for loose, corroded or damaged terminals, or terminals pushed back in the connector.**

**Q: Is ETACS-ECU connector C-315 in good condition?**

**YES :** Go to Step 9.

**NO :** Repair or replace the damaged component(s). Refer to GROUP 00E, Harness Connector Inspection [P.00E-2](#). When the front power window sub switch (RH) is operated, the front power window (RH) should raise and lower normally.

**STEP 9. Check the wiring harness between ETACS-ECU connector C-315 (terminal No. 8) and front power window sub switch connector E-09 (terminal No. 6).**

*NOTE: Also check intermediate connector C-116. If intermediate connector C-116 is damaged, repair or replace the damaged component(s) as described in GROUP 00E, Harness Connector Inspection [P.00E-2](#).*

**Q: Is the wiring harness between ETACS-ECU connector C-315 (terminal No. 8) and front power window sub switch connector E-09 (terminal No. 6) in good condition?**

**YES :** No action is necessary and testing is complete.

**NO :** The wiring harness may be damaged or the connector(s) may have loose, corroded or damaged terminals, or terminals pushed back in the connector. Repair the wiring harness as necessary. When the front power window sub switch is operated, the front power window (RH) should raise and lower normally.


**STEP 10. Check the ground circuit to the front power window sub switch. Measure the resistance at front power window sub switch connector E-09.**

- (1) Disconnect front power window sub switch connector E-09 and measure the resistance available at the wiring harness side of the connector.
  - The resistance should be 2 ohms or less.
- (2) Measure the resistance value between terminal 5 and ground, and also between terminal 8 and ground.

**Q: Is the measured resistance 2 ohms or less?**

**YES :** Go to Step 12.

**NO :** Go to Step 11.



**STEP 11. Check the wiring harness between power window main switch connector E-15 (terminals Nos. 1, 3) and front power window sub switch connector E-09 (terminals Nos. 8, 5).**

*NOTE: Also check intermediate connectors C-116 and C-128. If intermediate connector C-116 or C-128 is damaged, repair or replace the damaged component(s) as described in GROUP 00E, Harness Connector Inspection P.00E-2.*

**Q: Is the wiring harness between power window main switch connector E-15 (terminals Nos. 1, 3) and front power window sub switch connector E-09 (terminals Nos. 8, 5) in good condition?**

**YES :** Replace the power window main switch. When the front power window sub switch (RH) is operated, the front power window (RH) should raise and lower normally.

**NO :** The wiring harness may be damaged or the connector(s) may have loose, corroded or damaged terminals, or terminals pushed back in the connector. Repair the wiring harness as necessary. When the front power window sub switch (RH) is operated, the front power window (RH) should raise and lower normally.

---

**STEP 12. Check the wiring harness between front power window sub switch connector E-09 (terminals Nos. 4, 7) and front power window motor (RH) connector E-10 (terminals Nos. 1, 4).**

**Q: Is the wiring harness between front power window sub switch connector E-09 (terminals Nos. 4, 7) and front power window motor (RH) connector E-10 (terminals Nos. 1, 4) in good condition?**

**YES :** No action is necessary and testing is complete.

**NO :** The wiring harness may be damaged or the connector(s) may have loose, corroded or damaged terminals, or terminals pushed back in the connector. Repair the wiring harness as necessary. When the front power window sub switch (RH) is operated, the front power window (RH) should raise and lower normally.

**STEP 13. Check rear power window sub switch (LH) connector E-24 and rear power window motor (LH) connector E-25 for loose, corroded or damaged terminals, or terminals pushed back in the connector.**


**Q: Are rear power window sub switch (LH) connector E-24 and rear power window motor (LH) connector E-25 in good condition?**

**YES :** Go to Step 14.

**NO :** Repair or replace the damaged component(s). Refer to GROUP 00E, Harness Connector Inspection [P.00E-2](#). When the rear power window sub switch (LH) is operated, the rear power window (LH) should raise and lower normally.

**STEP 14. Check the rear power window sub switch (LH) for continuity.**

- (1) Remove the rear power window sub switch (LH). Refer to Door Glass and Regulator [P.42A-131](#).
- (2) Check continuity when the rear power window sub switch (LH) is operated to "UP" or "DOWN" position.



Switch position	Tester connection	Specified condition
UP	4 -5, 6 -7	Continuity exists (2 Ω or less)
OFF	4 -5, 7 -8	Continuity exists (2 Ω or less)
DOWN	4 -6, 7 -8	Continuity exists (2 Ω or less)


**Q: Is the rear power window sub switch (LH) normal?**

**YES :** Go to Step 15.

**NO :** Replace the rear power window sub switch (LH). When the rear power window sub switch (LH) is operated, the rear power window (LH) should raise and lower normally.

**STEP 15. Check the rear power window motor (LH).**

- (1) Remove the rear power window regulator (LH). Refer to Door Glass and Regulator P.42A-131.
- (2) Connect a battery to the motor terminal, and check that the motor runs freely.



Battery connection	Slider position
<ul style="list-style-type: none"> <li>• Connect terminal 4 to the negative battery terminal</li> <li>• Connect terminal 1 to the positive battery terminal</li> </ul>	UP
<ul style="list-style-type: none"> <li>• Connect terminal 1 to the negative battery terminal</li> <li>• Connect terminal 4 to the positive battery terminal</li> </ul>	DOWN


**Q: Is the rear power window motor (LH) normal?**

**YES :** Go to Step 16.

**NO :** Replace the rear power window regulator (LH). When the rear power window sub switch (LH) is operated, the rear power window (LH) should raise and lower normally.

**STEP 16. Check the battery power supply circuit to the rear power window sub switch (LH). Measure the voltage at rear power window sub switch (LH) connector E-24.**

- (1) Disconnect rear power window sub switch (LH) connector E-24 and measure the voltage available at the wiring harness side of the connector.
- (2) Measure the voltage between terminal 6 and ground.
  - The voltage should measure approximately 12 volts (battery positive voltage).



**Q: Is the measured voltage approximately 12 volts (battery positive voltage)?**

**YES :** Go to Step 19.

**NO :** Go to Step 17.

**STEP 17. Check ETACS-ECU connector C-311 for loose, corroded or damaged terminals, or terminals pushed back in the connector.**

**Q: Is ETACS-ECU connector C-311 in good condition?**

**YES :** Go to Step 18.

**NO :** Repair or replace the damaged component(s). Refer to GROUP 00E, Harness Connector Inspection [P.00E-2](#). When the rear power window sub switch (LH) is operated, the rear power window (LH) should raise and lower normally.

**STEP 18. Check the wiring harness between ETACS-ECU connector C-311 (terminal No. 12) and rear power window sub switch (LH) connector E-24 (terminal No. 6).**

*NOTE: Also check joint connector (5) D-27, intermediate connector D-24. If joint connector (5) D-27, intermediate connector D-24 is damaged, repair or replace the connector as described in GROUP 00E, Harness Connector Inspection [P.00E-2](#).*

**Q: Is the wiring harness between ETACS-ECU connector C-311 (terminal No. 12) and rear power window sub switch (LH) connector E-24 (terminal No. 6) in good condition?**

**YES :** No action is necessary and testing is complete.

**NO :** The wiring harness may be damaged or the connector(s) may have loose, corroded or damaged terminals, or terminals pushed back in the connector. Repair the wiring harness as necessary. When the rear power window sub switch (LH) is operated, the rear power window (LH) should raise and lower normally.


**STEP 19. Check the ground circuit to the rear power window sub switch (LH). Measure the resistance at rear power window sub switch (LH) connector E-24.**

- (1) Disconnect rear power window sub switch (LH) connector E-24 and measure the resistance available at the wiring harness side of the connector.
- (2) Measure the resistance value between terminal 5 and ground, and also between terminal 8 and ground.
  - The resistance should be 2 ohms or less.

**Q: Is the measured resistance 2 ohms or less?**

**YES :** Go to Step 21.

**NO :** Go to Step 20.



---

**STEP 20. Check the wiring harness between power window main switch connector E-15 (terminals Nos. 18, 19) and rear power window sub switch (LH) connector E-24 (terminals Nos. 5, 8).**

*NOTE: Also check intermediate connectors C-42, C-128 and D-24. If intermediate connectors C-42, C-128 or D-24 is damaged, repair or replace the damaged component(s) as described in GROUP 00E, Harness Connector Inspection P.00E-2.*

**Q: Is the wiring harness between power window main switch connector E-15 (terminals Nos. 18, 19) and rear power window sub switch (LH) connector E-24 (terminals Nos. 5, 8) in good condition?**

**YES :** Replace the power window main switch. When the rear power window sub switch (LH) is operated, the rear power window (LH) should raise and lower normally.

**NO :** The wiring harness may be damaged or the connector(s) may have loose, corroded or damaged terminals, or terminals pushed back in the connector. Repair the wiring harness as necessary. When the rear power window sub switch (LH) is operated, the rear power window (LH) should raise and lower normally.

---

**STEP 21. Check the wiring harness between rear power window sub switch (LH) connector E-24 (terminals Nos. 4, 7) and rear power window motor (LH) connector E-25 (terminals Nos. 4, 1).**

**Q: Is the wiring harness between rear power window sub switch (LH) connector E-24 (terminals Nos. 4, 7) and rear power window motor (LH) connector E-25 (terminals Nos. 4, 1) in good condition?**

**YES :** Replace the power window main switch. When the rear power window sub switch (LH) is operated, the rear power window (LH) should raise and lower normally.

**NO :** The wiring harness may be damaged or the connector(s) may have loose, corroded or damaged terminals, or terminals pushed back in the connector. Repair the wiring harness as necessary. When the rear power window sub switch (LH) is operated, the rear power window (LH) should raise and lower normally.

**STEP 22. Check rear power window sub switch (RH) connector E-21 and rear power window motor (RH) connector E-20 for loose, corroded or damaged terminals, or terminals pushed back in the connector.**


**Q: Are rear power window sub switch (RH) connector E-21 and rear power window motor (RH) connector E-20 in good condition?**

**YES :** Go to Step 23.

**NO :** Repair or replace the damaged component(s). Refer to GROUP 00E, Harness Connector Inspection [P.00E-2](#). When the rear power window sub switch (RH) is operated, the rear power window (RH) should raise and lower normally.

**STEP 23. Check the rear power window sub switch (RH) for continuity.**

- (1) Remove the rear power window sub switch (RH). Refer to Door Glass and Regulator [P.42A-131](#).
- (2) Check continuity when the rear power window sub switch (RH) is operated to "UP" or "DOWN" position.



Switch position	Tester connection	Specified condition
UP	4 -5, 6 -7	Continuity exists (2 Ω or less)
OFF	4 -5, 7 -8	Continuity exists (2 Ω or less)
DOWN	4 -6, 7 -8	Continuity exists (2 Ω or less)


**Q: Is the rear power window sub switch (RH) normal?**

**YES :** Go to Step 24.

**NO :** Replace the rear power window sub switch (RH). When the rear power window sub switch (RH) is operated, the rear power window (RH) should raise and lower normally.

**STEP 24. Check the rear power window motor (RH).**

- (1) Remove the rear power window regulator (RH). Refer to Door Glass and Regulator P.42A-131.
- (2) Connect a battery to the motor terminal, and check that the motor runs freely.



Battery connection	Slider position
<ul style="list-style-type: none"> <li>• Connect terminal 4 to the negative battery terminal</li> <li>• Connect terminal 1 to the positive battery terminal</li> </ul>	UP
<ul style="list-style-type: none"> <li>• Connect terminal 1 to the negative battery terminal</li> <li>• Connect terminal 4 to the positive battery terminal</li> </ul>	DOWN


**Q: Is the rear power window motor (RH) normal?**

**YES :** Go to Step 25.

**NO :** Replace the rear power window regulator (RH). When the rear power window sub switch (RH) is operated, the rear power window (RH) should raise and lower normally.

**STEP 25. Check the battery power supply circuit to the rear power window sub switch (RH). Measure the voltage at rear power window sub switch (RH) connector E-21.**

- (1) Disconnect rear power window sub switch (RH) connector E-21 and measure the voltage available at the wiring harness side of the connector.
- (2) Measure the voltage between terminal 6 and ground.
  - The voltage should measure approximately 12 volts (battery positive voltage).



**Q: Is the measured voltage approximately 12 volts (battery positive voltage)?**

**YES :** Go to Step 28.

**NO :** Go to Step 26.

**STEP 26. Check ETACS-ECU connector C-311 for loose, corroded or damaged terminals, or terminals pushed back in the connector.**

**Q: Is ETACS-ECU connector C-311 in good condition?**

**YES :** Go to Step 27.

**NO :** Repair or replace the damaged component(s). Refer to GROUP 00E, Harness Connector Inspection [P.00E-2](#). When the rear power window sub switch (RH) is operated, the rear power window (RH) should raise and lower normally.

**STEP 27. Check the wiring harness between ETACS-ECU connector C-311 (terminal No. 12) and rear power window sub switch (RH) connector E-21 (terminal No. 6).**

*NOTE: Also check joint connector (5) D-27, intermediate connector D-01. If joint connector (5) D-27, intermediate connector D-01 is damaged, repair or replace the connector as described in GROUP 00E, Harness Connector Inspection [P.00E-2](#).*

**Q: Is the wiring harness between ETACS-ECU connector C-311 (terminal No. 12) and rear power window sub switch (RH) connector E-21 (terminal No. 6) in good condition?**

**YES :** No action is necessary and testing is complete.

**NO :** The wiring harness may be damaged or the connector(s) may have loose, corroded or damaged terminals, or terminals pushed back in the connector. Repair the wiring harness as necessary. When the rear power window sub switch (RH) is operated, the rear power window (RH) should raise and lower normally.


**STEP 28. Check the ground circuit to the rear power window sub switch (RH). Measure the resistance at rear power window sub switch (RH) connector E-21.**

- (1) Disconnect rear power window sub switch (RH) connector E-21 and measure the resistance available at the wiring harness side of the connector.
- (2) Measure the resistance value between terminal 5 and ground, and also between terminal 8 and ground.
  - The resistance should be 2 ohms or less.

**Q: Is the measured resistance 2 ohms or less?**

**YES :** Go to Step 30.

**NO :** Go to Step 29.



---

**STEP 29. Check the wiring harness between power window main switch connector E-15 (terminals Nos. 15, 17) and rear power window sub switch (RH) connector E-21 (terminals Nos. 5, 8).**

*NOTE: Also check intermediate connectors C-23, C-128 and D-01. If intermediate connectors C-23, C-128 or D-01 is damaged, repair or replace the damaged component(s) as described in GROUP 00E, Harness Connector Inspection P.00E-2.*

**Q: Is the wiring harness between power window main switch connector E-15 (terminals 15, 17) and rear power window sub switch (RH) connector E-21 (terminals 5, 8) in good condition?**

**YES :** Replace the power window main switch. When the rear power window sub switch (RH) is operated, the rear power window (RH) should raise and lower normally.

**NO :** The wiring harness may be damaged or the connector(s) may have loose, corroded or damaged terminals, or terminals pushed back in the connector. Repair the wiring harness as necessary. When the rear power window sub switch (RH) is operated, the rear power window (RH) should raise and lower normally.

---

**STEP 30. Check the wiring harness between rear power window sub switch (RH) connector E-21 (terminals Nos. 4, 7) and rear power window motor (RH) connector E-20 (terminals Nos. 4, 1).**

**Q: Is the wiring harness between rear power window sub switch (RH) connector E-21 (terminals Nos. 4, 7) and rear power window motor (RH) connector E-20 (terminals Nos. 4, 1) in good condition?**

**YES :** No action is necessary and testing is complete.


**NO :** The wiring harness may be damaged or the connector(s) may have loose, corroded or damaged terminals, or terminals pushed back in the connector. Repair the wiring harness as necessary. When the rear power window sub switch (RH) is operated, the rear power window (RH) should raise and lower normally.

**INSPECTION PROCEDURE 4: Front and/or Rear Passenger's Power Window(s) do not work by means of the Power Window Main Switch.**

**CAUTION**



Before replacing the ECU, ensure that the power supply circuit, the ground circuit and the communication circuit are normal.

Power Window Circuit




AC709212AB

Connector: C-128

Connector: C-315  
ETACS-ECU

Connector: E-15



## CIRCUIT OPERATION

When you operate each power window switch for front or rear passengers (incorporated in the power window main switch), the corresponding power window motor operates, opening or closing each power window.

## TECHNICAL DESCRIPTION (COMMENT)

If the corresponding power window opens and closes normally when each power window sub-switch is operated, the power window main switch may be defective.

## TROUBLESHOOTING HINT

- The power window main switch may be defective
- The front power window sub switch may be defective
- The rear power window sub switches may be defective
- The ETACS-ECU may be defective
- The wiring harness or connectors may have loose, corroded, or damaged terminals, or terminals pushed back in the connector

## DIAGNOSTIC PROCEDURE

### Required Special Tools:

- MB992006: Extra fine probe
- MB991223: Harness set
- MB991958: Scan Tool (M.U.T.-III Sub Assembly)
  - MB991824: Vehicles Communication Interface (V.C.I.)
  - MB991827: M.U.T.-III USB Cable
  - MB991910: M.U.T.-III Main Harness A (Vehicles with CAN communication system)

### STEP 1. Check the power window main switch.

Check that the driver's power window works by means of the power window main switch.

#### Q: Is the check result normal?

**YES** : Go to Step 2.

**NO** : Refer to inspection procedure 2 "Driver's power window does not work by means of the power window main switch [P.42A-82](#)."

**STEP 2. Check the power window sub switch.**

Check that each power window works by means of the respective power window sub switch when the power window lock switch is turned off.

**Q: Is the check result normal?**

**YES :** Go to Step 3.

**NO :** Refer to inspection procedure 3 "Relevant power window(s) does not work by means of the front and rear passenger's power window sub switches [P.42A-85.](#)"

**STEP 3. Check the power supply system.**

With the ignition switch in the LOCK (OFF) position, check if the following function operates normally:

- Hazard warning light

**Q: Is the check result normal?**

**YES :** Go to Step 4.

**NO :** Refer to GROUP 54A –Malfunction of ETACS-ECU power supply circuit [P.54A-700.](#)

**STEP 4. Using scan tool MB991958, read the diagnostic trouble code.**

**⚠ CAUTION**


To prevent damage to scan tool MB991958, always turn the ignition switch to the "LOCK" (OFF) position before connecting or disconnecting scan tool MB991958.

- (1) Connect scan tool MB991958. Refer to "How to connect scan tool (M.U.T.-III) [P.42B-9.](#)"
- (2) Turn the ignition switch to the "ON" position.
- (3) Check whether the ETACS-ECU related DTC is set.
- (4) Turn the ignition switch to the "LOCK" (OFF) position.

**Q: Is the DTC set?**

**YES :** Diagnose the ETACS-ECU. Refer to GROUP 54B, Diagnostic trouble code chart [P.54B-6.](#)

**NO :** Go to Step 5.



**STEP 5. Check power window main switch connector E-15 for loose, corroded or damaged terminals, or terminals pushed back in the connector.**

**Q: Is power window main switch connector E-15 in good condition?**

**YES :** Go to Step 6.

**NO :** Repair or replace the damaged component(s). Refer to GROUP 00E, Harness Connector Inspection [P.00E-2](#). When the power window main switch is operated, the front and/or rear passenger's power windows should raise and lower normally.


**STEP 6. Check the ETACS-ECU connector C-315 line circuit to the power window main switch. Measure the voltage at power window main switch connector E-15.**

- (1) Disconnect power window main switch connector E-15 and measure the voltage available at the wiring harness side of the connector.
- (2) Measure the voltage between terminal 4 and ground.
  - The voltage should measure approximately 12 volts (battery positive voltage).

**Q: Is the measured voltage approximately 12 volts (battery positive voltage)?**

**YES :** Go to Step 9.

**NO :** Go to Step 7.



**STEP 7. Check ETACS-ECU connector C-315 for loose, corroded or damaged terminals, or terminals pushed back in the connector.**

**Q: Is ETACS-ECU connector C-315 in good condition?**

**YES :** Go to Step 8.

**NO :** Repair or replace the damaged component(s). Refer to GROUP 00E, Harness Connector Inspection [P.00E-2](#). When the power window main switch is operated, the front and/or rear passenger's power windows should raise and lower normally.

**STEP 8. Check the wiring harness between ETACS-ECU connector C-315 (terminal No. 8) and power window main switch connector E-15 (terminal No. 4).**

*NOTE: Also check intermediate connector C-128. If intermediate connector C-128 is damaged, repair or replace the damaged component(s) as described in GROUP 00E, Harness Connector Inspection P.00E-2.*

**Q: Is the wiring harness between ETACS-ECU connector C-315 (terminal No. 8) and power window main switch connector E-15 (terminal No. 4) in good condition?**

**YES :** No action is necessary and testing is complete.

**NO :** The wiring harness may be damaged or the connector(s) may have loose, corroded or damaged terminals, or terminals pushed back in the connector. Repair the wiring harness as necessary. When the power window main switch is operated, the front and/or rear passenger's power windows should raise and lower normally.

**STEP 9. Retest the system.**

Replace the power window main switch. Check that the front and/or rear passenger's power windows work by means of the power window main switch.

**Q: Is the check result normal?**

**YES :** No action is necessary and testing is complete.

**NO :** Replace ETACS-ECU. Check that the power window works normally.

**INSPECTION PROCEDURE 5: The Power Window Timer Function does not work Normally.**

**⚠ CAUTION**

Before replacing the ECU, ensure that the power supply circuit, the ground circuit and the communication circuit are normal.

**COMMENTS ON TROUBLE SYMPTOM**

If the power window timer function does not work normally, a malfunction of the power window main switch or ETACS-ECU is suspected.

**PROBABLE CAUSES**

- Malfunction of the front door switch (LH)
- Malfunction of the front door switch (RH)
- Malfunction of the power window main switch
- Malfunction of ETACS-ECU
- Damaged wiring harness and connectors

**DIAGNOSTIC PROCEDURE**

**Required Special Tools:**

- MB992006: Extra fine probe
- MB991223: Harness set
- MB991958: Scan Tool (M.U.T.-III Sub Assembly)
  - MB991824: Vehicles Communication Interface (V.C.I.)
  - MB991827: M.U.T.-III USB Cable
  - MB991910: M.U.T.-III Main Harness A

**STEP 1. Check the power supply system.**

With the ignition switch in the LOCK (OFF) position, check if the following function operates normally:

- Hazard warning lamp

**Q: Is the check result normal?**

**YES** : Go to Step 2.

**NO** : Refer to GROUP 54A –Malfunction of ETACS-ECU power supply circuit [P.54A-700](#).


**STEP 2. Using scan tool MB991958, check data list.**

Check the signals related to the power window timer function operation.

**CAUTION**

To prevent damage to scan tool MB991958, always turn the ignition switch to the "LOCK" (OFF) position before connecting or disconnecting scan tool MB991958.

- (1) Connect scan tool MB991958. Refer to "How to connect scan tool (M.U.T.-III) [P.42B-9](#)."
- (2) Turn the ignition switch to the "ON" position.
- (3) Check the data list of the ETACS.
  - Turn the ignition switch to the LOCK (OFF) position.
  - Close the driver's door.
  - Close the passenger's door.



Item No.	Item name	Normal condition
254	IG voltage	Battery positive voltage
256	Dr door ajar switch	Close
257	As door ajar switch	Close

- (4) Turn the ignition switch to the "LOCK" (OFF) position.

**OK: Normal condition is displayed.**

**Q: Is the check result normal?**

**YES** <Normal conditions are displayed for all the items.> : Go to Step 3.

**NO** <Normal condition is not displayed for item No.

**254.>** : Refer to GROUP 54A –Inspection procedure 2: "The ignition switch (IG1) signal is not received [P.54A-706](#)."

**NO** <Normal condition is not displayed for item No.

**256.>** : Refer to GROUP 54A –Inspection procedure 5: "The front door switch (driver's side) signal is not received [P.54A-721](#)."

**NO** <Normal condition is not displayed for item No.

**257.>** : Refer to GROUP 54A –Inspection procedure 6: the front door switch (passenger's side) signal is not received. [P.54A-719](#).

---

**STEP 3. Retest the system.**

Check that the power window timer function works normally.

**Q: Is the check result normal?**

**YES** : No action is necessary and testing is complete.

**NO** : Replace the power window main switch. Check that the power window timer function works normally.

---

**INSPECTION PROCEDURE 6: Power Window Anti-trap Function does not work Normally. <Driver's side only>**

---

**COMMENTS ON TROUBLE SYMPTOM**

Malfunction of the power window motor revolution detection sensor is suspected.


**PROBABLE CAUSES**

- Malfunction of the power window motor
- Damaged wiring harness and connectors

**DIAGNOSTIC PROCEDURE**

**Required Special Tools:**

- MB992006: Extra fine probe
- MB991223: Harness set
- MB991958: Scan Tool (M.U.T.-III Sub Assembly)
  - MB991824: Vehicles Communication Interface (V.C.I.)
  - MB991827: M.U.T.-III USB Cable
  - MB991910: M.U.T.-III Main Harness A



**STEP 1. Using scan tool MB991958, read the diagnostic trouble code.**

**⚠ CAUTION**

To prevent damage to scan tool MB991958, always turn the ignition switch to the "LOCK" (OFF) position before connecting or disconnecting scan tool MB991958.

- (1) Connect scan tool MB991958. Refer to "How to connect scan tool (M.U.T.-III) P.42B-9."
- (2) Turn the ignition switch to the "ON" position.
- (3) Check whether the power window main switch related DTC is set.
- (4) Turn the ignition switch to the "LOCK" (OFF) position.

**Q: Is the DTC set?**

**YES :** Diagnose the power window main switch. Refer to Diagnostic trouble code chart P.42A-64.

**NO :** Go to Step 2.

**STEP 2. Check the power window operating current.**

Check that the power window operating current is normal (Refer to P.42A-122).

**Q: Is the check result normal?**

**YES :** Door window glass adjustment (Refer to P.42A-120). Then go to Step 3.

**NO :** Replace the power window motor. Verify that the power window anti-trap function works normally.

**STEP 3. Confirm the power window learning function.**

Check that the power window switch has learned the fully closed position of the windows.

**Q: Is the check result normal?**

**YES :** Go to Step 4.

**NO :** Make the power window switch learn the fully closed position of the windows (Refer to P.42A-123). Verify that the power window anti-trap function works normally.

---

**STEP 4. Retest the system.**

Check that the power window anti-trap function works normally.

**Q: Is the check result normal?**

**YES** : No action is necessary and testing is complete.

**NO** : Replace the front power window motor (LH). Verify that the power window anti-trap function works normally.

---

**INSPECTION PROCEDURE 7: The Window Glass Lowers Automatically while it is Rising.**

---

**COMMENTS ON TROUBLE SYMPTOM**

If the sliding resistance is too great when the window is being raised or the window glass encounters an object, the window glass will lower by approximately 150 mm (5.9 inches).

**PROBABLE CAUSES**

- Improperly adjusted door window glass
- Incorrectly installed or warped glass slider
- Malfunction of the power window motor
- Malfunction of the window regulator

---

**DIAGNOSTIC PROCEDURE**

---

**STEP 1. Determine a trouble spot.****Q: Which type of the power window is installed on vehicle?**

**Driver's side seat** : Go to Step 2.

**Except driver's side seat** : Go to Step 3..

---

**STEP 2. Check the power window anti-trap function.**

Check that the power window anti-trap function works. Refer to [P.42A-122](#).

**Q: Is the check result normal?**

**YES** : Go to Step 3.

**NO** : Refer to inspection procedure 6 "Power window anti-trap function does not work normally [P.42A-107](#)."

---

**STEP 3. Check that the door window glasses are installed correctly.**

Check that the door window glasses are installed correctly. Refer to [P.42A-120](#).

**Q: Is the check result normal?**

**YES** : Go to Step 4.

**NO** : Adjust the door window glass (Refer to [P.42A-120](#)).

---

**STEP 4. Retest the system.**

Check that the power window does not lower while it is being raised.

**Q: Is the check result normal?**

**YES** : No action is necessary and testing is complete.

**NO** : Replace the power window motor of the defective window.


## CHECK AT ECU TERMINAL

M1429013600380

## POWER WINDOW SWITCH TERMINAL CHECK

## POWER WINDOW MAIN SWITCH

E-15



AC609433AD

Terminal No.	Check items	Check conditions	Normal conditions
1	Output to power window motor (Passenger's side)	–	–
2	Output to power window motor (Driver's side)	–	–
3	Output to power window motor (Passenger's side)	–	–
4	Power supply	Power window relay: ON	Battery positive voltage
5	Power supply	Always	Battery positive voltage
6	Output to power window motor (Driver's side)	–	–
7	LIN communication line (between ETACS-ECUs)	Always	0 to 12 V (pulse signal)
8	Input from power window motor (pulse sensor signal)	When the power windows are operating	0 to 5 V (pulse signal)
9	Input from power window motor (pulse sensor ground)	–	1 V or less
10	Ground	Always	1 V or less
11	Input from power window motor (pulse sensor signal)	When the power windows are operating	0 to 5 V (pulse signal)
12	Input from power window motor (power supply to pulse sensor)	When the power windows are operating	5 V
13	–	–	–
14	–	–	–
15	Output to power window motor (Rear right side)	–	–
16	–	–	–
17	Output to power window motor (Rear right side)	–	–
18	Output to power window motor (Rear left side)	–	–
19	Output to power window motor (Rear left side)	–	–

## DOOR DIAGNOSIS

### INTRODUCTION TO GLASS AND DOOR DIAGNOSIS

M1423007300285

Glass and door faults include water leaks and improper opening and closing. Causes for these faults can include faults in the glass, weatherstrip, drain hole, waterproof film or door installation.

### GLASS AND DOOR DIAGNOSTIC TROUBLESHOOTING STRATEGY

M1423006700343

Use these steps to plan your diagnostic strategy. If you follow them carefully, you will be sure that you have exhausted most of the possible ways to find a glass and door fault.

1. Gather information from the customer.

2. Verify that the condition described by the customer exists.
3. Find the malfunction by following the Symptom Chart.
4. Verify malfunction is eliminated.

### SYMPTOM CHART

M1423007000400

Symptom	Inspection procedure	Reference page
Water leak through door window glass	1	<a href="#">P.42A-111</a>
Door window glass malfunction	2	<a href="#">P.42A-112</a>
Water leak through door edge	3	<a href="#">P.42A-112</a>
Water leak from door center	4	<a href="#">P.42A-112</a>
Door hard to open	5	<a href="#">P.42A-113</a>
Door does not open or close completely	6	<a href="#">P.42A-113</a>
Uneven gap between body	7	<a href="#">P.42A-113</a>
Wind noise around door	8	<a href="#">P.42A-114</a>

### SYMPTOM PROCEDURES

#### INSPECTION PROCEDURE 1: Water Leak Through Door Window Glass

##### DIAGNOSIS

**STEP 1. Check the door window glass installation.**

**Q: Is the door window glass installed correctly?**

**YES :** Go to Step 2.

**NO :** Assemble the door window glass again. Refer to [P.42A-128](#). Then go to Step 3.

**STEP 2. Check the clearance at the top of the door window glass.**

**Q: Is the clearance at the top of the door window glass correct?**

**YES :** Go to Step 3.

**NO :** Adjust the door window glass. Refer to [P.42A-120](#). Then go to Step 3.

**STEP 3. Retest the system.**

**Q: Is any water leaking?**

**YES :** Return to Step 1.

**NO :** The procedure is complete.

---

**INSPECTION PROCEDURE 2: Door Window Glass Malfunction**

---

**DIAGNOSIS**

---

**STEP 1. Check the door window glass installation condition.****Q: Is the door window glass installed correctly?****YES :** Go to Step 2.**NO :** Assemble the door window glass again.  
(Refer to [P.42A-131.](#)) Then go to Step 4.

---

**STEP 2. Check the door sash.****Q: Is the door sash in good condition?****YES :** Go to Step 3.**NO :** Repair or replace the door sash, then go to Step 4.

---

**STEP 3. Inspect the window regulator assembly.****Q: Is the window regulator assembly in good condition?****YES :** Go to Step 4.**NO :** Repair or replace the window regulator assembly, then go to Step 4.

---

**STEP 4. Retest the system.****Q: Does the door window glass operate correctly?****YES :** The procedure is complete.**NO :** Return to Step 1.

---

**INSPECTION PROCEDURE 3: Water Leak Through Door Edge**

---

**DIAGNOSIS**

---

**STEP 1. Check the weatherstrip.****Q: Is the weatherstrip in good condition?****YES :** Go to Step 2.**NO :** Replace the weatherstrip, then go to Step 3.

---

**STEP 2. Check the door fit (alignment).****Q: Is the door fit (alignment) correct?****YES :** Go to Step 3.**NO :** Adjust the door fit. Refer to [P.42A-118.](#)  
Then go to Step 3.

---

**STEP 3. Retest the system.****Q: Is any water leaking?****YES :** Return to Step 1.**NO :** The procedure is complete.

---

**INSPECTION PROCEDURE 4: Water Leak from Door Center**

---

**DIAGNOSIS**

---

**STEP 1. Check the drain hole.****Q: Is the drain hole clogged?****YES :** Clean the drain hole, then go to Step 3.**NO :** Go to Step 2.

---

**STEP 2. Check the weatherstrip.****Q: Is the weatherstrip in good condition?****YES :** Go to Step 3.**NO :** Repair or replace the weatherstrip, then go to Step 3.

---

**STEP 3. Retest the system.****Q: Is any water leaking?****YES :** Return to Step 1.**NO :** The procedure is complete.

**INSPECTION PROCEDURE 5: Door Hard to Open**

**DIAGNOSIS**

**STEP 1. Adjust the latch and striker engagement.**  
Refer to [P.42A-118](#).

**Q: Is the latch and striker engagement adjusted?**  
**YES :** Go to Step 2.  
**NO :** Adjust the latch and striker. Refer to [P.42A-118](#). Then go to Step 4.

**STEP 2. Check for lock rod damage.**

**Q: Is the lock rod damaged?**  
**YES :** Repair or replace the lock rod, then go to Step 4.  
**NO :** Go to Step 3.

**STEP 3. Check the door handle flexibility (amount of movement of handle required to open door).**

**Q: Is the door handle flexibility good?**  
**YES :** Go to Step 4.  
**NO :** Adjust the door handle. Refer to [P.42A-125](#) and [P.42A-125](#). Then go to Step 4.

**STEP 4. Retest the system.**

**Q: Does the door open easily?**  
**YES :** The procedure is complete.  
**NO :** Return to Step 1.

**INSPECTION PROCEDURE 6: Door does not Open or Close Completely**

**DIAGNOSIS**

**STEP 1. Check the door hinge position.**

**Q: Is the door hinge correct?**  
**YES :** Go to Step 2.  
**NO :** Adjust the door hinge. Refer to [P.42A-118](#). Then go to Step 4.

**STEP 2. Check the door.**

**Q: Is the door in good condition?**  
**YES :** Go to Step 3.  
**NO :** Repair or replace door, then go to Step 4.

**STEP 3. Check the grease.**

**Q: Is the door check or door hinge grease sufficient?**  
**YES :** Go to Step 4.  
**NO :** Apply the grease, then go to Step 4.

**STEP 4. Retest the system.**

**Q: Does the door open and close correctly?**  
**YES :** The procedure is complete.  
**NO :** Return to Step 1.

**INSPECTION PROCEDURE 7: Uneven Gap Between Body**


**DIAGNOSIS**

Adjust the door fit. Refer to [P.42A-118](#). Then check that the gap has been improved.


**INSPECTION PROCEDURE 8: Wind Noise Around Door****DIAGNOSIS****STEP 1. Check the weatherstrip for holding condition.****Q: Is the weatherstrip holding firmly?****YES :** Go to Step 2.**NO :** Adjust fit of door. Refer to [P.42A-121](#). Then go to Step 5.**STEP 2. Check the weatherstrip for installation condition.****Q: Is the weatherstrip for installed properly?****YES :** Go to Step 3.**NO :** Repair or replace the weatherstrip. Then go to Step 5.**STEP 3. Check the clearance.****Q: Are the door glass and the door weatherstrip holder assembled correctly?****YES :** Go to Step 4.**NO :** Adjust the door glass and the door weatherstrip. Refer to [P.42A-121](#). Then go to Step 5.**STEP 4. Check the door.****Q: Is the door deformed?****YES :** Repair or replace the door. then go to Step 5.**NO :** Go to Step 5.**STEP 5. Retest the system.****Q: Has the wind noise been improved?****YES :** Return to Step 1.**NO :** This diagnosis complete.**HOW TO LOCATE WIND NOISE**

M1421004200294

1. Attach cloth tape to every place, such as panel seams, projections, molding seams, glass and body seams, etc. which might conceivably be the source of wind noise.
2. Then make a road test to check that the places not covered by tape are not sources of wind noise.




AC708683




AC708683


3. Remove the strips of tape one by one, making a road test after each is removed, until a wind noise source is discovered.



4. When such a place is found, cover it again and repeat the procedure to check if there are any other noise source.
5. If no others are found, the last remaining tape is the only source.








6. Cut the remaining piece of tape into smaller pieces, attach it again as it was before, and then remove the pieces one by one to narrow down the source.












7. Check that wind noise occurs when the last remaining tape is removed, and that noise does not occur when it is re-attached.
8. When the source(s) of the wind noise is finally located, attach butyl tape, body sealer or similar material to obstruct this source as much as possible.

SPECIAL TOOLS

M1423000601103

Tool	Tool number and name	Supersession	Application
 <p>MB990480</p>	<p>MB990480 Glass holder</p>	<p>General service tool</p>	<p>Removal of power window regulator assembly</p>
 <p>MB990900</p>	<p>MB990900 or MB991164 Door adjusting wrench</p>	<p>MB990900-01</p>	<p>Adjustment of door fit</p>
 <p>MB990925AI</p>	<p>MB990925 Bearing and oil seal installer set a: MB990939 Remover bar</p>	<p>MB990925-01 or General service tool</p>	<p>Adjustment of door striker</p>
 <p>MB990211</p>	<p>MB990211 Slider hammer</p>	<p>MB990211-01</p>	
 <p>MB990241AI</p>	<p>MB990241 Axle shaft puller a: MB990243 Body puller</p>	<p>MB990241-01 or General service tool</p>	

Tool	Tool number and name	Supersession	Application
<p><b>a</b></p>  <p>MB991824</p> <p><b>b</b></p>  <p>MB991827</p> <p><b>c</b></p>  <p>MB991910</p> <p><b>d</b></p>  <p>MB991911</p> <p><b>e</b></p>  <p>MB991914</p> <p><b>f</b></p>  <p>MB991825</p> <p><b>g</b></p>  <p>MB991826 MB991958</p>	<p>MB991958</p> <p>a: MB991824 b: MB991827 c: MB991910 d: MB991911 e: MB991914 f: MB991825 g: MB991826</p> <p>Scan tool (M.U.T.-III sub assembly)</p> <p>a: Vehicle communication interface (V.C.I.) b: M.U.T.-III USB cable c: M.U.T.-III main harness A (Vehicles with CAN communication system) d: M.U.T.-III main harness B (Vehicles without CAN communication system) e: M.U.T.-III main harness C (for Daimler Chrysler models only) f: M.U.T.-III measurement adapter g: M.U.T.-III trigger harness</p>	<p>MB991824-KIT</p> <p><i>NOTE: G: MB991826 M.U.T.-III Trigger Harness is not necessary when pushing V.C.I. ENTER key.</i></p>	<p><b>⚠ CAUTION</b></p> <p><b>For vehicles with CAN communication, use M.U.T.-III main harness A to send simulated vehicle speed. If you connect M.U.T.-III main harness B instead, the CAN communication does not function correctly.</b></p> <p>Communication line check (ECU check and service data)</p>

Tool	Tool number and name	Supersession	Application
	MB991223 Harness set a: MB991219 Test harness b: MB991220 LED harness c: MB991221 LED harness adapter d: MB991222 Probe	General service tools	Making voltage and resistance measurement during troubleshooting a: Connector pin contact pressure inspection b: Power circuit inspection c: Power circuit inspection d: Commercial tester connection
	MB992006 Extra fine probe	-	Making voltage and resistance measurement during troubleshooting

## ON-VEHICLE SERVICE

### DOOR FIT ADJUSTMENT


M1423001100476

#### Required Special Tools:


- MB990211: Slide Hammer
- MB990243: Body Puller
- MB990900 or MB991164: Door Adjusting Wrench
- MB990939: Brass Bar

#### CAUTION

- **Do not rotate special tool MB991164 with a torque of over 98 N·m (72 ft-lb).**
1. When the clearance between the door and the body is uneven
    - (1) Apply protective tape to the fender around the hinge installation position and door edge.
    - (2) Remove the splash shield front <Front door only> (Refer to GROUP 42A, Splash Shield [P.42A-12](#)).
    - (3) Remove the center pillar trim, lower <Rear door only> (Refer to GROUP 52A, Interior Trim [P.52A-12](#)).




- (4) Use special tool MB990900 or MB991164 to loosen the hinge mounting bolts on the body side, and then adjust the clearance around the door so that it is uniform on all sides.
- (5) Move the door to adjust until the clearance around the door is even.



2. When the door is not flush with the vehicle body surface.


- (1) Loosen the door-side hinge mounting bolts.

*NOTE: The non-adjusting bolts have been installed as a factory setting. To adjust the levelling of the door, replace them with the adjusting bolts (MU001031).*



- (2) Move the door to adjust so that the door is flush with the vehicle body.
- (3) Tighten the door-side door hinge mounting bolt to the specified torque.


**Tightening torque: 26 ± 6 N· m (19 ± 5 ft-lb)**



3. If the door is stiff to lock and unlock:

- (1) Adjustment using the striker (toward the inside of the vehicle and vertical direction)

Install a temporary bolt instead of the striker mounting bolt, and use special tool MB990939 and a hammer to tap the bolt in the desired direction.




- (2) Adjustment by using the striker (toward the outside of the vehicle)


Use special tools MB990211 and MB990243 to pull the striker toward the outside of the vehicle.

## DOOR WINDOW GLASS ADJUSTMENT

M1423001000714

Check that the door glass operates smoothly and moves along the door glass run channel when the door window glass is fully raised and fully lowered. If there is a problem, adjust by the following procedure.





1. Remove the door trim assembly (Refer to GROUP 52A – Door Trim [P.52A-16](#)).
2. Remove the waterproof film (Refer to [P.42A-142](#)).
3. Remove the grommet from the adjusting hole <Vehicles with 9 speakers (Rockford Fosgate ® premium sound system)>.
4. Remove the power window switch from the removed door trim, and connect it to the connector, then set the channel guide mounting bolt to the adjusting hole. (Refer to [P.42A-131](#)).
5. Raise the door window glass and loosen the channel guide mounting bolts to adjust tilting up/down of the glass.

### **POWER WINDOW CHECK**

M1429004400656

Check the power window as described below. If it does not work, perform troubleshooting (Refer to [P.42A-64](#)).

- Turn off the power window lock switch of the power window main switch, and operate each of the power window switches to check that each power window operates.
- Turn on the power window lock switch of the power window main switch, and operate the front and rear passenger's power window sub switches to check that the power windows do not work.
- Turn on the power window lock switch of the power window main switch, and operate the power window main switch to check that each power window operates.


*NOTE: The power window lock switch function can be adjusted with the customization feature, confirm it before check (Refer to [P.42A-127](#)).*

### **GLASS SLIDING MECHANISM CHECK AND ADJUSTMENT**

M1429000900411

If the door window glass wrongly, automatically lowers while being raised, adjust or replace as follows:


1. Remove the door trim assembly (Refer to GROUP 52A, Door Trim [P.52A-16](#)).
2. Remove waterproof film (Refer to [P.42A-142](#)).
3. Remove the window regulator assembly from the door window glass, and then raise and lower the door window glass by hand to check the operation force.



4. If the door window glass does not move up and down smoothly, check and repair as follows:
  - Check the installation condition of the runchannel.
  - Straighten twist in the door sash.
  - Check the installation condition of the lower sash.
5. If repair or adjustment is impossible, replace the door assembly.

## POWER WINDOW SAFETY MECHANISM CHECK <DRIVER'S SIDE ONLY>

M1429013700031



1. Place an approximately 10 mm (0.39 inch) thick wood chip as shown. Then, raise the window glass.
2. Check that the window lowers by about 150 mm (5.9 inches) when the window clamps the board. If this doesn't happen, do troubleshooting. Refer to [P.42A-64](#).

*NOTE: If the anti-trap function (safety mechanism) is activated consecutively three times or more, carry out the learning procedures of the power window fully closed position (Refer to [P.42A-123](#)).*

## POWER WINDOW TIMER FUNCTION CHECK


M1429004300585

Check the power window timer as described below. If it does not work, perform troubleshooting (Refer to [P.42A-64](#)).

- Close the door and turn the ignition switch to the LOCK (OFF) position, and then check that the power windows operate for 30 seconds.
- Close the door and turn the ignition switch to the LOCK (OFF) position. While the timer is on, open the driver's door or front passenger's door, and check that the timer is cancelled.

## POWER WINDOW OPERATING CURRENT CHECK

M1429001100601



1. Remove the power window fuse, and connect a multimeter as shown in the illustration.
2. Raise the power window to measure the current during operation.

**Standard value (A): 7 A or less [Power supply voltage  $14.5 \pm 0.5V$ ,  $25^\circ C$  ( $77^\circ F$ )]**

*NOTE: If the power supply voltage does not meet the standard value, check and repair the generator and the battery. Then carry out this check again.*

3. If the operation current is outside the standard value, refer to [P.42A-64](#).

## LEARNING PROCEDURES OF THE POWER WINDOW FULLY CLOSED POSITION <DRIVER'S SIDE ONLY>

M1429004600218

## LEARNING PROCEDURES OF THE FULLY CLOSED POSITION WHEN THE POWER WINDOW SWITCH IS REMOVED, OR THE POWER WINDOW REGULATOR ASSEMBLY IS REMOVED OR REPLACED

1. If the anti-trap function (safety mechanism) is activated consecutively three times or more, the fully closed position that the power window switch has learned will be erased (initialized).
2. Operate the power window switch and fully open the door window glass.

### CAUTION

**The anti-trap function will not activated until the learning procedures of the fully closed position have been completed (because the anti-trap function was reset).**

3. Operate the power window switch and fully close the door window glass. The power window activates for 0.7 seconds and stops automatically when the power window switch is pressed once. Repeat this operation until the door window glass fully closes and release the switch once. Then, hold the power window switch to the fully closed side again for one second so that the power window switch completes learning the fully closed position.

*NOTE: If the power window switch is operated to open the door window glass while the switch is learning, the learning will be cancelled. If this happens, return to step 2.*

## LEARNING PROCEDURES WHEN THE POWER WINDOW SWITCH IS REPLACED WITH A NEW ONE

### CAUTION

**The anti-trap function will not activated until the learning procedures of the fully closed position have been completed (because the anti-trap function was reset).**

Operate the power window switch to fully close the door window glass by one-shot up action so that the power window switch will complete learning (no initialization is required).

**CENTRAL DOOR LOCKING SYSTEM CHECK**

M1427001100553

- Check that the central door locking system works by operating the door lock switch. If it does not operate, perform troubleshooting. Refer to [P.42A-30](#).

*NOTE: When the inside lock knob is operated with the driver's door opened, the driver's door is not locked.*

- Check whether the driver's door is opened when the driver's door inside handle is pulled with all the doors locked. If it does not operate, replace the driver's door latch assembly. Refer to [P.42A-136](#).

**CHECK OF KEY LOCK PREVENTION FUNCTION**

M1427003300285

Check that the driver's door is not locked when the driver's door inside lock knob is operated with the driver's door opened. If it is locked, replace the door latch. Refer to [P.42A-136](#).

**SHIFT "P" INTERLINK DOOR UNLOCK FUNCTION CHECK <TC-SST>**

M1427003400237

When the selector is moved to the P (parking) position with the ignition switch on, all the doors will be unlocked. Carry out troubleshooting if the door is unlocked. Refer to [P.42A-30](#).

*NOTE: The selector "P" position-linked door unlocking function can be switched with the customization function. Confirm it before check. Refer to [P.42A-127](#).*

**IGNITION "LOCK (OFF)" POSITION-LINKED DOOR UNLOCKING FUNCTION CHECK <M/T, TC-SST>**

M1427006200083

When the ignition switch is moved to the LOCK (OFF) position, all the doors will be unlocked. Carry out the troubleshooting if a door does not operate. Refer to [P.42A-61](#).

*NOTE: The ignition "LOCK" position-linked door unlocking function can be switched with the customization function. Confirm it before check. Refer to [P.42A-127](#).*


**DOOR OUTSIDE HANDLE PLAY CHECK**

M1423001600590

1. Check that the door outside handle assembly play meets the standard value.

**Standard value (B): 0.3 –5.0 mm (0.01 –0.2 inch) [Target value: 2.4 mm (0.09 inch)]**

2. Check the door outside handle assembly and door latch assembly, and replace them if they are out of the standard value.



**DOOR INSIDE HANDLE CHECK**

M1423001500667

**DOOR INSIDE HANDLE KNOB PLAY CHECK**


1. Check that the door inside handle knob play meets the standard value.

**Standard value (B):**

**Front driver's side: 10.0 –23.7 mm (0.39 –0.93 inch) [Target value: 17.0 mm (0.67 inch)]**

**Except Front driver's side: 5.0 –18.7 mm (0.2 –0.74 inch) [Target value: 12.0 mm (0.47 inch)]**



2. Check the door inside handle and door latch assembly, and replace them if they are out of the standard value.



**DOOR INSIDE HANDLE LOCK KNOB STROKE CHECK**

1. Remove the door trim assembly (Refer to GROUP 52A – Door Trim P.52A-16).
2. Check that the stroke of the door inside handle lock knob meets the standard value.

**Standard value (B): 13.7 –15.0 mm (0.54 –0.59 inch)**  
**[Target value: 14.7 mm (0.58 inch)]**



3. If it is outside the standard value, adjust the stroke of the inside handle lock knob by using the outer cable end, which connects the inside handle lock knob to the inside lock cable.

**CUSTOMIZATION FUNCTION**

M1429007800523

By operating the ETACS system or MMCS of scan tool MB991958, the following functions can be programmed. The programmed information is held even when the battery is disconnected.

Adjustment item (scan tool MB991958 M.U.T.-III display)	Adjustment item	Adjusting contents (scan tool MB991958 display)	Adjusting contents
Auto door unlock	Adjustment of the auto door unlock function	Disabled	Without function (initial condition) <M/T, TC-SST>
		Always (P pos)	With function: Operates when the shift lever or the selector lever is moved to the P position. <TC-SST>
		P/W unlock (P)	With function: Operates when the shift lever or the selector lever is moved to the P position with the power window lock switch in the OFF position. <TC-SST>
		Always(Lock pos)	With function: Operates when the ignition switch is moved to the LOCK (OFF) position. <M/T, TC-SST>
		P/W unlock(Lock)	With function: Operates when the ignition switch is turned to the LOCK (OFF) position with the power window lock switch in the OFF position. <M/T, TC-SST>


**DOOR ASSEMBLY  
REMOVAL AND INSTALLATION**

M1423002200885

**Post-installation Operation**

- Door Fit Adjustment (Refer to [P.42A-118](#)).

<Front door>



**Front door assembly removal steps**

- Cowl side trim (Refer to GROUP 52A, Trim [P.52A-12.](#))
  - Bottom cover assembly <Passenger's side> (Refer to GROUP 52A, Glove Box [P.52A-7.](#))
1. Wiring harness connector connection
  2. Door check connecting bolt
  3. Front door assembly

>>A<<

**Front door hinge removal steps**

3. Front door assembly
4. Fender protector rear
5. Front door upper hinge
6. Front door lower hinge

**Striker removal steps**

7. Striker


**Damper removal**

8. Damper

**Door switch removal steps**

- Center pillar trim lower (Refer to GROUP 52A - Interior Trim [P.52A-12.](#))
9. Door switch

<Rear door>



AC607388AC

**Rear door assembly removal steps**

1. Wiring harness connector connection
2. Door check connecting bolt
3. Rear door assembly

**Rear door hinge removal steps**

- Center pillar trim lower (Refer to GROUP 52A, Trim [P.52A-12.](#))
- 3. Rear door assembly

**Rear door hinge removal steps**

4. Rear door upper hinge
5. Rear door lower hinge

**Striker removal**

6. Striker

**Damper removal**

7. Damper

**Door switch removal**


8. Door switch

>>A<<

**INSTALLATION SERVICE POINT**

**>>A<< STRIKER INSTALLATION**


Align the center of the striker and latch within  $\pm 1.5$  mm (0.06 inch), and install.



**INSPECTION**

M1423006000731

**DOOR SWITCH CHECK**




Switch position	Terminal number	Normal value
Release (ON)	1 – Ground, 2 – Ground, 3 – Ground	Continuity exists (2 $\Omega$ or less)
Depressed (OFF)	1 – Ground, 2 – Ground, 3 – Ground	Open circuit

**DOOR GLASS AND REGULATOR  
REMOVAL AND INSTALLATION**

M1429001301385

<p><b>Pre-removal operation</b></p> <ul style="list-style-type: none"> <li>• Door trim assembly removal (Refer to GROUP 52A, Door Trim P.52A-16).</li> <li>• Waterproof film removal (Refer to P.42A-142).</li> </ul>	<p><b>Post-installation operation</b></p> <ul style="list-style-type: none"> <li>• Door window glass adjustment (Refer to P.42A-120.)</li> <li>• Waterproof film installation (Refer to P.42A-142).</li> <li>• Door trim assembly installation (Refer to GROUP 52A, Door Trim P.52A-16).</li> <li>• Learning procedures of the power window fully closed position &lt;Driver's side only&gt; (Refer to P.42A-123.)</li> </ul>
---	---

<Front door>



AC609369AI

**Door window glass assembly removal steps**

1. Door window glass runchannel
  - Door mirror assembly (Refer to GROUP 51, Door Mirror P.51-97.)
2. Door beltline weatherstrip inner
3. Door beltline molding
4. Door speaker bracket
5. Grommet
6. Door window glass assembly

**Power window regulator assembly removal steps**


4. Door speaker bracket
5. Grommet
7. Power window regulator assembly
8. Power window motor

<<A>>

**Required Special Tool:**

- MB990480: Window Glass Holder

<Rear door>



AC609370AJ

**Door window glass assembly and stationary window glass removal steps**

**Power window regulator assembly removal steps**

1. Door window glass runchannel
2. Door beltline weatherstrip inner
3. Grommet
4. Door window glass assembly
5. Door center sash
6. Stationary window weatherstrip
7. Stationary window glass

3. Grommet
8. Power window regulator assembly
9. Power window motor


<<A>>

**Required Special Tool:**

- MB990480: Window Glass Holder

<<B>>

<Rear door>




7

**Power window switch <Front door> removal step**

1. Front upper pad energy absorption
2. Front door ornament
3. Front door trim upper
4. Power window switch panel assembly

<Front door>



3

1

2

5

6

AC607392AC

**Power window switch <Front door> removal step (Continued)**

5. Power window switch panel
  6. Power window main switch <Driver's side>, power window sub switch <Front passenger's side>
- Power window sub switch <Rear door> removal step**
7. Power window sub switch

**REMOVAL SERVICE POINTS**


**<<A>> POWER WINDOW REGULATOR REMOVAL**

1. Remove the door window glass installation bolts.

**⚠ CAUTION**


If tinting film is adhered to the door window glass, attach special tool MB990480 to the outside of the glass to prevent the film from peeling off.

2. Lift the door window glass, and attach special tool MB990480 to the glass as shown to prevent the glass from falling.
3. Remove the power window regulator.



**<<B>> DOOR CENTER SASH REMOVAL**

1. Remove the door outer opening weatherstrip from the door center sash only.
2. Remove the door center sash mounting screws, and then remove the door center sash from the door panel.




**INSPECTION**

M1429001400914

**POWER WINDOW SWITCH CONTINUITY CHECK**


**SUB SWITCH**



Switch position	Tester connection	Specified condition
UP	4 -5, 6 -7	Continuity exists (2 Ω or less)
OFF	4 -5, 7 -8	Continuity exists (2 Ω or less)
DOWN	4 -6, 7 -8	Continuity exists (2 Ω or less)


**DOOR WINDOW REGULATOR CHECK**

1. Connect a battery directly to the motor terminals and check that the motor runs smoothly.
2. Check that the motor runs in the opposite direction when the battery is connected with the polarity reversed.
3. If a defect is found, replace the window regulator as an assembly.



**FRONT DOOR (PASSENGER'S SIDE)**

Battery connection	Slider position
<ul style="list-style-type: none"> <li>• Connect terminal No. 1 to the negative battery terminal.</li> <li>• Connect terminal No. 4 to the positive battery terminal.</li> </ul>	UP
<ul style="list-style-type: none"> <li>• Connect terminal No. 4 to the negative battery terminal.</li> <li>• Connect terminal No. 1 to the positive battery terminal.</li> </ul>	DOWN



**REAR DOOR**

Battery connection	Slider position
<ul style="list-style-type: none"> <li>• Connect terminal No. 4 to the negative battery terminal.</li> <li>• Connect terminal No. 1 to the positive battery terminal.</li> </ul>	UP
<ul style="list-style-type: none"> <li>• Connect terminal No. 1 to the negative battery terminal.</li> <li>• Connect terminal No. 4 to the positive battery terminal.</li> </ul>	DOWN

**DOOR HANDLE AND LATCH  
REMOVAL AND INSTALLATION**


M1423004601439

**CAUTION**



When the door lock cylinder of the vehicle with WCM is replaced as a full service key set, the key must be registered with the barcode No. attached to the ignition key. (Refer to GROUP 42C, ID Code Registration Criteria Table P.42C-9.)

Pre-removal operation	Post-installation operation
<ul style="list-style-type: none"> <li>Door trim assembly removal (Refer to GROUP 52A, Door Trim P.52A-16).</li> <li>Waterproof film removal (Refer to P.42A-142).</li> </ul>	<ul style="list-style-type: none"> <li>Door inside handle play check (Refer to P.42A-125).</li> <li>Door outside handle play check (Refer to P.42A-125).</li> <li>Waterproof film installation (Refer to P.42A-142).</li> <li>Door trim assembly installation (Refer to GROUP 52A, Door Trim P.52A-16).</li> </ul>

<Front door>



AC711102AC



AC605594 AH

**Door inside handle removal steps**

- >>B<< 1. Door inside handle  
2. Clip  
3. Grommet

**Door outside handle removal steps**

- <<A>> >>C<< 4. Plug  
5. Door outside handle cover assembly <Driver's side>  
6. Door lock key cylinder <Driver's side>  
7. Door outside handle cover  
8. Door outside handle  
9. Door outside handle gasket  
10. Door outside handle base  
11. Clip


**Door latch assembly removal steps**

- >>B<< 1. Door inside handle  
12. Door speaker bracket  
13. Rear lower sash  
14. Screw  
15. Door latch assembly  
16. Door inside lock cable  
17. Door inside handle cable  
18. Door outside handle rod  
19. Door outside lock rod <Driver's side>  
20. Door panel bracket <Driver's side>  
21. Clip



**Door check removal steps**

- Front door speaker (Refer to GROUP 54A, Speaker P.54A-638.)
- >>A<< 22. Door check

<Rear door>



AC711190AB



AC605594AF

**Door inside handle removal steps**

- >>B<< 1. Door inside handle  
2. Clip  
3. Grommet

**Door outside handle removal steps**

- <<A>> >>C<< 4. Plug  
5. Door outside handle cover  
6. Door outside handle  
7. Door outside handle gasket  
8. Door outside handle base  
9. Clip

**Door latch assembly removal steps**

- >>B<< 1. Door inside handle  
10. Screw  
11. Door latch assembly  
12. Door inside lock cable  
13. Door inside handle cable  
14. Door outside handle rod  
15. Clip

**Door check removal steps**

- Rear door speaker (Refer to GROUP 54A, Speaker P.54A-638.)

- >>A<< 16. Door check


**Required Special Tool:**

- T-type Long Torx Wrench (T30)

**REMOVAL SERVICE POINT**

**<<A>> DOOR OUTSIDE HANDLE COVER  
REMOVAL**


Prepare a tool as shown to remove the door outside handle cover.



**INSTALLATION SERVICE POINTS**

**>>A<< DOOR CHECK INSTALLATION**

Install the door check with the following identification marks facing upward.



Applicable location		Identification mark
Front door	Left door	55L
	Right door	55R
Rear door	Left door	64L
	Right door	64R


**>>B<< DOOR INSIDE HANDLE INSTALLATION**

When connecting the inside cable to the door inside handle, ensure that the door latch and the inside handle are locked.

**>>C<< DOOR OUTSIDE HANDLE BASE  
INSTALLATION**

Prepare a tool as shown, and tighten it to the specified torque.


**Tightening torque: 4.0 ± 2.0 N·m (35 ± 17 in-lb)**



**INSPECTION**

**FRONT DOOR LOCK ACTUATOR CHECK**

**ACTUATOR OPERATION CHECK**



Lever position	Battery connection	Lever operation
At the "LOCK" position	<ul style="list-style-type: none"> <li>Connect terminal No.4 to the negative battery terminal.</li> <li>Connect terminal No.6 to the positive battery terminal.</li> </ul>	The lever moves from the "LOCK" position to the "UNLOCK" position.
At the "UNLOCK" position	<ul style="list-style-type: none"> <li>Connect terminal No.6 to the negative battery terminal.</li> <li>Connect terminal No.4 to the positive battery terminal.</li> </ul>	The lever moves from the "UNLOCK" position to the "LOCK" position.


**ACTUATOR SWITCH CHECK <DRIVER'S SIDE>**

Lever position	Terminal number	Normal value
UNLOCK	1 -3	Continuity exists (2 Ω or less)

**ACTUATOR SWITCH CHECK <PASSENGER'S SIDE (VEHICLES WITH KOS)>**

Lever position	Terminal number	Normal value
UNLOCK	1 -3	Continuity exists (2 Ω or less)

**REAR DOOR LOCK ACTUATOR CHECK**  
**ACTUATOR OPERATION CHECK**




Lever position	Battery connection	Lever operation
At the "LOCK" position	<ul style="list-style-type: none"> <li>Connect terminal No.4 to the negative battery terminal.</li> <li>Connect terminal No.6 to the positive battery terminal.</li> </ul>	The lever moves from the "LOCK" position to the "UNLOCK" position.
At the "UNLOCK" position	<ul style="list-style-type: none"> <li>Connect terminal No.6 to the negative battery terminal.</li> <li>Connect terminal No.4 to the positive battery terminal.</li> </ul>	The lever moves from the "UNLOCK" position to the "LOCK" position.

**CENTRAL DOOR LOCK SWITCH CONTINUITY CHECK**


Remove the power window switch (Refer to P.42A-131).

**<DRIVER'S SIDE>**




Switch position	Tester connection	Specified condition
LOCK	14 -Ground	Continuity exists (2 Ω or less)
UNLOCK	13 -Ground	Continuity exists (2 Ω or less)

**<PASSENGER'S SIDE>**



Switch position	Tester connection	Specified condition
LOCK	3 -4	Continuity exists (2 Ω or less)
UNLOCK	2 -4	Continuity exists (2 Ω or less)

**LOCK SWITCH CHECK <VEHICLE WITH  
KEYLESS OPERATION SYSTEM (KOS)>**




Switch position	Tester connection	Specified condition
ON	1 -2	Continuity exists (2 Ω or less)
OFF	1 -2	Open circuit


**WINDOW GLASS RUNCHANNEL AND DOOR OPENING WEATHERSTRIP  
REMOVAL AND INSTALLATION**

M1423003101390

<Front door>




AC804822AC




AC804824AB

- Door trim assembly (Refer to GROUP 52A, Door Trim P.52A-16.)
- >>B<< 1. Waterproof film
- >>C<< 2. Door window glass runchannel
- Door window glass runchannel removal**
- >>C<< 2. Door window glass runchannel
- Door beltline weatherstrip inner removal steps**
- Door trim assembly (Refer to GROUP 52A, Door Trim P.52A-16.)
- 3. Door beltline weatherstrip inner
- Door speaker cover removal steps <Vehicles with Rockford Fosgate premium sound system>**
- Door trim assembly (Refer to GROUP 52A, Door Trim P.52A-16.)
- >>B<< 1. Waterproof film
- 4. Door speaker cover
- Door beltline molding removal steps <GSR>**
- Door mirror assembly (Refer to GROUP 51, Door Mirror P.51-97.)
- 5. Door beltline molding
- Door beltline molding removal steps <MR>**
- Door mirror assembly (Refer to GROUP 51, Door Mirror P.51-97.)
- Door trim assembly (Refer to GROUP 52A, Door Trim P.52A-16.)
- >>B<< 1. Waterproof film
- 3. Door beltline weatherstrip inner
- <<A>>
- Door beltline molding removal steps <MR> (Continued)**
- 4. Door speaker cover <Vehicles with Rockford Fosgate premium sound system>
- 5. Door beltline molding
- Speaker bracket removal steps <Vehicles with Rockford Fosgate premium sound system>**
- Door trim assembly (Refer to GROUP 52A, Door Trim P.52A-16.)
- >>B<< 1. Waterproof film
- 6. Door speaker bracket
- Rear lower sash removal steps**
- Door trim assembly (Refer to GROUP 52A, Door Trim P.52A-16.)
- >>B<< 1. Waterproof film
- 6. Door speaker bracket <Vehicles with Rockford Fosgate premium sound system>
- 7. Rear lower sash
- Door opening weatherstrip inner removal steps**
- Cowl side trim and front scuff plate (Refer to GROUP 52A, Trim P.52A-12.)
- 8. Door opening weatherstrip inner
- Door opening weatherstrip outer removal steps**
- 9. Door check connecting bolt (Refer to P.42A-128.)
- <<C>> >>A<< 10. Door opening weatherstrip outer

<Rear door>



AC804823AB





Sealant: 3M™ AAD Part No.8633 or equivalent

AC804825AB



<<B>> DOOR BELTLINE MOLDING <REAR  
DOOR> REMOVAL

<Rear door>



AC802332AD


NOTE

- ← : Clip positions
- ▢ : Front of vehicle

1. Prize the clip of the door beltline molding using a flat-tipped screwdriver in the order of the numbers (from 1 to 4) shown in the figure. Lift the vehicle front side of the door beltline molding.


*NOTE: The flat-tipped screwdriver cannot be used at clips 5 and 6 of the door beltline molding shown in the figure.*

2. Lift the door beltline molding in the direction of the arrow in the figure, then remove the door beltline molding.



<<C>> DOOR OPENING WEATHERSTRIP OUTER  
REMOVAL

Make the tool as shown in the figure, and remove the weatherstrip from the door panel.



## INSTALLATION SERVICE POINTS

### >>A<< DOOR OPENING WEATHERSTRIP OUTER INSTALLATION

The clip color identifies the left and right weatherstrips so be sure to see the colors so as to install correctly.

Applicable side	Identification color
Left door	Yellow
Right door	Purple

### >>B<< WATERPROOF FILM INSTALLATION

#### CAUTION


When a waterproof film is applied, guide the butyl rubber tape under the inner panel drain hole.

Apply the specified adhesive to the waterproof film as shown in the figure and stick the film.

**Butyl rubber tape: 3M™ AAD Part number 8633 or equivalent**


### >>C<< DOOR WINDOW GLASS RUNCHANNEL INSTALLATION

Apply soapy water to the tip of the door window glass runchannel, and then install it to the door.



**PROTECTOR FILM <Vehicles without side air dam>  
REMOVAL AND INSTALLATION**

M1421007800206





AC705564AC

- >>A<<** 1. **Removal**  
Protector film



**INSTALLATION SERVICE POINT**

**>>A<< PROTECTOR FILM INSTALLATION**

Installation point



Install the protector film at the position 3.0 mm (0.12 in) away from the rear door end line.



AC705565AB

**CAUTION**

- The ambient temperature should be 20 to 38° C (68 – 100° F). Ensure that the working area is clean.
- If ambient temperature is less than 20° C (68° F), heat the protector film and application surface to a temperature of 20 to 30° C (68 – 86° F).
- Be careful that air bubbles are not formed under the protector film.

Installation procedure

1. Use 3M™ AAD Part number 8906 or equivalent to clean the protector film installation surfaces on the body.
2. Remove backing paper from the protector film, and apply the film to the specified position.
3. Remove the application film from the protector film surface.

**TRUNK LID****SPECIFICATIONS****SEALANT**

M1421000500378

Item	Specified sealant	Remark
Trunk lid hinge	3M™ AAD Part No. 8531 Heavy drip check sealer, 3M™ AAD Part No. 8646 Automotive joint and seam sealer or equivalent	Body sealer

**TRUNK LID DIAGNOSIS****INTRODUCTION TO TRUNK LID DIAGNOSIS**

M1421005800459

Difficult locking and unlocking, uneven clearance and height, and wind noise from the trunk lid may be caused by improper adjustment of the trunk lid.

**TRUNK LID DIAGNOSTIC TROUBLESHOOTING STRATEGY**

M1421005900401

Use these steps to plan your diagnostic strategy. If you follow them carefully, you will be sure that you have exhausted most of the possible ways to find a trunk lid fault.

1. Gather information from the customer.

2. Verify that the condition described by the customer exists.
3. Find the malfunction by following the Symptom Chart.
4. Verify malfunction is eliminated.

**TROUBLE SYMPTOM CHART**

M1421006000478

Symptom	Inspection procedure	Reference page
Difficult locking and unlocking	1	<a href="#">P.42A-150</a>
Uneven body clearance	2	<a href="#">P.42A-151</a>
Uneven height	3	<a href="#">P.42A-151</a>

**SYMPTOM PROCEDURES****INSPECTION PROCEDURE 1: Difficult Locking and Unlocking****DIAGNOSIS**

**STEP 1. Check the release cable routing condition.**

**Q: Is the release cable routing condition good?**

**YES :** Go to Step 3.

**NO :** Repair the release cable routing, then go to Step 2.

**STEP 2. Check the engagement of the trunk lid latch and trunk lid striker.**

**Q: Are the trunk lid latch and trunk lid striker engaged correctly?**

**YES :** Then go to Step 3.

**NO :** Adjust the trunk lid striker. Refer to [P.42A-152](#).

**STEP 3. Retest the system.**

**Q: Does the trunk lid lock operate easily?**

**YES :** The procedure is complete.

**NO :** Return to Step 1.

**INSPECTION PROCEDURE 2: Uneven Body Clearance**

**DIAGNOSIS**

**STEP 1. Check the clearance around the trunk lid..**

**Q: Are the apertures between the trunk lid and the adjacent body panels aligned correctly?**  
**YES :** Then go to Step 2.  
**NO :** Adjust the trunk lid panel assembly. Refer to [P.42A-152](#).

**STEP 2. Retest the system.**

**Q: Are the clearances between the body panels even?**  
**YES :** The procedure is complete.  
**NO :** Return to Step 1.

**INSPECTION PROCEDURE 3: Uneven Height**

**DIAGNOSIS**

**STEP 1. Check the trunk lid height.**



**Q: Is the trunk lid hinge height proper?**  
**YES :** Then go to Step 2.  
**NO :** Adjust the trunk lid hinge. Refer to [P.42A-152](#).

**STEP 2. Retest the system.**

**Q: Are the trunk lid and body height even?**  
**YES :** The procedure is complete.  
**NO :** Return to Step 1.

**SPECIAL TOOLS**

M1421000600546


Tool	Tool number and name	Supersession	Application
<p>a </p> <p>b </p> <p>c </p> <p>d  MB991223</p>	<p>MB991223 Harness set</p> <p>a: MB991219 Test harness</p> <p>b: MB991220 LED harness</p> <p>c: MB991221 LED harness adapter</p> <p>d: MB991222 Probe</p>	<p>General service tools</p>	<p>Making voltage and resistance measurement during troubleshooting</p> <p>a: Connector pin contact pressure inspection</p> <p>b: Power circuit inspection</p> <p>c: Power circuit inspection</p> <p>d: Commercial tester connection</p>
<p> MB992006</p>	<p>MB992006 Extra fine probe</p>	<p>-</p>	<p>Making voltage and resistance measurement during troubleshooting</p>

## ON-VEHICLE SERVICE

## ADJUSTMENT OF CLEARANCE AROUND TRUNK LID

M1421008100062


Loosen the trunk lid panel assembly mounting bolts and move the trunk lid panel assembly to make the clearance around the trunk lid uniform.



## TRUNK LID STRIKER ADJUSTMENT

M1421008200058

After checking the trunk lid release cable for proper routing, loosen the trunk lid striker mounting bolts. Change the position of the trunk lid striker relative to the trunk lid latch assembly so that trunk lid locking and unlocking effort is correct.



## TRUNK LID HEIGHT ADJUSTMENT


M1421008300152

## ADJUSTMENT AT BODY-SIDE

If the height between the trunk lid and the body is uneven, adjust the height in the following manner.

1. Loosen the body-side trunk lid hinge mounting bolts.
2. Adjust the height.
3. Tighten the hinge mounting bolts

**Specified torque: 23 ± 6 N·m (17 ± 4 ft-lb)**



### ADJUSTMENT AT TRUNK LID HINGE-SIDE

If the height between the trunk lid and the body is uneven, adjust the height in the following manner.


1. Remove the trunk lid damper on the trunk lid hinge.

**CAUTION**

Up to maximum 3 washers can be used.

2. Increase or decrease the number of washers until the even height between the trunk lid and the body can be obtained.
3. Tighten the trunk lid damper.

**Specified torque: 5.0 ± 1.0 N·m (44 ± 8 in-lb)**



## TRUNK LID

### REMOVAL AND INSTALLATION


M1421002200403

**CAUTION**


- Do not disassemble or throw the trunk lid gas spring into fire.
- Punch a hole in the trunk lid gas spring before disposal to release the gas inside.
- Ensure the trunk lid gas spring piston rod does not come into contact with foreign material.

**Post-installation Operation**

- Adjustment of Clearance Around Trunk Lid (Refer to P.42A-152).
- Trunk Lid Striker Adjustment (Refer to P.42A-152).
- Trunk Lid Height Adjustment (Refer to P.42A-152).



AC708687  
AC708812AB



ADHESIVE: 3M AAD PART NO.8531 HEAVY DRIP CHECK SEALER, 3M AAD PART NO.8646 AUTOMOTIVE JOINT AND SEAM SEALER OR EQUIVALENT

AC609214AD

**Trunk lid panel assembly, Trunk lid gas spring and Trunk lid hinge removal steps**

&lt;&lt;A&gt;&gt;

- Trunk room side trim <LH> (Refer to GROUP 52A, Trims [P.52A-12.](#))
- 1. Trunk lid harness connector connection
- 2. Trunk lid panel assembly
- Rear spoiler assembly <Vehicles with rear spoiler> (Refer to GROUP 51, Rear spoiler [P.51-16.](#))
- 3. High mount stoplight (Refer to GROUP 54A, High mount stoplight [P.54A-281.](#))
- 4. Taillight assembly (Refer to GROUP 54A, Taillight [P.54A-237.](#))
- Trunk lid trim (Refer to GROUP 52A, Trims [P.52A-12.](#))

&lt;&lt;B&gt;&gt;

- 5. Trunk lid harness connector
- 6. Trunk lid gas spring
- 7. Trunk lid hinge
- 8. Trunk lid damper
- 9. Washer
- Trunk lid latch removal steps**
- Trunk lid trim (Refer to GROUP 52A, Trims [P.52A-12.](#))
- 10. Trunk lid latch assembly

**Trunk lid open switch removal steps <Vehicles with keyless operation system>**

- Trunk lid trim (Refer to GROUP 52A, Trims [P.52A-12.](#))
- 11. Cylinder lock retainer
- 12. Trunk lid open switch

**Trunk lid release handle, Trunk lid release cable and Trunk lid latch striker removal steps**

- Front scuff plate <LH> (Refer to GROUP 52A, Trims [P.52A-12.](#))
- 13. Trunk lid release handle
- Front seat assembly (Refer to GROUP 52A, Front Seat Assembly [P.52A-21.](#))
- Rear seat cushion assembly, Rear seatback assembly (Refer to GROUP 52A, Rear Seat Assembly [P.52A-27.](#))
- Center pillar trim lower, Rear end trim, trunk side trim <LH> (Refer to GROUP 52A, Trims [P.52A-12.](#))
- 14. Trunk lid latch striker
- 15. Trunk lid release cable

**Damper removal**

- 16. Damper

**Trunk lid weatherstrip removal**

- >>A<< 17. Trunk lid weatherstrip


**Trunk lid stay damper bracket removal steps**

- 18. Trunk lid stay damper bracket
- 19. Trunk lid damper
- 20. Plug

**REMOVAL SERVICE POINTS**

**<<A>> TRUNK LID HARNESS CONNECTOR CONNECTION REMOVAL**


Disconnect the trunk lid harness connector.



Connector number	Connector name
F-27 (10)	Connection between the rear floor harness (LH) and trunk lid harness

**<<B>> TRUNK LID GAS SPRING REMOVAL**


As shown in the figure, slide the pin upward, then remove the trunk lid gas spring in the direction of the arrow to unscrew the trunk lid hinge.



**INSTALLATION SERVICE POINT**

**>>A<< TRUNK LID WEATHERSTRIP INSTALLATION**


Install the trunk lid weatherstrip so that the marking are aligned with the body center line.



**INSPECTION**


**TRUNK LID LATCH ASSEMBLY CHECK**

**TRUNK LID LATCH ACTUATOR CHECK**



Lever position	Battery connection	Lever operation
At the "OFF" position	<ul style="list-style-type: none"> <li>Connect terminal No. 2 and the negative battery terminal.</li> <li>Connect terminal No. 3 and the positive battery terminal.</li> </ul>	The lever moves from the "OFF" position to the "OPEN" position.


**TRUNK LID LATCH SWITCH CONTINUITY CHECK**



Lever position	Tester connection	Specified condition
ON (Latch open)	1 -2	Continuity exists (2 Ω or less)
OFF (Latch shut)	1 -2	Open circuit

**TRUNK LID OPENER SWITCH CHECK**

<VEHICLES WITH KOS>



Switch position	Terminal number	Normal value
ON (Push)	1 -2	Continuity exists (2 Ω or less)
OFF (Release)	1 -2	Open circuit

# SUNROOF

## SPECIFICATION(S)

### SERVICE SPECIFICATION

M1421000300772

Item	Standard value
Sunroof lid glass operation current A	7 or less [at 20° C(68° F)]

### SEALANT

M1421000500389

Item	Specified sealant
Sunroof assembly	Grease: Use resin -proof silicone grease

## GENERAL INFORMATION


M1426000100353

### SUNROOF FUNCTION

A motor-driven inner slide-type glass sunroof with a tilt-up mechanism is available in some models as optional equipment. Even when the sunroof is fully closed, a sufficient amount of lighting and a feeling of openness can still be obtained by opening the sunroof sunshade.

The sunroof ECU (integrated into the sunroof motor assembly) receives the ignition switch (IG1) signal transmitted by ETACS-ECU. If the ignition switch (IG1) signal turns OFF, the sunroof ECU allows the sunroof switch to open/close (timer activation) the sunroof for approximately 30 seconds. During the timer operation, if the driver's or passenger's door open is detected from the door switch signal transmitted by ETACS-ECU, the sunroof timer function stops at this time.

### SUNROOF TIMER FUNCTION



### SAFETY MECHANISM

Refer to [P.42A-190](#).

## SUNROOF DIAGNOSIS

## TROUBLESHOOTING STRATEGY

M1426001700239

Refer to GROUP 00, How to Use Troubleshooting/Inspection Service Points, Troubleshooting Contents [P.00-7](#).

## DIAGNOSTIC TROUBLE CODE CHART

M1426001900136

**⚠ CAUTION**

On troubleshooting, if the ignition switch is turned ON while disconnecting connector(s), diagnostic trouble code(s) associated with other system may be set. On completion, check all systems for diagnostic trouble code(s). If diagnostic trouble code(s) are set, erase them all.

Diagnosis Code No.	Diagnostic item	Reference page
L0630	S/R Power supply	<a href="#">P.42A-159</a>
L0632	S/R Switch fail	<a href="#">P.42A-161</a>
L0634	S/R Sensor signal	<a href="#">P.42A-163</a>
L0637	S/R Position	<a href="#">P.42A-163</a>
L0640	S/R Over load	<a href="#">P.42A-164</a>

NOTE: S/R: Abbreviation of sunroof

## TROUBLE SYMPTOM CHART

M1426002000426

**⚠ CAUTION**

During diagnosis, a diagnostic trouble code associated with other system may be set when the ignition switch is turned on with connector(s) disconnected. On completion, check all systems for diagnostic trouble code(s). If diagnostic trouble code(s) are set, erase them all.

Trouble symptom	Inspection procedure number	Reference page
Sunroof does not work at all.	1	<a href="#">P.42A-165</a>
The sunroof lid glass does not tilt-up (tilt-down, open, and close normally).	2	<a href="#">P.42A-170</a>
The sunroof lid glass does not open (tilt-up, tilt-down, and close normally).	3	<a href="#">P.42A-173</a>
The sunroof lid glass does not tilt-down or close (tilt-up and open normally).	4	<a href="#">P.42A-176</a>
Sunroof safety function does not work.	5	<a href="#">P.42A-179</a>
Sunroof timer lock function does not work.	6	<a href="#">P.42A-181</a>


DIAGNOSTIC TROUBLE CODE PROCEDURES

CODE NO. L0630: S/R POWER SUPPLY



**CAUTION**

Before replacing the ECU, ensure that the input and output signal circuits are normal.

Sunroof Motor Assembly Power Supply Circuit



AC609429AD



### COMMENTS ON TROUBLE SYMPTOM

When the terminal voltage of the sunroof motor assembly is 8 V or less, or 18 V or more, and if it continues for 60 seconds, the sunroof motor assembly will set the diagnostic trouble code No. L0630.

### PROBABLE CAUSES

- Malfunction of the sunroof motor assembly
- Damaged wiring harness and connectors

### DIAGNOSTIC PROCEDURE

**STEP 1. Check sunroof motor assembly connector D-06 for loose, corroded or damaged terminals, or terminals pushed back in the connector.**

**Q: Is sunroof switch connector D-06 in good condition?**

**YES :** Go to Step 2.

**NO :** Repair or replace the damaged component(s). Refer to GROUP 00E, Harness Connector Inspection [P.00E-2](#). Check that the sunroof works normally.

**STEP 2. Check the wiring harness between sunroof motor assembly connector D-06 (terminal 6) and fusible link (34).**


*NOTE: Also check ETACS-ECU connectors C-309 and C-316 for loose, corroded, or damaged terminals, or terminals pushed back in the connector. If ETACS-ECU connectors C-309 and C-316 is damaged, repair or replace the damaged component(s) as described in GROUP 00E, Harness Connector Inspection [P.00E-2](#).*

**Q: Is the wiring harness between sunroof motor assembly connector D-06 (terminal 6) and fusible link (34) in good condition?**

**YES :** Go to Step 3.

**NO :** The wiring harness may be damaged or the connector(s) may have loose, corroded or damaged terminals, or terminals pushed back in the connector. Repair the wiring harness as necessary. Check that the sunroof works normally.





### COMMENTS ON TROUBLE SYMPTOM

If each switch (UP, OPEN, CLOSE/DOWN) of the sunroof switch is in the ON status for 60 seconds, the sunroof motor assembly will set the diagnostic trouble code No. L0632.

### PROBABLE CAUSES

- Malfunction of the sunroof motor assembly
- Malfunction of the sunroof switch
- Damaged wiring harness and connectors

## DIAGNOSTIC PROCEDURE

**STEP 1. Check sunroof switch connector D-05 and sunroof motor assembly D-06 for loose, corroded or damaged terminals, or terminals pushed back in the connector.**

**Q: Are sunroof switch connector D-05 and sunroof motor assembly D-06 in good condition?**

**YES :** Go to Step 2.

**NO :** Repair or replace the damaged component(s). Refer to GROUP 00E, Harness Connector Inspection [P.00E-2](#). Check that the sunroof works normally.

**STEP 2. Check the wiring harness between sunroof switch connector D-05 (terminals No. 3, 5, 6) and sunroof motor assembly connector D-06 (terminals No. 4, 5, 10).**

**Q: Is the wiring harness between sunroof switch connector D-05 (terminal 3, 5, 6) and sunroof motor assembly connector D-06 (terminal No. 4, 5, 10) in good condition?**

**YES :** Go to Step 3.

**NO :** The wiring harness may be damaged or the connector(s) may have loose, corroded or damaged terminals, or terminals pushed back in the connector. Repair the wiring harness as necessary. Check that the sunroof works normally.

### STEP 3. Diagnostic trouble code recheck

Replace the sunroof switch. Recheck if the diagnostic trouble code is set.

- (1) Erase the diagnostic trouble code.
- (2) Turn the ignition switch from the LOCK (OFF) position to the ON position.
- (3) Check if the diagnostic trouble code is set.

**Q: Is the diagnostic trouble code set?**

**YES :** Replace the sunroof motor assembly.

**NO :** The procedure is complete.

**CODE NO. L0634: S/R Sensor signal**

**⚠ CAUTION**

Before replacing the ECU, ensure that the input and output signal circuits are normal.

**COMMENTS ON TROUBLE SYMPTOM**

If one of two signals from the sunroof lid glass position detection sensor cannot be detected, the sunroof motor assembly will set the diagnostic trouble code No. L0634.

**PROBABLE CAUSES**

- Malfunction of the sunroof motor assembly

**DIAGNOSTIC PROCEDURE**

**Diagnostic trouble code recheck**

Recheck if the diagnostic trouble code is set.

- (1) Erase the diagnostic trouble code.
- (2) Turn the ignition switch from the LOCK (OFF) position to the ON position.
- (3) Check if the diagnostic trouble code is set.

**Q: Is the diagnostic trouble code set?**

**YES** : Replace the sunroof motor assembly.

**NO** : The procedure is complete.

**CODE NO. L0637: S/R Position**

**⚠ CAUTION**

Before replacing the ECU, ensure that the input and output signal circuits are normal.

**COMMENTS ON TROUBLE SYMPTOM**

If the roof lid glass position is out of the specified range, ETACS-ECU will set the diagnostic trouble code No. L0637.

**PROBABLE CAUSES**

- Malfunction of the sunroof motor assembly

**DIAGNOSTIC PROCEDURE**

**STEP 1. Check the sunroof fully closed position**

- (1) Carry out the learning procedures of the sunroof fully closed position. Refer to [P.42A-189](#).
- (2) Recheck if the diagnostic trouble code is set.
  - a. Erase the diagnostic trouble code.
  - b. Turn the ignition switch from the LOCK (OFF) position to the ON position.
  - c. Check if the diagnostic trouble code is set.

**Q: Is the check result normal?**

**YES** : The procedure is complete.

**NO** : Go to Step 2.

**STEP 2. Diagnostic trouble code recheck**

Recheck if the diagnostic trouble code is set.

- (1) Erase the diagnostic trouble code.
- (2) Turn the ignition switch from the LOCK (OFF) position to the ON position.
- (3) Check if the diagnostic trouble code is set.

**Q: Is the diagnostic trouble code set?**

**YES** : Replace the sunroof motor assembly.

**NO** : The procedure is complete.

---

**CODE NO. L0640: S/R Over load**

---

** CAUTION**

Before replacing the ECU, ensure that the input and output signal circuits are normal.

**COMMENTS ON TROUBLE SYMPTOM**

If the over load (foreign material pinched) is detected consecutively five times during a sunroof operation, ETACS-ECU will set the diagnostic trouble code No. L0640.

**PROBABLE CAUSES**

- Malfunction of the sunroof motor assembly

**DIAGNOSTIC PROCEDURE**

---

**STEP 1. Check the sunroof fully closed position**

- (1) Carry out the learning procedures of the sunroof fully closed position. Refer to [P.42A-189](#).
- (2) Recheck if the diagnostic trouble code is set.
  - a. Erase the diagnostic trouble code.
  - b. Turn the ignition switch from the LOCK (OFF) position to the ON position.
  - c. Check if the diagnostic trouble code is set.

**Q: Is the check result normal?**

**YES** : The procedure is complete.

**NO** : Go to Step 2.

---

**STEP 2. Diagnostic trouble code recheck**

Recheck if the diagnostic trouble code is set.

- (1) Erase the diagnostic trouble code.
- (2) Turn the ignition switch from the LOCK (OFF) position to the ON position.
- (3) Check if the diagnostic trouble code is set.

**Q: Is the diagnostic trouble code set?**

**YES** : Replace the sunroof motor assembly.

**NO** : The procedure is complete.


SYMPTOM PROCEDURES

INSPECTION PROCEDURE 1: Sunroof does not work at All.

**CAUTION**


Before replacing the ECU, ensure that the power supply circuit, the ground circuit and the communication circuit are normal.

Sunroof Motor Assembly Power Supply Circuit



AC609432AC

TSB Revision



## CIRCUIT OPERATION

Malfunctions of the sunroof motor assembly power supply/ground system, sunroof motor assembly, or sunroof switch are suspected.

## TROUBLESHOOTING HINTS

- The sunroof switch may be defective
- The sunroof motor assembly may be defective
- The wiring harness or connectors may have loose, corroded, or damaged terminals, or terminals pushed back in the connector

## DIAGNOSTIC PROCEDURE

### Required Special Tools:

- MB992006: Extra fine probe
- MB991223: Harness set
- MB991958: Scan Tool (M.U.T.-III Sub Assembly)
  - MB991824: Vehicles Communication Interface (V.C.I.)
  - MB991827: M.U.T.-III USB Cable
  - MB991910: M.U.T.-III Main Harness A

**STEP 1. Using scan tool MB991958, read CAN bus the diagnostic trouble code.**

### **⚠ CAUTION**


To prevent damage to scan tool MB991958, always turn the ignition switch to the "LOCK" (OFF) position before connecting or disconnecting scan tool MB991958.

- (1) Connect scan tool MB991958. Refer to "How to connect scan tool (M.U.T.-III) P.42B-9."
- (2) Turn the ignition switch to the "ON" position.
- (3) Check whether the CAN bus lines related DTC is set.
- (4) Turn the ignition switch to the "LOCK" (OFF) position.

### Q: Is the DTC set?

**YES** : Repair the CAN bus line (Refer to GROUP 54C, CAN bus diagnostics table P.54C-15).

**NO** : Go to Step 2.



**STEP 2.** Using scan tool MB991958, read the diagnostic trouble code.

**⚠ CAUTION**


To prevent damage to scan tool MB991958, always turn the ignition switch to the "LOCK" (OFF) position before connecting or disconnecting scan tool MB991958.

- (1) Connect scan tool MB991958. Refer to "How to connect scan tool (M.U.T.-III) P.42B-9."
- (2) Turn the ignition switch to the "ON" position.
- (3) Check whether the sunroof motor assembly related DTC is set.
- (4) Turn the ignition switch to the "LOCK" (OFF) position.

**Q: Is the DTC set?**

**YES :** Diagnose the sunroof motor assembly. Refer to Diagnostic trouble code chart P.42A-158.

**NO :** Go to Step 3.




**STEP 3.** Check sunroof switch connector D-05 for loose, corroded or damaged terminals, or terminals pushed back in the connector.

**Q: Is sunroof switch connector D-05 in good condition?**

**YES :** Go to Step 4.

**NO :** Repair or replace the damaged component(s). Refer to GROUP 00E, Harness Connector Inspection P.00E-2. Check that the sunroof works normally.



**STEP 4. Sunroof switch check**

- (1) Remove the sunroof switch. Refer to P.42A-193.
- (2) Check continuity when the sunroof switch is operated to "OPEN", "TILT-UP" or "CLOSE/TILT-DOWN" position.

Switch position	Terminal No.	Normal value
Tilt-up	3 -4	Continuity exists (2 Ω or less)
OFF	3 -4, 4 -5, 4 -6	Open circuit
Open	4 -5	Continuity exists (2 Ω or less)
Close/tilt-down	4 -6	Continuity exists (2 Ω or less)


**Q: Is the sunroof switch normal?**

**YES :** Go to Step 5.

**NO :** Replace the sunroof switch. Check that the sunroof works normally.

**STEP 5. Check the ground circuit to the sunroof motor assembly. Measure the resistance at sunroof switch connector D-05.**

- (1) Disconnect sunroof switch connector D-05 and measure the resistance available at the wiring harness side of the connector.
- (2) Measure the resistance value between terminal 4 and ground.
  - The resistance should be 2 ohms or less.



**Q: Is the measured resistance 2 ohms or less?**

**YES :** Go to Step 8.

**NO :** Go to Step 6.

**STEP 6. Check sunroof motor assembly connector D-06 for loose, corroded or damaged terminals, or terminals pushed back in the connector.**

**Q: Is sunroof motor assembly connector D-06 in good condition?**

**YES :** Go to Step 7.

**NO :** Repair or replace the damaged component(s). Refer to GROUP 00E, Harness Connector Inspection P.00E-2. Check that the sunroof works normally.

**STEP 7. Check the wiring harness between sunroof switch connector D-05 (terminal 4) and sunroof motor assembly connector D-06 (terminal 1).**

**Q: Is the wiring harness between sunroof switch connector D-05 (terminal 4) and sunroof motor assembly connector D-06 (terminal No. 1) in good condition?**

**YES :** No action is necessary and testing is complete.

**NO :** The wiring harness may be damaged or the connector(s) may have loose, corroded or damaged terminals, or terminals pushed back in the connector. Repair the wiring harness as necessary. Check that the sunroof works normally.

**STEP 8. Check sunroof motor assembly connector D-06 for loose, corroded or damaged terminals, or terminals pushed back in the connector.**

**Q: Is sunroof motor assembly connector D-06 in good condition?**

**YES :** Go to Step 9.

**NO :** Repair or replace the damaged component(s). Refer to GROUP 00E, Harness Connector Inspection [P.00E-2](#). Check that the sunroof works normally.


**STEP 9. Check the ground circuit to the sunroof motor assembly. Measure the resistance at sunroof motor assembly connector D-06.**

- (1) Disconnect sunroof motor assembly connector D-06 and measure the resistance available at the wiring harness side of the connector.
- (2) Measure the resistance value between terminal 2 and ground.
  - The resistance should be 2 ohms or less.

**Q: Is the measured resistance 2 ohms or less?**

**YES :** Go to Step 11.

**NO :** Go to Step 10.



**STEP 10. Check the wiring harness between sunroof motor assembly connector D-06 (terminal 2) and ground.**

**Q: Is the wiring harness between sunroof motor assembly connector D-06 (terminal 2) and ground in good condition?**

**YES :** No action is necessary and testing is complete.

**NO :** The wiring harness may be damaged or the connector(s) may have loose, corroded or damaged terminals, or terminals pushed back in the connector. Repair the wiring harness as necessary. Check that the sunroof works normally.

**STEP 11. Retest the system.**

Check that the sunroof works normally.

**Q: Is the check result normal?**


**YES :** No action is necessary and testing is complete.


**NO :** Replace the sunroof motor assembly. Check that the sunroof works normally.

**INSPECTION PROCEDURE 2: The Sunroof Lid Glass does not Tilt-up (Tilt-down, Open, and Close Normally).**

**CAUTION**

Before replacing the ECU, ensure that the power supply circuit, the ground circuit and the communication circuit are normal.





**TECHNICAL DESCRIPTION (COMMENT)**

The sunroof switch or the sunroof motor assembly may be defective.

**TROUBLESHOOTING HINTS**

- The sunroof switch may be defective
- The sunroof motor assembly may be defective
- The wiring harness or connectors may have loose, corroded, or damaged terminals, or terminals pushed back in the connector

**DIAGNOSTIC PROCEDURE**

**Required Special Tools:**

- MB992006: Extra fine probe
- MB991223: Harness set
- MB991958: Scan Tool (M.U.T.-III Sub Assembly)
  - MB991824: Vehicles Communication Interface (V.C.I.)
  - MB991827: M.U.T.-III USB Cable
  - MB991910: M.U.T.-III Main Harness A

**STEP 1. Using scan tool MB991958, read the diagnostic trouble code.**

**⚠ CAUTION**


To prevent damage to scan tool MB991958, always turn the ignition switch to the "LOCK" (OFF) position before connecting or disconnecting scan tool MB991958.

- (1) Connect scan tool MB991958. Refer to "How to connect scan tool (M.U.T.-III) P.42B-9."
- (2) Turn the ignition switch to the "ON" position.
- (3) Check whether the sunroof motor assembly related DTC is set.
- (4) Turn the ignition switch to the "LOCK" (OFF) position.

**Q: Is the DTC set?**

**YES :** Diagnose the sunroof motor assembly. Refer to Diagnostic trouble code chart P.42A-158.

**NO :** Go to Step 2.




**STEP 2. Check sunroof switch connector D-05 for loose, corroded or damaged terminals, or terminals pushed back in the connector.**

**Q: Is sunroof switch connector D-05 in good condition?**

**YES :** Go to Step 3.

**NO :** Repair or replace the damaged component(s). Refer to GROUP 00E, Harness Connector Inspection [P.00E-2](#). Check that the sunroof works normally.



**STEP 3. Sunroof switch check**

(1) Remove the sunroof switch. Refer to [P.42A-193](#).

(2) Check continuity when the sunroof switch is operated to "TILT-UP" position.

Switch position	Terminal No.	Normal value
Tilt-up	3 -4	Continuity exists (2 $\Omega$ or less)
OFF	3 -4, 4 -5, 4 -6	Open circuit

**Q: Is the sunroof switch normal?**

**YES :** Go to Step 4.

**NO :** Replace the sunroof switch. Check that the sunroof works normally.

**STEP 4. Check sunroof motor assembly connector D-06 for loose, corroded or damaged terminals, or terminals pushed back in the connector.**

**Q: Is sunroof motor assembly connector D-06 in good condition?**

**YES :** Go to Step 5.

**NO :** Repair or replace the damaged component(s). Refer to GROUP 00E, Harness Connector Inspection [P.00E-2](#). Check that the sunroof works normally.

**STEP 5. Check the wiring harness between sunroof switch connector D-05 (terminal 3) and sunroof motor assembly connector D-06 (terminal 4).**

**Q: Is the wiring harness between sunroof switch connector D-05 (terminal 3) and sunroof motor assembly connector D-06 (terminal No. 4) in good condition?**

**YES :** Go to Step 6.

**NO :** The wiring harness may be damaged or the connector(s) may have loose, corroded or damaged terminals, or terminals pushed back in the connector. Repair the wiring harness as necessary. Check that the sunroof works normally.

**STEP 6. Retest the system.**

Check that the sunroof lid glass tilts up.

**Q: Is the check result normal?**


**YES :** No action is necessary and testing is complete.


**NO :** Replace the sunroof motor assembly. Check that the sunroof works normally.

**INSPECTION PROCEDURE 3: The Sunroof Lid Glass does not Open (Tilt-up, Tilt-down, And Close Normally).**

**CAUTION**

Before replacing the ECU, ensure that the power supply circuit, the ground circuit and the communication circuit are normal.



**TECHNICAL DESCRIPTION (COMMENT)**

The sunroof switch or the sunroof motor assembly may be defective.

**TROUBLESHOOTING HINTS**

- The sunroof switch may be defective
- The sunroof motor assembly may be defective
- The wiring harness or connectors may have loose, corroded, or damaged terminals, or terminals pushed back in the connector

**DIAGNOSTIC PROCEDURE****Required Special Tools:**

- MB992006: Extra fine probe
- MB991223: Harness set
- MB991958: Scan Tool (M.U.T.-III Sub Assembly)
  - MB991824: Vehicles Communication Interface (V.C.I.)
  - MB991827: M.U.T.-III USB Cable
  - MB991910: M.U.T.-III Main Harness A

**STEP 1. Using scan tool MB991958, read the diagnostic trouble code.**

**⚠ CAUTION**


To prevent damage to scan tool MB991958, always turn the ignition switch to the "LOCK" (OFF) position before connecting or disconnecting scan tool MB991958.

- (1) Connect scan tool MB991958. Refer to "How to connect scan tool (M.U.T.-III) P.42B-9."
- (2) Turn the ignition switch to the "ON" position.
- (3) Check whether the sunroof motor assembly related DTC is set.
- (4) Turn the ignition switch to the "LOCK" (OFF) position.

**Q: Is the DTC set?**

**YES** : Diagnose the sunroof motor assembly. Refer to Diagnostic trouble code chart P.42A-158.

**NO** : Go to Step 2.



**STEP 2. Check sunroof switch connector D-05 for loose, corroded or damaged terminals, or terminals pushed back in the connector.**

**Q: Is sunroof switch connector D-05 in good condition?**


**YES :** Go to Step 3.

**NO :** Repair or replace the damaged component(s). Refer to GROUP 00E, Harness Connector Inspection [P.00E-2](#). Check that the sunroof works normally.

**STEP 3. Sunroof switch check**

(1) Remove the sunroof switch. Refer to [P.42A-193](#).

(2) Check continuity when the sunroof switch is operated to "OPEN" position.



Switch position	Terminal No.	Normal value
Open	4 -5	Continuity exists (2 $\Omega$ or less)
OFF	3 -4, 4 -5, 4 -6	Open circuit

**Q: Is the sunroof switch normal?**

**YES :** Go to Step 4.

**NO :** Replace the sunroof switch. Check that the sunroof works normally.

**STEP 4. Check sunroof motor assembly connector D-06 for loose, corroded or damaged terminals, or terminals pushed back in the connector.**

**Q: Is sunroof motor assembly connector D-06 in good condition?**

**YES :** Go to Step 5.

**NO :** Repair or replace the damaged component(s). Refer to GROUP 00E, Harness Connector Inspection [P.00E-2](#). Check that the sunroof works normally.

**STEP 5. Check the wiring harness between sunroof switch connector D-05 (terminal 5) and sunroof motor assembly connector D-06 (terminal 5).**

**Q: Is the wiring harness between sunroof switch connector D-05 (terminal 5) and sunroof motor assembly connector D-06 (terminal No. 5) in good condition?**

**YES :** Go to Step 6.

**NO :** The wiring harness may be damaged or the connector(s) may have loose, corroded or damaged terminals, or terminals pushed back in the connector. Repair the wiring harness as necessary. Check that the sunroof works normally.

**STEP 6. Retest the system.**

Check that the sunroof lid glass opens.

**Q: Is the check result normal?**


**YES :** No action is necessary and testing is complete.


**NO :** Replace the sunroof motor assembly. Check that the sunroof works normally.

**INSPECTION PROCEDURE 4: The Sunroof Lid Glass does not Tilt-down or Close (Tilt-up and Open Normally).**

**CAUTION**

Before replacing the ECU, ensure that the power supply circuit, the ground circuit and the communication circuit are normal.





**TECHNICAL DESCRIPTION (COMMENT)**

The sunroof switch or the sunroof motor assembly may be defective.

**TROUBLESHOOTING HINTS**

- The sunroof switch may be defective
- The sunroof motor assembly may be defective
- The wiring harness or connectors may have loose, corroded, damaged terminals or terminals pushed back in the connector

**DIAGNOSTIC PROCEDURE**

**Required Special Tools:**

- MB992006: Extra fine probe
- MB991223: Harness set
- MB991958: Scan Tool (M.U.T.-III Sub Assembly)
  - MB991824: Vehicles Communication Interface (V.C.I.)
  - MB991827: M.U.T.-III USB Cable
  - MB991910: M.U.T.-III Main Harness A

**STEP 1. Using scan tool MB991958, read the diagnostic trouble code.**

**⚠ CAUTION**


To prevent damage to scan tool MB991958, always turn the ignition switch to the "LOCK" (OFF) position before connecting or disconnecting scan tool MB991958.

- (1) Connect scan tool MB991958. Refer to "How to connect scan tool (M.U.T.-III) P.42B-9."
- (2) Turn the ignition switch to the "ON" position.
- (3) Check whether the sunroof motor assembly related DTC is set.
- (4) Turn the ignition switch to the "LOCK" (OFF) position.

**Q: Is the DTC set?**

**YES :** Diagnose the sunroof motor assembly. Refer to [P.42A-158](#).

**NO :** Go to Step 2.




**STEP 2. Check sunroof switch connector D-05 for loose, corroded or damaged terminals, or terminals pushed back in the connector.**

**Q: Is sunroof switch connector D-05 in good condition?**

**YES :** Go to Step 3.

**NO :** Repair or replace the damaged component(s). Refer to GROUP 00E, Harness Connector Inspection [P.00E-2](#). Check that the sunroof works normally.



**STEP 3. Sunroof switch check**

(1) Remove the sunroof switch. Refer to [P.42A-193](#).

(2) Check continuity when the sunroof switch is operated to "CLOSE/TILT-DOWN" position.

Switch position	Terminal No.	Normal value
Close/tilt-down	4 -6	Continuity exists (2 Ω or less)
OFF	3 -4, 4 -5, 4 -6	Open circuit

**Q: Is the sunroof switch normal?**

**YES :** Go to Step 4.

**NO :** Replace the sunroof switch. Check that the sunroof works normally.

**STEP 4. Check sunroof motor assembly connector D-06 for loose, corroded or damaged terminals, or terminals pushed back in the connector.**

**Q: Is sunroof motor assembly connector D-06 in good condition?**

**YES :** Go to Step 5.

**NO :** Repair or replace the damaged component(s). Refer to GROUP 00E, Harness Connector Inspection [P.00E-2](#). Check that the sunroof works normally.

**STEP 5. Check the wiring harness between sunroof switch connector D-05 (terminal 6) and sunroof motor assembly connector D-06 (terminal 10).**

**Q: Is the wiring harness between sunroof switch connector D-05 (terminal 6) and sunroof motor assembly connector D-06 (terminal No. 10) in good condition?**

**YES :** Go to Step 6.

**NO :** The wiring harness may be damaged or the connector(s) may have loose, corroded or damaged terminals, or terminals pushed back in the connector. Repair the wiring harness as necessary. Check that the sunroof works normally.

---

**STEP 6. Retest the system.**

Check that the sunroof lid glass tilts down or closes.

**Q: Is the check result normal?**

**YES** : No action is necessary and testing is complete.

**NO** : Replace the sunroof motor assembly. Check that the sunroof works normally.

---

**INSPECTION PROCEDURE 5: Sunroof Safety Function does not work.**

---

**⚠ CAUTION**

Before replacing the ECU, ensure that the power supply circuit, the ground circuit and the communication circuit are normal.

**CIRCUIT OPERATION**

Malfunction of the sunroof motor assembly or incorrect learning of the sunroof fully closed position is suspected.


**TROUBLESHOOTING HINTS**

- The sunroof motor assembly may be defective
- Incorrect learning of the sunroof fully closed position

**DIAGNOSTIC PROCEDURE**

**Required Special Tools:**

- MB992006: Extra fine probe
- MB991223: Harness set
- MB991958: Scan Tool (M.U.T.-III Sub Assembly)
  - MB991824: Vehicles Communication Interface (V.C.I.)
  - MB991827: M.U.T.-III USB Cable
  - MB991910: M.U.T.-III Main Harness A



**STEP 1. Using scan tool MB991958, read the diagnostic trouble code.**

**⚠ CAUTION**

To prevent damage to scan tool MB991958, always turn the ignition switch to the "LOCK" (OFF) position before connecting or disconnecting scan tool MB991958.

- (1) Connect scan tool MB991958. Refer to "How to connect scan tool (M.U.T.-III) P.42B-9."
- (2) Turn the ignition switch to the "ON" position.
- (3) Check whether the sunroof motor assembly related DTC is set.
- (4) Turn the ignition switch to the "LOCK" (OFF) position.

**Q: Is the DTC set?**

**YES** : Diagnose the sunroof motor assembly. Refer to Diagnostic trouble code chart P.42A-158.

**NO** : Go to Step 2.

**STEP 2. Check the trouble symptom.**

Check the sunroof trouble symptom according to the following procedures.

- (1) Carry out the learning procedures of the sunroof fully closed position (Refer to P.42A-189).
- (2) Check the trouble symptom.

**Q: Is the check result normal?**

**YES** : No action is necessary and testing is complete.

**NO** : Replace the sunroof motor assembly. Check that the sunroof works normally.

---

**INSPECTION PROCEDURE 6: The Sunroof Timer Function does not work.**

---

**⚠ CAUTION**

Before replacing the ECU, ensure that the power supply circuit, the ground circuit and the communication circuit are normal.

- When the driver's door or the passenger's door are opened and closed while the sunroof timer function is on, the sunroof operative duration will be changed.

**CIRCUIT OPERATION**

- The sunroof timer function works according to the signals from the following switches:
  - Ignition switch (IG1): OFF
  - Front door switch (LH): OFF
  - Front door switch (RH): OFF
- Vehicle condition
  - Ignition switch: LOCK (OFF) position
  - Front door (LH): Closed
  - Front door (RH): Closed

**TECHNICAL DESCRIPTION (COMMENT)**

Is the sunroof timer function does not work normally, the input circuits from the switches described in "CIRCUIT OPERATION", the sunroof motor assembly, the ETACS-ECU or the LIN communication line may be defective.

**TROUBLESHOOTING HINTS**

- The front door switch may be defective
- The sunroof motor assembly may be defective
- The wiring harness or connectors may have loose, corroded, or damaged terminals, or terminals pushed back in the connector

**DIAGNOSTIC PROCEDURE**

**Required Special Tools:**

- MB992006: Extra fine probe
- MB991223: Harness set
- MB991958: Scan Tool (M.U.T.-III Sub Assembly)
  - MB991824: Vehicles Communication Interface (V.C.I.)
  - MB991827: M.U.T.-III USB Cable
  - MB991910: M.U.T.-III Main Harness A

---

**STEP 1. Check the power supply system.**

With the ignition switch in the LOCK (OFF) position, check if the following function operates normally:

- Hazard warning light
- Central door locking system

**Q: Is the check result normal?**

**YES :** Go to Step 2.

**NO :** Refer to GROUP 54A –Malfunction of ETACS-ECU power supply circuit [P.54A-700](#).

**STEP 2.** Using scan tool MB991958, read CAN bus the diagnostic trouble code.

**⚠ CAUTION**


To prevent damage to scan tool MB991958, always turn the ignition switch to the "LOCK" (OFF) position before connecting or disconnecting scan tool MB991958.

- (1) Connect scan tool MB991958. Refer to "How to connect scan tool (M.U.T.-III) P.42B-9."
- (2) Turn the ignition switch to the "ON" position.
- (3) Check whether the CAN bus lines related DTC is set.
- (4) Turn the ignition switch to the "LOCK" (OFF) position.

**Q: Is the DTC set?**

**YES :** Repair the CAN bus line (Refer to GROUP 54C, CAN bus diagnostics table P.54C-15).

**NO :** Go to Step 3.



**STEP 3.** Using scan tool MB991958, read the diagnostic trouble code.

**⚠ CAUTION**


To prevent damage to scan tool MB991958, always turn the ignition switch to the "LOCK" (OFF) position before connecting or disconnecting scan tool MB991958.


- (1) Connect scan tool MB991958. Refer to "How to connect scan tool (M.U.T.-III) [P.42B-9](#)."
- (2) Turn the ignition switch to the "ON" position.
- (3) Check whether the ETACS-ECU related DTC is set.
- (4) Turn the ignition switch to the "LOCK" (OFF) position.

**Q: Is the DTC set?**

**YES :** Diagnose the ETACS-ECU. Refer to GROUP 54B, Diagnostic trouble code chart [P.54B-6](#).

**NO :** Go to Step 4.



**STEP 4. Using scan tool MB991958, check data list.**

Check the signals related to the sunroof timer function operation.

**⚠ CAUTION**

To prevent damage to scan tool MB991958, always turn the ignition switch to the "LOCK" (OFF) position before connecting or disconnecting scan tool MB991958.

- (1) Connect scan tool MB991958. Refer to "How to connect the Scan Tool (M.U.T.-III) P.42B-9."
- (2) Turn the ignition switch to the "ON" position.
- (3) Check the data list of the ETACS.
  - Turn the ignition switch to the LOCK (OFF) position.
  - Close the driver's door.
  - Close the passenger's door.

Item No.	Item name	Normal condition
254	IG voltage	Battery positive voltage
256	Dr door ajar switch	Close
257	As door ajar switch	Close

- (4) Turn the ignition switch to the "LOCK" (OFF) position.

**OK: Normal conditions are displayed for all the items.**

**Q: Are the check results normal?**

**YES** <Normal conditions are displayed for all the items.> : Go to Step 5.

**NO** <Normal condition is not displayed for item No.

**254.>** : Refer to GROUP 54A –inspection procedure 2: the ignition switch (IG1) signal is not received [P.54A-706](#).

**NO** <Normal condition is not displayed for item No.

**256.>** : Refer to GROUP 54A –inspection procedure 5: the front door switch (driver's side) signal is not received. [P.54A-721](#).

**NO** <Normal condition is not displayed for item No.

**257.>** : Refer to GROUP 54A –inspection procedure 6: the front door switch (passenger's side) signal is not received. [P.54A-719](#).

**STEP 5. Retest the system.**

Check that the sunroof timer function works normally.

**Q: Is the check result normal?**

**YES** : No action is necessary and testing is complete.


**NO** : Replace the ETACS-ECU. Check that the sunroof timer function works normally.

**CHECK AT ECU TERMINAL**

M1426002400264

**SUNROOF MOTOR ASSEMBLY TERMINAL CHECK**







D-06




AC312987AJ

Terminal number	Check items	Check conditions	Normal conditions
1	Ground	Always	1 V or less
2	Ground	Always	1 V or less
3	Battery power supply	Ignition switch: ON	Battery positive voltage
4	Input from sunroof switch (tilt-up)	Sunroof switch: Up	1 V or less
5	Input from sunroof switch (open)	Sunroof switch: Open	1 V or less
6	Battery power supply	Always	Battery positive voltage
7	LIN communication line (between ETACS-ECU)	Always	0 to 12 V (pulse signal)
8	–	–	–
9	–	–	–
10	Input from sunroof switch (close or down)	Sunroof switch: Close or down	1 V or less

SPECIAL TOOLS

Tool	Tool number and name	Supersession	Application
<p><b>a</b></p>  <p>MB991824</p> <p><b>b</b></p>  <p>MB991827</p> <p><b>c</b></p>  <p>MB991910</p> <p><b>d</b></p>  <p>MB991911</p> <p><b>e</b></p>  <p>MB991914</p> <p><b>f</b></p>  <p>MB991825</p> <p><b>g</b></p>  <p>MB991826 MB991958</p>	<p>MB991958</p> <p>a: MB991824 b: MB991827 c: MB991910 d: MB991911 e: MB991914 f: MB991825 g: MB991826</p> <p>Scan tool (M.U.T.-III sub assembly)</p> <p>a: Vehicle communication interface (V.C.I.) b: M.U.T.-III USB cable c: M.U.T.-III main harness A (Vehicles with CAN communication system) d: M.U.T.-III main harness B (Vehicles without CAN communication system) e: M.U.T.-III main harness C (for Daimler Chrysler models only) f: M.U.T.-III measurement adapter g: M.U.T.-III trigger harness</p>	<p>MB991824-KIT</p> <p><i>NOTE: G: MB991826 M.U.T.-III Trigger Harness is not necessary when pushing V.C.I. ENTER key.</i></p>	<p><b>⚠ CAUTION</b></p> <p><b>For vehicles with CAN communication, use M.U.T.-III main harness A to send simulated vehicle speed. If you connect M.U.T.-III main harness B instead, the CAN communication does not function correctly.</b></p> <p>Communication line check (ECU check and service data)</p>

Tool	Tool number and name	Supersession	Application
	MB991223 Harness set a: MB991219 Test harness b: MB991220 LED harness c: MB991221 LED harness adapter d: MB991222 Probe	General service tools	Making voltage and resistance measurement during troubleshooting a: Connector pin contact pressure inspection b: Power circuit inspection c: Power circuit inspection d: Commercial tester connection
	MB992006 Extra fine probe	-	Making voltage and resistance measurement during troubleshooting


## ON-VEHICLE SERVICE

### WATER TEST

M1426000900490

Check if there are any leaks in the sunroof by the following procedure.


1. Fully close the roof lid glass.
2. Adjust the water pressure so that water comes out of the hose to a height of approximately 50 cm (19.7 inches) when the hose is held vertically facing upwards.
3. Hold the end of the hose approximately 30 cm (11.8 inches) above the roof and let the water run onto the weatherstrip for 5 minutes or more.
4. Check if any water leaks can be found in the room while watering. Even though there are any water leaks around the roof lid glass, it can be acceptable as long as water is caught in the drip area.



**SUNROOF FIT ADJUSTMENT**

M1426001000490

1. Fully close the sunroof lid glass.
2. Fully open the sunshade.
3. Loosen the sunroof lid glass assembly mounting screws. Adjust the sunroof lid glass height by moving the sunroof lid glass assembly along the sunroof lid guide oblong hole so that the clearance between the sunroof lid glass and the vehicle body is even throughout the circumference.
4. After adjustment, check that the sunroof operates smoothly.

**SUNROOF SAFETY FUNCTION CHECK**

M1426004400390

1. Close the sunroof lid glass while placing an approximately 10 mm (0.39 inch) thickness wood chip at right angles with the roof lid glass.
2. Check to see if the sunroof motor assembly turns in the opposite direction and the sunroof lid glass opens when the sunroof lid glass touches the wood chip. If any problem occurs, perform troubleshooting (Refer to [P.42A-158](#)).

**SUNROOF CHECK**

M1426004700432


Check to see that the sunroof operates by pressing the sunroof switch. If it does not operate, perform troubleshooting. Refer to [P.42A-158](#).

**SUNROOF TIMER FUNCTION CHECK**

M1426004300285

Check the system as described below. If the system does not work, carry out troubleshooting. Refer to [P.42A-158](#).

- Close the door and turn the ignition switch to the LOCK (OFF) position, and then check that the sunroof operates for 30 seconds.
- Close the door and turn the ignition switch to the LOCK (OFF) position. While the timer is on, open the driver's door and front passenger's door, and check that the sunroof stays during the operation. (When the driver's door or front passenger's door is opened while the timer is on, the timer will be turned off.)



## SUNROOF LID GLASS OPERATION CURRENT CHECK

M1426003200445

1. Remove the fuse of the sunroof, then connect the circuit tester as shown in the figure.
2. Turn ON the sunroof switch, then measure the operating current when the sunroof lid glass is halfway opened.  
**Standard value: 7 A or less [at 20 ° C (68 ° F)]**
3. Check the following areas if the operating current exceeds the standard value:
  - Sunroof installation, deformation and presence of any foreign substances.
  - Drive cable installation.
  - Tilting of sunroof lid glass.

## LEARNING PROCEDURES OF THE SUNROOF FULLY CLOSED POSITION

M1426004600350

### SHIFTING CONDITIONS FOR THE FULLY CLOSED POSITION ADJUSTMENT MODE

- When shifting to the forced fully closed position adjustment mode  
How to shift to the forced fully closed position adjustment mode
  1. Turn the ignition switch to the "ON" position.
  2. With the roof lid glass stopped (the position of the roof lid glass can be any position between fully opened and fully closed), press and hold the up switch for 10 seconds.
- When the anti-trap function (safety mechanism) is activated consecutively five times
- When the position information may be incorrect due to abnormal power supply during the sunroof operation

*NOTE: When installing the sunroof assembly, or installing/replacing the sunroof motor assembly, operate the forced fully closed position adjustment mode to adjust the fully closed position.*

### HOW TO ADJUST THE FULLY CLOSED POSITION <FORCED FULLY CLOSED POSITION ADJUSTMENT MODE>

1. With the roof lid glass stopped (the position of the roof lid glass can be any position between fully opened and fully closed), press and hold the up switch.

*NOTE: If operating the up switch moves the sunroof normally, use the open switch to fully open the roof lid glass. After the roof lid glass stops, press and hold the up switch.*

- Use the up switch to set the roof lid glass to the tilt-up position. The roof lid glass activates for approximately 30 mm and stops automatically when the switch is pressed once. Repeat this operation until the tilt-up position is reached and hold there for 3 seconds so that the fully closed position learning is completed.

### HOW TO ADJUST THE FULLY CLOSED POSITION <SUCH AS WHEN THE SAFETY FUNCTION IS ACTIVATED CONSECUTIVELY FIVE TIMES>

Use the up switch to set the roof lid glass to the tilt-up position. The roof lid glass activates for approximately 30 mm and stops automatically when the switch is pressed once. Repeat this operation until the tilt-up position is reached and hold there for 3 seconds so that the fully closed position learning is completed.

## SUNROOF OPERATION CHECK


M1426002600581

### **CAUTION**

Check that the following items are normal before carrying out this operation check.

- Installation condition of the sunroof assembly
- Installation condition, deformation and contamination of the sunroof drive cable
- Installation of sunroof lid glass
- Sunroof switch and sunroof motor assembly

Check that the following items. If faulty, replace the sunroof motor assembly.



AC506511AC

**BASIC OPERATION**

No.	Sunroof function	Requirements for the sunroof to function	Normal operation
01	OPEN	1. Ignition switch: ON 2. Sunroof switch: OPEN	When the open switch is operated, the sunroof lid glass stops approximately 30 mm (1.2 inches) before the fully-open position. This position is called comfort position. The sunroof lid glass can be fully opened by operating the open switch again.
02	CLOSE	1. Ignition switch: ON 2. Sunroof switch: CLOSE/TILT-DOWN	Automatically the sunroof fully closes.
03	TILT-UP	1. Ignition switch: ON 2. Sunroof switch: TILT-UP	The sunroof tilts up fully and automatically.
04	TILT-DOWN	1. Ignition switch: ON 2. Sunroof switch: CLOSE/TILT-DOWN	The sunroof tilts down fully and automatically.
05	AUTOMATIC OPERATION INTERRUPTION (OPEN OR TILT-UP)	A 1. Ignition switch: ON 2. Sunroof switch: OPEN or TILT-UP	The sunroof stops the automatic opening operation.
		B 1. Ignition switch: ON 2. Sunroof switch: CLOSE/TILT-DOWN (Push the sunroof switch to the CLOSE/TILT-DOWN position while the sunroof is automatically opening and release the switch within two seconds)	The sunroof stops the automatic opening operation.
		C 1. Ignition switch: ON 2. Sunroof switch: CLOSE/TILT-DOWN (Push the sunroof switch to the CLOSE/TILT-DOWN position more than two seconds while the sunroof is automatically opening)	The sunroof stops the automatic opening operation, and the sunroof closes while the sunroof switch is pushed to the CLOSE/TILT-DOWN position.
06	AUTOMATIC OPERATION INTERRUPTION (CLOSE OR TILT-DOWN)	A 1. Ignition switch: ON 2. Sunroof switch: CLOSE/TILT-DOWN	The sunroof stops the automatic closing operation.
		B 1. Ignition switch: ON 2. Sunroof switch: OPEN or TILT-UP (Push the sunroof switch to the OPEN or TILT-UP position while the sunroof is automatically opening and release the switch within two seconds)	The sunroof stops the automatic closing operation.
		C 1. Ignition switch: ON 2. Sunroof switch: OPEN or TILT-UP (Push the sunroof switch to the OPEN or TILT-UP position more than two seconds while the sunroof is automatically opening)	The sunroof stops the automatic closing operation, and the sunroof opens while the sunroof switch is pushed to the OPEN or TILT-UP position.

**SUNROOF TIMER MECHANISM**

In cases except the following, the basic operation and jam preventing mechanism will be maintained for 30 seconds after the ignition switch is turned to the "LOCK" (OFF) position (Sunroof timer function).

- If you open a door within that period (i.e. a door switch is on), the sunroof timer function will be cancelled immediately.
- If you turn the ignition switch to the "LOCK" (OFF) position while the timer is working, the sunroof will continue moving until it closes fully, regardless of the time-out period.

**SAFETY MECHANISM**

- If any obstacle such as a hand or a head is detected to be pinched during a sunroof lid glass closing operation, the sunroof lid glass is opened by approximately 200 mm (7.9 inches) or more. (Safety mechanism)
- During the sunroof lid glass closing operation, by continuing the sunroof close switch operation, the sunroof can be forcibly closed without activating the safety mechanism even when the obstacle is detected to be pinched.
- During the safety mechanism activation, when the sunroof close switch is operated, the sunroof lid glass stops. By continuing the close switch operation, the sunroof lid glass can be forcibly closed without activating the safety mechanism even when the obstacle is detected to be pinched.

SUNROOF



SUNROOF ASSEMBLY REMOVAL AND INSTALLATION

M1426001201129


**Post-installation operation**

- Roof lid glass assembly and sunroof assembly
- Sunroof leakage check (Refer to P.42A-188.)
  - Sunroof alignment (Refer to P.42A-188.)
  - Learning procedures for sunroof fully closed position (Refer to P.42A-189.)

**Section B – B**



**Section A – A**



Grease: Use resin - proof silicone grease

AC808809  
AC809007AB

**Sunroof switch removal**

- Front dome light (Refer to GROUP 54A, Dome Light P.54A-279.)

**Sunroof lid glass assembly removal**

1. Sunroof lid glass assembly
2. Sunroof lid weatherstrip
3. Sunroof lid glass

**Sunroof motor assembly removal steps**

- Headlining (Refer to GROUP 52A, Headlining P.52A-18.)

4. Sunroof motor assembly

**Sunroof assembly removal steps**

- Headlining (Refer to GROUP 52A, Headlining P.52A-18.)

**Sunroof assembly removal steps  
(Continued)**


- <<A>>
5. Drain pipe connection
  6. Sunroof assembly
- Front drain pipe <Driver's side> removal steps**
- Headlining (Refer to GROUP 52A, Headlining P.52A-18.)
  - Instrument panel cover lower (Refer to GROUP 52A, Instrument lower panel P.52A-9.)
- >>A<<
7. Front drain pipe (Driver's side)

**Front drain pipe <Passenger's side> removal steps**

- Headlining (Refer to GROUP 52A, Headlining P.52A-18.)
  - Satellite radio tuner assembly (Refer to GROUP 54A, Satellite radio tuner P.54A-628.)
- >>A<<
8. Front drain pipe (Passenger's side)
- Rear drain pipe removal steps**
- Side roof box, rear (Refer to GROUP 52A, Headlining P.52A-18.)
  - Rear shelf trim and trunk side trim (Refer to GROUP 52A, Trims P.52A-12.)
  - Rear wheelhouse splash shield (Refer to P.42A-12.)
- >>A<<
9. Rear drain pipe

**REMOVAL SERVICE POINT****<<A>> SUNROOF ASSEMBLY REMOVAL**


Use a pair of long nose pliers or the like to remove the sunroof assembly while turning it in the direction shown in the figure.



**INSTALLATION SERVICE POINT**

**>>A<< FRONT DRAIN PIPE/REAR DRAIN PIPE  
INSTALLATION**


Install the grommet, and adjust the drain pipe projection as shown.



**INSPECTION**

M1426001300220


**SUNROOF SWITCH CONTINUITY CHECK**



Switch position	Terminal number	Normal value
Tilt up	3 -4	Continuity exists (2 Ω or less)
OFF	3 -4, 4 -5, 4 -6	Open circuit
Open	4 -5	Continuity exists (2 Ω or less)
Close/down	4 -6	Continuity exists (2 Ω or less)

DISASSEMBLY AND ASSEMBLY

M1426001400476



AC708942 AB

**Disassembly steps**

**Disassembly steps (Continued)**

<<A>>

<<B>> >>B<<

1. Sunroof drip rail
2. Sunroof sunshade stopper
3. Sunroof sunshade knob
4. Sunroof sunshade
5. Sunroof drip plate and sunroof lid slide guide

>>A<<


6. Sunroof drip plate
7. Sunroof lid slide guide
8. Sunroof deflector
9. Sunroof pad
10. Sunroof housing

**REMOVAL SERVICE POINTS**

**<<A>> SUNROOF SUNSHADE REMOVAL**

**⚠ CAUTION**


Before removing the sunroof sunshade, clean the shaded area of the sunroof housing shown in the illustration. Otherwise, the sunroof sunshade may get dirty when it is removed.



AC708959 AB

### <<B>> SUNROOF DRIP PLATE AND SUNROOF LID SLIDE GUIDE REMOVAL

Slide the slide part of the sunroof lid slide guide to the rear of the sunroof housing, and then pull out the sunroof drip plate and sunroof lid slide guide.



### INSTALLATION SERVICE POINTS


#### >>A<< SUNROOF DRIP PLATE AND SUNROOF LID SLIDE GUIDE INSTALLATION

1. Install the sunroof drip plate and sunroof lid slide guide to the sunroof housing.
2. Push the sunroof drip plate and sunroof lid slide guide toward the front of sunroof housing until they stop.

#### **⚠ CAUTION**


**If the slide part of the sunroof lid slide guide is positioned incorrectly, the sunroof may not work normally.**

3. Push the slide part of the sunroof lid slide guide forward. Align the pin center of the slide part with the location shown in the illustration.



#### >>B<< SUNROOF PAD INSTALLATION

Align the sunroof pad with the mark on the sunroof housing, and then install it.



# LOOSE PANEL


## REMOVAL AND INSTALLATION

M1421003101101

**CAUTION**

- Disconnect the battery (-) terminal and wait for 60 seconds or more before starting work. Insulate the disconnected (-) terminal by wrapping the tape.(Refer to GROUP 52B –Service precautions P.52B-24)
- Handle the front impact sensor with sufficient caution, and do not drop the sensor or allow contact with water, oil, or others. If a dent, crack, deformation, and others are discovered, replace it with a new one.

<Headlight support upper panel>



AC70882AB

**Headlight support upper panel removal steps**

- Headlight support panel cover (Refer to GROUP 51-Front bumper assembly and radiator grille P.51-3.)
1. Hood latch
  2. Hood lock release cable
  3. Horn (LO)

**Headlight support upper panel removal steps (Continued)**


4. Charge air cooler inlet pipe B
- Front impact sensor (Refer to GROUP 52B –Front impact sensor P.52B-407.)
5. Headlight support upper panel

<<A>> >>A<<

REMOVAL SERVICE POINT

<<A>> HEADLIGHT SUPPORT UPPER PANEL  
REMOVAL


Remove the harness clamps and bolts shown in the illustration, and then remove the headlight support upper panel.




INSTALLATION SERVICE POINT

>>A<< HEADLIGHT SUPPORT UPPER PANEL  
INSTALLATION

After installing the headlight support upper panel, tighten the bolts shown in the illustration to the specified torques.





**Cowl top panel removal steps**

- Windshield wiper link assembly (Refer to GROUP 51 –Windshield wiper P.51-74.)
- 1. Strut tower bar (Refer to P.42A-14.)
- 2. Cowl top panel
- 3. Body loose panel grommet
- 4. Dash panel heat protector
- 5. Dash panel drain hose

**Front end crossmember dynamic damper removal steps**

- Engine room under cover front A and engine room under cover center (Refer to GROUP 51 –Under cover P.51-15.)
- 6. Front end crossmember dynamic damper

**Front floor backbone brace removal**

- 7. Front floor backbone brace

**Rear seatback brace removal steps**

- Rear seatback assembly (Refer to GROUP 52A –Rear seat assembly P.52A-29.)
- 8. Rear seatback brace

**Rear tie down removal steps**

- 9. Rear tie down hook
- Hydraulic unit bracket A (Refer to GROUP 22C –Hydraulic Unit P.22C-434.)
- 10. Rear tie down bracket

**Rear traction hook removal**

- 11. Rear traction hook